

# Accela Open Autosampler

## Hardware Manual

60357-97102 Revision B March 2011

DOCUMENTATION  
SURVEY

© 2011 Thermo Fisher Scientific Inc. All rights reserved.

Xcalibur is a registered trademark of Thermo Fisher Scientific Inc. in the United States.

The following are registered trademarks in the United States and other countries: Microsoft and Windows are registered trademarks of Microsoft Corporation. Teflon and Kalrez are registered trademarks of E.I. du Pont de Nemours & Company. Unimetrics is a registered trademark of Unimetrics Company. Tygon is a registered trade mark of Saint-Gobain Performance Plastics Company. Rheodyne and the Rheodyne logo are registered trademarks of Rheodyne, L.P. PAL is a trademark of CTC Analytics AG. Agilent is a registered trademark of Agilent Technologies Inc. Ryton is a registered trademark of Chevron Phillips Chemical Company. Valco, VICI, and Cheminert are registered trademarks of Valco Instruments Company, Inc. Simriz is a registered trademark of Carl Freudenberg KG Corporation. Torx is a registered trademark of Textron Inc.

PEEK is a trademark of Victrex plc.

All other trademarks are the property of Thermo Fisher Scientific and its subsidiaries.

Thermo Fisher Scientific Inc. provides this document to its customers with a product purchase to use in the product operation. This document is copyright protected and any reproduction of the whole or any part of this document is strictly prohibited, except with the written authorization of Thermo Fisher Scientific Inc.

The contents of this document are subject to change without notice. All technical information in this document is for reference purposes only. System configurations and specifications in this document supersede all previous information received by the purchaser.

**Thermo Fisher Scientific Inc. makes no representations that this document is complete, accurate or error-free and assumes no responsibility and will not be liable for any errors, omissions, damage or loss that might result from any use of this document, even if the information in the document is followed properly.**

This document is not part of any sales contract between Thermo Fisher Scientific Inc. and a purchaser. This document shall in no way govern or modify any Terms and Conditions of Sale, which Terms and Conditions of Sale shall govern all conflicting information between the two documents.

Release history: Revision A, April, 2010; Revision B, March 2011.

Software versions: LC Devices 2.5.0 or later; ChromQuest 5.0 or later.

**For Research Use Only. Not for use in diagnostic procedures.**



## Regulatory Compliance

Thermo Fisher Scientific performs complete testing and evaluation of its products to ensure full compliance with applicable domestic and international regulations. When the system is delivered to you, it meets all pertinent electromagnetic compatibility (EMC) and safety standards.

Changes that you make to your system may void compliance with one or more of these EMC and safety standards. Changes to your system include replacing a part or adding components, options, or peripherals not specifically authorized and qualified by Thermo Fisher Scientific. To ensure continued compliance with EMC and safety standards, replacement parts and additional components, options, and peripherals must be ordered from Thermo Fisher Scientific or one of its authorized representatives.

## Accela Open Autosampler

### EMC Directive 2004/108/EC

EMC compliance has been evaluated by CTC Analytics for the HTC PAL™ autosampler.

IEC 61326-1:2005

IEC 61326-2-6:2005

EN 61326-1:1997, A1:1998

CISPR 22:2005, A1:2005, A2:2006

FCC Class A, CFR 47 Part 15:2003

### Low Voltage Safety Compliance

Low Voltage Safety Compliance has been evaluated by CTC Analytics for the HTC PAL autosampler.

This device complies with Low Voltage Directive 2006/95/EC and harmonized standard EN 61010-1:2001, IEC 61010-1:2001, ANSI/UL 61010 A-1:2004, CAN/CSA 22.2 61010-1:2004.

## FCC Compliance Statement

THIS DEVICE COMPLIES WITH PART 15 OF THE FCC RULES. OPERATION IS SUBJECT TO THE FOLLOWING TWO CONDITIONS: (1) THIS DEVICE MAY NOT CAUSE HARMFUL INTERFERENCE, AND (2) THIS DEVICE MUST ACCEPT ANY INTERFERENCE RECEIVED, INCLUDING INTERFERENCE THAT MAY CAUSE UNDESIRE OPERATION.



**CAUTION** Read and understand the various precautionary notes, signs, and symbols contained inside this manual pertaining to the safe use and operation of this product before using the device.

## Notice on Lifting and Handling of Thermo Scientific Instruments

For your safety, and in compliance with international regulations, the physical handling of this Thermo Fisher Scientific instrument *requires a team effort* to lift and/or move the instrument. This instrument is too heavy and/or bulky for one person alone to handle safely.

## Notice on the Proper Use of Thermo Scientific Instruments

In compliance with international regulations: Use of this instrument in a manner not specified by Thermo Fisher Scientific could impair any protection provided by the instrument.

## Notice on the Susceptibility to Electromagnetic Transmissions

Your instrument is designed to work in a controlled electromagnetic environment. Do not use radio frequency transmitters, such as mobile phones, in close proximity to the instrument.

For manufacturing location, see the label on the instrument.

## WEEE Compliance

This product is required to comply with the European Union's Waste Electrical & Electronic Equipment (WEEE) Directive 2002/96/EC. It is marked with the following symbol:



Thermo Fisher Scientific has contracted with one or more recycling or disposal companies in each European Union (EU) Member State, and these companies should dispose of or recycle this product. See [www.thermo.com/WEEERoHS](http://www.thermo.com/WEEERoHS) for further information on Thermo Fisher Scientific's compliance with these Directives and the recyclers in your country.

## WEEE Konformität

Dieses Produkt muss die EU Waste Electrical & Electronic Equipment (WEEE) Richtlinie 2002/96/EC erfüllen. Das Produkt ist durch folgendes Symbol gekennzeichnet:



Thermo Fisher Scientific hat Vereinbarungen mit Verwertungs-/Entsorgungsfirmen in allen EU-Mitgliedsstaaten getroffen, damit dieses Produkt durch diese Firmen wiederverwertet oder entsorgt werden kann. Mehr Information über die Einhaltung dieser Anweisungen durch Thermo Fisher Scientific, über die Verwerter, und weitere Hinweise, die nützlich sind, um die Produkte zu identifizieren, die unter diese RoHS Anweisung fallen, finden sie unter [www.thermo.com/WEEERoHS](http://www.thermo.com/WEEERoHS).

## Conformité DEEE

Ce produit doit être conforme à la directive européenne (2002/96/EC) des Déchets d'Équipements Électriques et Électroniques (DEEE). Il est marqué par le symbole suivant:



Thermo Fisher Scientific s'est associé avec une ou plusieurs compagnies de recyclage dans chaque état membre de l'union européenne et ce produit devrait être collecté ou recyclé par celles-ci. Davantage d'informations sur la conformité de Thermo Fisher Scientific à ces directives, les recycleurs dans votre pays et les informations sur les produits Thermo Fisher Scientific qui peuvent aider la détection des substances sujettes à la directive RoHS sont disponibles sur [www.thermo.com/WEEERoHS](http://www.thermo.com/WEEERoHS).

CAUTION Symbol	CAUTION	VORSICHT	ATTENTION	PRECAUCION	AVVERTENZA
	<b>Electric Shock:</b> This instrument uses high voltages that can cause personal injury. Before servicing, shut down the instrument and disconnect the instrument from line power. Keep the top cover on while operating the instrument. Do not remove protective covers from PCBs.	<b>Elektroschock:</b> In diesem Gerät werden Hochspannungen verwendet, die Verletzungen verursachen können. Vor Wartungsarbeiten muß das Gerät abgeschaltet und vom Netz getrennt werden. Betreiben Sie Wartungsarbeiten nicht mit abgenommenem Deckel. Nehmen Sie die Schutzabdeckung von Leiterplatten nicht ab.	<b>Choc électrique:</b> L'instrument utilise des tensions capables d'infliger des blessures corporelles. L'instrument doit être arrêté et débranché de la source de courant avant tout intervention. Ne pas utiliser l'instrument sans son couvercle. Ne pas enlever les étuis protecteurs des cartes de circuits imprimés.	<b>Descarga eléctrica:</b> Este instrumento utiliza altas tensiones, capaces de producir lesiones personales. Antes de dar servicio de mantenimiento al instrumento, éste deberá apagarse y desconectarse de la línea de alimentación eléctrica. No opere el instrumento sin sus cubiertas exteriores quitadas. No remueva las cubiertas protectoras de las tarjetas de circuito impreso.	<b>Shock da folgorazione.</b> L'apparecchio è alimentato da corrente ad alta tensione che può provocare lesioni fisiche. Prima di effettuare qualsiasi intervento di manutenzione occorre spegnere ed isolare l'apparecchio dalla linea elettrica. Non attivare lo strumento senza lo schermo superiore. Non togliere i coperchi a protezione dalle schede di circuito stampato (PCB).
	<b>Chemical:</b> This instrument might contain hazardous chemicals. Wear gloves when handling toxic, carcinogenic, mutagenic, or corrosive or irritant chemicals. Use approved containers and proper procedures to dispose waste oil.	<b>Chemikalien:</b> Dieses Gerät kann gefährliche Chemikalien enthalten. Tragen Sie Schutzhandschuhe beim Umgang mit toxischen, karzinogenen, mutagenen oder ätzenden/reizenden Chemikalien. Entsorgen Sie verbrauchtes Öl entsprechend den Vorschriften in den vorgeschriebenen Behältern.	<b>Chimique:</b> Des produits chimiques dangereux peuvent se trouver dans l'instrument. Portez des gants pour manipuler tous produits chimiques toxiques, cancérigènes, mutagènes, ou corrosifs/irritants. Utiliser des récipients et des procédures homologuées pour se débarrasser des déchets d'huile.	<b>Química:</b> El instrumento puede contener productos químicos peligrosos. Utilice guantes al manejar productos químicos tóxicos, carcinógenos, mutágenos o corrosivos/irritantes. Utilice recipientes y procedimientos aprobados para deshacerse del aceite usado.	<b>Prodotti chimici.</b> Possibile presenza di sostanze chimiche pericolose nell'apparecchio. Indossare dei guanti per maneggiare prodotti chimici tossici, cancerogeni, mutageni, o corrosivi/irritanti. Utilizzare contenitori aprovo e seguire la procedura indicata per lo smaltimento dei residui di olio.
	<b>Heat:</b> Before servicing the instrument, allow any heated components to cool.	<b>Hitze:</b> Warten Sie erhitzte Komponenten erst nachdem diese sich abgekühlt haben.	<b>Haute Temperature:</b> Permettre aux composants chauffés de refroidir avant tout intervention.	<b>Altas temperaturas:</b> Permita que los componentes se enfríen, ante de efectuar servicio de mantenimiento.	<b>Calore.</b> Attendere che i componenti riscaldati si raffreddino prima di effettuare l'intervento di manutenzione.
	<b>Fire:</b> Use care when operating the system in the presence of flammable gases.	<b>Feuer:</b> Beachten Sie die einschlägigen Vorsichtsmaßnahmen, wenn Sie das System in Gegenwart von entzündbaren Gasen betreiben.	<b>Incendie:</b> Agir avec précaution lors de l'utilisation du système en présence de gaz inflammables.	<b>Fuego:</b> Tenga cuidado al operar el sistema en presencia de gases inflamables.	<b>Incendio.</b> Adottare le dovute precauzioni quando si usa il sistema in presenza di gas infiammabili.
	<b>Eye Hazard:</b> Eye damage could occur from splattered chemicals or flying particles. Wear safety glasses when handling chemicals or servicing the instrument.	<b>Verletzungsgefahr der Augen:</b> Verspritzte Chemikalien oder kleine Partikel können Augenverletzungen verursachen. Tragen Sie beim Umgang mit Chemikalien oder bei der Wartung des Gerätes eine Schutzbrille.	<b>Danger pour les yeux:</b> Des projections chimiques, liquides, ou solides peuvent être dangereuses pour les yeux. Porter des lunettes de protection lors de toute manipulation de produit chimique ou pour toute intervention sur l'instrument.	<b>Peligro par los ojos:</b> Las salicaduras de productos químicos o partículas que saltan bruscamente pueden causar lesiones en los ojos. Utilice anteojos protectores al manipular productos químicos o al darle servicio de mantenimiento al instrumento.	<b>Pericolo per la vista.</b> Gli schizzi di prodotti chimici o delle particelle presenti nell'aria potrebbero causare danni alla vista. Indossare occhiali protettivi quando si maneggiano prodotti chimici o si effettuano interventi di manutenzione sull'apparecchio.
	<b>General Hazard:</b> A hazard is present that is not included in the above categories. Also, this symbol appears on the instrument to refer the user to instructions in this manual.	<b>Allgemeine Gefahr:</b> Es besteht eine weitere Gefahr, die nicht in den vorstehenden Kategorien beschrieben ist. Dieses Symbol wird im Handbuch außerdem dazu verwendet, um den Benutzer auf Anweisungen hinzuweisen.	<b>Danger général:</b> Indique la présence d'un risque n'appartenant pas aux catégories citées plus haut. Ce symbole figure également sur l'instrument pour renvoyer l'utilisateur aux instructions du présent manuel.	<b>Peligro general:</b> Significa que existe un peligro no incluido en las categorías anteriores. Este símbolo también se utiliza en el instrumento par referir al usuario a las instrucciones contenidas en este manual.	<b>Pericolo generico.</b> Pericolo non compreso tra le precedenti categorie. Questo simbolo è utilizzato inoltre sull'apparecchio per segnalare all'utente di consultare le istruzioni descritte nel presente manuale.
	When the safety of a procedure is questionable, contact your local Technical Support organization for Thermo Fisher Scientific San Jose Products.	Wenn Sie sich über die Sicherheit eines Verfahrens im unklaren sind, setzen Sie sich, bevor Sie fortfahren, mit Ihrer lokalen technischen Unterstützungsorganisation für Thermo Fisher Scientific San Jose Produkte in Verbindung.	Si la sûreté d'une procédure est incertaine, avant de continuer, contacter le plus proche Service Clientèle pour les produits de Thermo Fisher Scientific San Jose.	Cuando la certidumbre acerca de un procedimiento sea dudosa, antes de proseguir, pongase en contacto con la Oficina de Asistencia Técnica local para los productos de Thermo Fisher Scientific San Jose.	Quando e in dubbio la misura di sicurezza per una procedura, prima di continuare, si prega di mettersi in contatto con il Servizio di Assistenza Tecnica locale per i prodotti di Thermo Fisher Scientific San Jose.

## CAUTION Symbol

## CAUTION

## 危険警告

## 危險警告



**Electric Shock:** This instrument uses high voltages that can cause personal injury. Before servicing, shut down the instrument and disconnect the instrument from line power. Keep the top cover on while operating the instrument. Do not remove protective covers from PCBs.

**電撃:** この計測器は高電圧を使用し、人体に危害を与える可能性があります。保守・修理は、必ず作業を停止し、電源を切ってから実施して下さい。上部カバーを外したままで計測器を使用しないで下さい。プリント配線板の保護カバーは外さないで下さい。

**電撃:** 儀器設備使用會造成人身傷害的高伏電壓。在維修之前，必須先關儀器設備並切除電源。務必要在頂蓋蓋上的情況下操作儀器。請勿拆除PCB保護蓋。



**Chemical:** This instrument might contain hazardous chemicals. Wear gloves when handling toxic, carcinogenic, mutagenic, or corrosive or irritant chemicals. Use approved containers and proper procedures to dispose waste oil.

**化学物質:** 危険な化学物質が計測器中に存在している可能性があります。毒性、発がん性、突然変異性、腐食・刺激性などのある薬品を取り扱う際は、手袋を着用して下さい。廃油の処分には、規定の容器と手順を使用して下さい。

**化学品:** 儀器設備中可能存在有危險性的化學物品。接觸毒性致癌、誘變或腐蝕/刺激性化學品時，請配帶手套。處置廢油時，請使用經過許可的容器和程序。



**Heat:** Before servicing the instrument, allow any heated components to cool.

**熱:** 熱くなった部品は冷えるのを待ってから保守・修理を行って下さい。

**高温:** 請先等高温零件冷卻之後再進行維修。



**Fire:** Use care when operating the system in the presence of flammable gases.

**火災:** 可燃性のガスが存在する場所でシステムを操作する場合は、充分な注意を払って下さい。

**火災:** 在有易燃氣體的場地操作該系統時，請務必小心謹慎。



**Eye Hazard:** Eye damage could occur from splattered chemicals or flying particles. Wear safety glasses when handling chemicals or servicing the instrument.

**眼に対する危険:** 化学物質や微粒子が飛散して眼を傷つける危険性があります。化学物質の取り扱い、あるいは計測器の保守・修理に際しては防護眼鏡を着用して下さい。

**眼睛傷害危険:** 飛濺の化学品或顆粒可能造成眼睛傷害。處理化學品或維修儀器設備時請佩戴安全眼鏡。



**General Hazard:** A hazard is present that is not included in the above categories. Also, this symbol appears on the instrument to refer the user to instructions in this manual.

**一般的な危険:** この標識は上記以外のタイプの危険が存在することを示します。また、計測器にこの標識がついている場合は、本マニュアル中の指示を参照して下さい。

**一般性危険:** 説明未包括在上述類別中的其他危險。此外，儀器設備上使用這個標誌，以指示用戶本使用手冊中的說明。

When the safety of a procedure is questionable, contact your local Technical Support organization for Thermo Fisher Scientific San Jose Products.

**安全を確保する手順がよくわからない時は、作業を一時中止し、お近くのサーモエレクトロンサンローゼプロダクトのテクニカルサポートセンターにご連絡ください。**

**如對安全程序有疑問，請在操作之前與當地的菲尼根技術服務中心聯繫。**

# Contents

	<b>Preface</b> .....	<b>xv</b>
	Related Documentation .....	xv
	Safety and Special Notices .....	xv
	Contacting Us .....	xvi
<b>Chapter 1</b>	<b>Introduction</b> .....	<b>1</b>
	Open Autosampler Components .....	1
	Main Components .....	1
	Dynamic Load and Wash (DLW) .....	3
	Specifications .....	6
	Physical Specifications .....	8
	Operating and Environmental Requirements .....	9
	Sound Pressure Level .....	9
<b>Chapter 2</b>	<b>Installing the Accela Open Autosampler</b> .....	<b>11</b>
	Installing the Autosampler and DLW .....	11
	Unpacking the Components .....	11
	Assembling the Open Autosampler .....	14
	Installing the DLW .....	26
	Electrical Connections .....	35
	System Synchronization Connections .....	38
	Connecting the Accela Open Autosampler Interconnect Cable .....	39
	Connecting the Adapter Cable for an Accela Detector or TSQ Series	
	MS Detector .....	42
	Connecting the Accela Pump Adapter Cable .....	46
	Connecting the Accela Open Autosampler to the Data System Computer .....	49
	Accela Open Autosampler Object Positions .....	49
	Defining Object Positions .....	49
	Description of Object Positions .....	51
	Injection Valve .....	60
	Valve Drives and Valves – General Remarks .....	60
	Injection Valve Flow Path .....	60

<b>Chapter 3</b>	<b>Operating the Accela Open Autosampler.....</b>	<b>65</b>
	Control Terminal .....	65
	Menu Screens .....	66
	Function Keys .....	67
	ESC and STOP Keys.....	67
	Scroll Knob and Enter Button.....	67
	Methods .....	67
	Creating Methods .....	67
	Editing and Viewing Methods.....	68
	Deleting Methods .....	69
	Job and Job Queue .....	69
	Building and Starting a Job Queue .....	70
	Cancelling a Job Queue.....	71
	Restarting a Cancelled Job Queue.....	71
	Utility Functions.....	71
	Syringe .....	72
	Tray.....	73
	Injector .....	74
	Wash Station.....	75
	Vial .....	76
	Dilutors.....	76
	Tools.....	77
	Logfile.....	78
	Info Functions.....	78
	Hardware .....	79
	Software .....	79
	Maintenance .....	79
	Free Objects/Free Items.....	80
	Setup Functions .....	80
	Sound .....	81
	Time .....	81
	Objects .....	82
	Communicating with the Computer .....	82
<b>Chapter 4</b>	<b>Installing Cycle Composer Macros or ICC Cycles Used for the DLW Option85</b>	
	Installing the Thermo PAL Driver Macros or ICC Cycles.....	86
	General Considerations .....	86
	Priming the Solvent Lines, Wash1 and Wash2 .....	87
	Standard DLW Injection Cycle .....	88
	Fast DLW Injection Cycle.....	91
<b>Chapter 5</b>	<b>Operating Dynamic Load and Wash (DLW) .....</b>	<b>93</b>
	Priming the Solvent Lines .....	93
	Location of Solvent and Waste Bottles .....	93

	Functionality of the DLW Option . . . . .	94
	DLW Pumps . . . . .	94
	DLW Actuator/Solenoid . . . . .	94
	DLW Cycle Step-By-Step . . . . .	96
	Cycle for Standard Injection . . . . .	96
	Additional Valve Toggle Step to DLW Standard Cycle . . . . .	109
	Cycle for Fast Injection . . . . .	118
<b>Chapter 6</b>	<b>Operating the Temperature Controllable Stack Coolers . . . . .</b>	<b>131</b>
	Temperature Setting, Control, and Alarm . . . . .	131
	Temperature Setting . . . . .	131
	Temperature Control . . . . .	132
	Temperature Alarm . . . . .	133
	Temperature Stability . . . . .	133
	Condensation Build-Up . . . . .	134
	Condensation Build-Up in Accela Open Autosampler Stack Coolers . . . . .	134
	Condensation Build-Up in PAL Tray Coolers . . . . .	135
<b>Chapter 7</b>	<b>Troubleshooting . . . . .</b>	<b>137</b>
	Troubleshooting Using Observed Symptoms or Error Messages . . . . .	137
	Cooled Stack Power Supply Error Messages . . . . .	141
	Troubleshooting Considerations . . . . .	142
	Tubing Connections . . . . .	142
	Solvent Delivery Pumps Not Priming . . . . .	147
	Solvent Delivery Pump Not Functioning . . . . .	147
	Standard Chromatographic Tests . . . . .	148
	Carryover Test with UV-Detection . . . . .	149
	Repeatability Test with UV-Detection . . . . .	150
<b>Chapter 8</b>	<b>Replacement Parts . . . . .</b>	<b>153</b>
	DLW Pump Module . . . . .	154
	DLW Wash Station . . . . .	154
	DLW Syringe . . . . .	154
	DLW Syringe Holder Assembly . . . . .	154
	DLW Option Spare Parts Ordering Information . . . . .	155
	DLW-2 Option Spare Parts Ordering Information . . . . .	159
	Control-xt Board . . . . .	160
	Injection Valve and Valve Rotor . . . . .	161
	Cleaning or Replacing Injection Valves . . . . .	161
	Cleaning or Replacing Valve Rotors . . . . .	162
	Injection Unit . . . . .	163
<b>Chapter 9</b>	<b>Maintenance . . . . .</b>	<b>165</b>
	Cooled Stack Maintenance . . . . .	166

<b>Appendix A</b>	<b>Appendix</b> .....	<b>169</b>
	Glossary .....	169
	Naming Convention .....	171
	Special Functions .....	172
	Accessing Extended User Mode .....	172
	Section F3-Setup .....	173
	Section F3-Setup/Objects .....	178
	PAL Firmware Overview .....	191
	PAL Firmware Error Codes .....	194
	External Connectors for Accela Open Autosampler .....	200
	System Limitations .....	206
	Accela Open Autosampler .....	206
	Sample Volume .....	206
	Wetted Parts and Material .....	206
	Tubing Internal Diameter (ID) and System Backpressure .....	207
	Interfacing the Open Autosampler to Other Devices .....	207
	Synchronization and Output Signals .....	207
<b>Appendix B</b>	<b>PAL Loader</b> .....	<b>211</b>
	Introduction .....	211
	New Features of PAL Loader Software 2.1.x .....	212
	Installation of PAL Loader Software .....	212
	Requirements .....	212
	PAL Loader Software Version 2.1.x Installation .....	213
	Multiple Shortcuts Assignment .....	214
	Dedicated Shortcut for Serial Communication .....	215
	Creating Multiple Shortcuts .....	216
	PAL Loader Software Operation .....	217
	Starting the PAL Loader Software .....	217
	Setting up COM Ports .....	218
	Serial Communication .....	219
	Reset PAL-xt to Serial Communication .....	221
	Backing Up the PAL Firmware .....	221
	Updating the PAL Firmware .....	223
	Troubleshooting .....	226
	Serial Communication with PAL Loader Software .....	226
	Reset PAL to Serial Communication .....	228
	Erratic Behavior of Software or Flash Memory .....	231
	Failure to Complete BACKUP or UPDATE Process .....	231
	Limitations .....	232
<b>Appendix C</b>	<b>Installing and Using the PAL Object Manager Software</b> .....	<b>233</b>

Installing PAL Object Manager . . . . . 234  
     Verifying System Requirements . . . . . 234  
     Installing the Object Manager Software to the Local Hard Drive . . . . . 235  
     Installing the PAL Object Lists . . . . . 235  
 Getting Started with PAL Object Manager . . . . . 236  
     Setting Up the Communication Mode . . . . . 236  
     Troubleshooting the Serial Communication Mode . . . . . 237  
     Using PAL Object Manager to Change Your System Configuration . . . . . 238  
  
**Index . . . . . 241**



## Preface

This manual describes the features, installation, and maintenance of the Accela™ Open Autosampler.

To provide us with comments about this document, click the link below. Thank you in advance for your help.



## Related Documentation

In addition to this guide, Thermo Fisher Scientific provides the following documentation as PDF files:

- *Accela Open Autosampler User Guide*
- Accela Open Autosampler Help

To access the manuals for LC Devices 2.5 or later, from the data system computer, choose **Start > All Programs > Thermo Instruments > Manuals > LC Devices > Accela > AccelaOpenAs**.

## Safety and Special Notices

Make sure to follow the precautionary statements presented in this guide. The safety and other special notices appear in boxes.

Safety and special notices include the following:



**CAUTION** Highlights hazards to humans, property, or the environment. Each CAUTION notice is accompanied by an appropriate CAUTION symbol.

**IMPORTANT** Highlights information necessary to prevent damage to software, loss of data, or invalid test results; or might contain information that is critical for optimal performance of the system.

**Note** Highlights information of general interest.

**Tip** Highlights helpful information that can make a task easier.

## Contacting Us

There are several ways to contact Thermo Fisher Scientific for the information you need.

### ❖ To contact Technical Support

Phone	800-532-4752
Fax	561-688-8736
E-mail	<a href="mailto:us.techsupport.analyze@thermofisher.com">us.techsupport.analyze@thermofisher.com</a>
Knowledge base	<a href="http://www.thermokb.com">www.thermokb.com</a>

Find software updates and utilities to download at [mssupport.thermo.com](http://mssupport.thermo.com).

### ❖ To contact Customer Service for ordering information

Phone	800-532-4752
Fax	561-688-8731
E-mail	<a href="mailto:us.customer-support.analyze@thermofisher.com">us.customer-support.analyze@thermofisher.com</a>
Web site	<a href="http://www.thermo.com/ms">www.thermo.com/ms</a>

### ❖ To get local contact information for sales or service

Go to [www.thermoscientific.com/wps/portal/ts/contactus](http://www.thermoscientific.com/wps/portal/ts/contactus).

### ❖ To copy manuals from the Internet

Go to [mssupport.thermo.com](http://mssupport.thermo.com), agree to the Terms and Conditions, and then click **Customer Manuals** in the left margin of the window.

❖ **To suggest changes to documentation or to Help**

- Fill out a reader survey online at [www.surveymonkey.com/s/PQM6P62](http://www.surveymonkey.com/s/PQM6P62).
- Send an e-mail message to the Technical Publications Editor at [techpubs-lcms@thermofisher.com](mailto:techpubs-lcms@thermofisher.com).



# Introduction

For an overview of the Accela Open Autosampler, read the following topics.

## Contents

- [Open Autosampler Components](#)
- [Specifications](#)
- [Physical Specifications](#)
- [Operating and Environmental Requirements](#)
- [Sound Pressure Level](#)

## Open Autosampler Components


This section introduces you to the major components of the Accela Open Autosampler.

- [Main Components](#)
- [Dynamic Load and Wash \(DLW\)](#)

## Main Components

[Figure 1](#) on [page 2](#) shows where major system components for the Accela Open Autosampler are located.

**Figure 1.** Accela Open Autosampler major system components



The main components of the Accela Open Autosampler are as follows:

- $x$ -,  $y$ -axes assembly
- Injection unit,  $z$ -axis
- Syringe kit for liquid injections
- Fast wash station for two different solvents
- Keypad terminal
- Safety guard
- Standard stand-alone supports, 215 mm


To set up the Accela Open Autosampler system, you need a tray set (tray holder and tray) and a stack. You can choose from many optional types of tray sets.

For further details, see [“Installing the Accela Open Autosampler”](#) on page 11.

## Dynamic Load and Wash (DLW)

This section contains an overview of the Dynamic Load and Wash (DLW) option.

**Figure 2.** Dynamic Load and Wash (DLW)



The DLW option represents a new wash station concept that combines an injection cycle with wash steps. The linked combination of the two steps, which are usually separate, minimizes cycle time and carryover.

There are two characterizing features for the DLW option:

- The sample solution never contacts the syringe itself; it is held between the holding loop.
- Wash solvents are pumped from back to front into the DLW system to intensely flush all critical parts that are in contact with the sample.

The DLW option consists of two self-priming micro pumps (mounted on a dedicated bracket), and the wetted parts are Ryton™ PPS and Kalrez™ (FFPM). The pump IN ports are connected to the wash solvent bottles and the OUT ports are connected to the DLW manifold, which is part of the assembly of the dedicated DLW syringe holder. A holding loop separates the syringe and the DLW actuator to avoid sample from contacting these parts. For a detailed list of the DLW components, see [“DLW-2 components”](#) on [page 14](#).

The syringe and holding loop are preloaded with wash solvent #1 at the start. The sample is picked up and remains separated from wash solvent #1 by an air gap. After loading the loop and injection, wash solvent #1 is pushed into the system, followed directly by wash solvent #2 to flush the critical valve paths.

The DLW syringe assembly is moved to the wash station for further cleaning steps and for preparing the Syringe and holding loop for the next cycle.

For further details, see “DLW Cycle Step-By-Step” on page 96.

There has been continuous development on the DLW option. The current version, DLW-2, has the following improvements over the DLW option:

- **Holding Loop**  
The DLW-2 Holding Loop consists of one single piece from the needle to the loop, which eliminates several tube connections and replaces the needle and flow diverter. The Holding Loop is made of high-quality stainless steel and the inner surface is passivated with acid.
- **DLW Syringe Holder back plate**  
The DLW-2 Syringe Holder back plate has changed in size and form to allow a replacement of the Holding Loop. The Actuator is supported from the back side to provide higher mechanical stability.
- **DLW Pump Assembly**  
The DLW-2 Pump Assembly is equipped with a housing to protect the electrical parts from solvent splashes.

**Note** For a list of the DLW-2 spare parts, refer to [DLW-2 Option Spare Parts Ordering Information](#) on page 159

## Differences Between DLW and DLW-2

Table 1 shows the differences between the critical parts or parameters of the DLW and DLW-2 option.

**Table 1.** Differences Between DLW and DLW-2 (Sheet 1 of 2)

Part or parameter	DLW option	DLW-2 option
<b>Holding Loop</b>		
Material	FEP tubing	Stainless steel, passivated
OD	1/16" (1.58 mm)	0.72 mm (Gauge 22)
ID	0.50 mm	0.41 mm
Length	550 mm	855 mm
Volume	108 µL	118 µL

**Table 1.** Differences Between DLW and DLW-2 (Sheet 2 of 2)

Part or parameter	DLW option	DLW-2 option
<b>Syringe Needle</b>		
Length	51 mm	Not applicable, integrated in DLW-2 Holding Loop
Gauge	22	
Material	Stainless steel	
<b>DLW Flow Diverter</b>		
Length	20.5 mm	Not applicable, integrated in DLW-2 Holding Loop
OD	0.72 mm (Gauge 22)	
ID	0.41 mm	
Material	Stainless steel	
<b>DLW Internal Volume</b>		
Total delay volume	205 $\mu$ L + Injection loop volume (204.7)	208 $\mu$ L + Injection loop volume
	Manifold: 90 $\mu$ L	Manifold: 90 $\mu$ L
	Holding Loop: 108 $\mu$ L	Holding Loop: 118 $\mu$ L
	Syringe Needle: 6.7 $\mu$ L	
	Installed Injection Loop	Installed Injection Loop

## Specifications

Table 2 lists the specifications for the Accela Open Autosampler.

**Table 2.** Accela Open Autosampler specifications (Sheet 1 of 3)

Component	Specification
Sample capacity	<ul style="list-style-type: none"> <li>• Six trays with 54 positions for 2 mL vials</li> <li>• Six deepwell or standard microtiter-plates with 96 positions</li> <li>• Six microtiter-plates with 384 positions</li> <li>• Six trays with 15 positions for 10 mL vials</li> </ul>
Thermostatted sample tray	<ul style="list-style-type: none"> <li>• 4 to +40 °C in 0.1 °C increments Peltier element</li> <li>• Temperature cooling: The specification for the stack cooler DW temperature cooling is defined as:               <ul style="list-style-type: none"> <li>• <math>T\Delta = \geq 14.0</math> °C within 60 minutes</li> <li>• <math>T\Delta = T_{\text{Roomtemperature}} - T_{\text{Stack Cooler DW}}</math></li> </ul> <p>You must reach a temperature of 14.0 °C between room temperature (22 ± 2 °C) and the stack cooler DW within 60 minutes.</p> <p>The control unit and the resulting temperature display on the stack cooler DW (display) are determinative; no comparison to an independent temperature measurement device is necessary.</p> </li> </ul>
Syringe sizes	<ul style="list-style-type: none"> <li>• 10, 25, 50, 100, 250, 500, 1000, 2500, and 5000 µL</li> <li>• Standard DLW syringe: 100 µL</li> </ul>
Liquid injection range	<ul style="list-style-type: none"> <li>• 10–100 µL with standard 100 µL syringe</li> <li>• Down to 0.1 µL with solvent sandwich technique</li> <li>• Down to 0.5 µL with optional 4-port internal loop valve</li> <li>• Up to 5000 µL with optional larger syringe and loop</li> </ul>
Replicate injections	<ul style="list-style-type: none"> <li>• 1–99 from one vial</li> </ul>
Minimum sample volume	<ul style="list-style-type: none"> <li>• 1 µL from a 3 µL sample in 1 mL tapered micro vial</li> </ul>
LC injector	<ul style="list-style-type: none"> <li>• Electrically actuated fast switching valve drive</li> <li>• 6-port Injection valve</li> <li>• VICI™/Valco™ Cheminert™ (P/N 00950-01-00336)</li> </ul> <p>Standard valve and other valves are available upon request.</p>

**Table 2.** Accela Open Autosampler specifications (Sheet 2 of 3)

Component	Specification
Wash station	<p>Fast wash station with two different wash DLW Pumps:</p> <ul style="list-style-type: none"> <li>• Two pieces. solenoid diaphragm pump</li> <li>• Self-priming               <ul style="list-style-type: none"> <li>– Flow rate range: 100 mL/min at atmospheric pressure (Pump itself, no connections to HPLC system)</li> <li>– Wetted parts: Pumps: Ryton PPS, and Kalrez (FFPM)</li> </ul> </li> <li>• Transfer tubing kit: Two pieces. PFA tubes 1/8 in. including connection fittings</li> <li>• Solvent Reservoir: 1000 mL borosilicate glass including 10 µm solvent filter</li> </ul>
Wash station	<ul style="list-style-type: none"> <li>• DLW Wash Station:               <ul style="list-style-type: none"> <li>– Wash station with two solvent ports and one waste port.</li> <li>– Two additional horizontal waste inlet ports in front to be combined with valve waste port.</li> </ul> </li> <li>• Wetted parts:               <ul style="list-style-type: none"> <li>– Wash station block: PVDF; inserts: sst 1.4404</li> <li>– Connections at bottom of inserts: PEEK™</li> </ul> </li> </ul> <p>Waste tube: Polyethylene (PE)</p>

**Table 2.** Accela Open Autosampler specifications (Sheet 3 of 3)

Component	Specification
Wash station	<ul style="list-style-type: none"> <li>• DLW Syringe assembly:               <ul style="list-style-type: none"> <li>– Syringe: Gastight Syringe 100 µL with Valflon tip Wetted parts: Glass, PTFE and Valflon</li> <li>– Syringe needle: Gauge 22 (18/25 mm OD/0.41 mm ID) Length: 51 mm, PTFE seal</li> </ul> </li> <li>• DLW Actuator/solenoid: 2/2-way flipper solenoid valve               <ul style="list-style-type: none"> <li>– Wetted parts: Body: PEEK Seal material: FFKM (Simriz™)</li> </ul> </li> </ul>
Wash station	<ul style="list-style-type: none"> <li>• DLW Manifold Solvent Selector module and Syringe Adapter assembly:               <ul style="list-style-type: none"> <li>– Wetted parts: Block: sst 1.4435 Perfluor (O-ring)</li> </ul> </li> <li>• Holding Loop: FEP Tubing OD 1/16 in., ID 0.50 mm, length 55 cm Loop Volume: 108 µL</li> <li>• DLW Flow Diverter               <ul style="list-style-type: none"> <li>– Tube dimensions: Gauge: 22 (OD 18/25 mm/ID 0.41 mm) Length: 23 mm Wetted part: Stainless chromium steel</li> </ul> </li> <li>• DLW Needle Holder assembly Wetted part: sst 1.4435</li> <li>• Standard Configuration Accela 1 (1250bar), Accela 2 (1250bar with 6-drawer cooled stack), Accela 3 (QuickQuan™), Accela 4 (EQuan™)</li> </ul>

## Physical Specifications

The physical specifications of the Accela Open Autosampler are as follows:

Height: 1045 mm (41.1 in.)

Depth: 717.5 mm (28.3 in.)

Width: 676 mm (26.6 in.)

Weight: 38.5 kg (84.9 lb)

## Operating and Environmental Requirements

Table 3 shows the operating and environmental requirements of the Accela Open Autosampler.

**Table 3.** Operating and environmental requirements

Parameter	Requirements
Operating temperature range	4 to 40 °C (39 to 104 °F)
Maximum relative humidity	75%, non-condensing
Bench space	<ul style="list-style-type: none"> <li>• At least 24 cm (10 in.) at the back</li> <li>• Access to power switches and power cords</li> <li>• Clean, level and smooth surface</li> <li>• Solid bench plate</li> </ul>
Vibration	Negligible
Static electricity	Negligible

## Sound Pressure Level

Table 4 shows the sound pressure level of the Accela Open Autosampler.

**Table 4.** Sound pressure level

Parameter	Requirements
Sound pressure level	<p>Measured value: 62 dBA (PAL System used for measurement)</p> <p>One meter from the equipment in the direction of maximum sound pressure level</p> <p>According to UL 610107A-1, 1st edition, clause 12.5 Limit &lt; 85 dBA</p> <p>dBA = A weighted sound pressure level</p>

**Note** Thermo Fisher Scientific reserves the right to make improvements, changes, or both to the product specifications without notice.



# Installing the Accela Open Autosampler

This chapter describes the installation, contact closure cable connection, computer connection, object positions, and injection valve of the Accela Open Autosampler.

## Contents

- [Installing the Autosampler and DLW](#)
- [System Synchronization Connections](#)
- [Connecting the Accela Open Autosampler to the Data System Computer](#)
- [Accela Open Autosampler Object Positions](#)
- [Injection Valve](#)

## Installing the Autosampler and DLW

This section contains information about unpacking components and assembling the open autosampler, installing the DLW, electrical connections, and the cool stack.

### Unpacking the Components

An Accela Open Autosampler system is shipped in four boxes. The contents of these boxes are as follows:

Box 1: Contains the  $x$ -,  $y$ -axes assembly, the injection unit, keypad terminal, stand-alone supports, connecting cables, power supply, syringe kit, wash station assembly, safety guard, and miscellaneous parts. See [“Open Autosampler Components”](#) on [page 1](#).

Box 2: Contains the DLW injection kit.

Box 3: Contains the cooled stack.

Box 4: Contains the Accela Open Autosampler table.

## 2 Installing the Accela Open Autosampler

Installing the Autosampler and DLW

### ❖ To unpack the components

1. Open Box 1 and first remove the accessory boxes and the injection unit before attempting to remove the  $x$ -,  $y$ -axes assembly.
2. Carefully lift the  $x$ -,  $y$ -axes assembly and remove it from the box. Hold the  $y$  axis in place while you are removing the assembly from the box. Set the  $x$ -,  $y$ -axes assembly on a bench.
3. Unpack the remaining small boxes and any other accessories.
4. When placing the Open Autosampler onto a stable surface, make sure that no objects interfere with either the  $y$  axis or the injection unit throughout the entire range of potential movement.


The Accela Open Autosampler Dynamic Load and Wash (DLW) option ships in one box (Box 2). Check for the following items:

1. DLW Pump Module
2. DLW Syringe Needle
3. DLW Syringe
4. DLW Plunger Holder
5. DLW Flow Diverter (installed in DLW Syringe assembly)
6. DLW Syringe Holder assembly
7. CD-ROM
8. Wash station cable to PAL System
9. DLW Tubing Kit
10. DLW Holding Loop (installed in DLW Syringe assembly)
11. Needle guide length tool
12. DLW Wash Station incl. waste tube
13. 2 pcs. Solvent bottle transfer line including PEEK solvent filter, 10  $\mu$ m
14. 2 pcs. 1 liter solvent reservoir bottles

Figure 4 illustrates the various DLW components as shown in the list above.

For details on how to install the DLW, see “[Installing the DLW](#)” on page 26. For a list of DLW spare parts and ordering information, see “[DLW Option Spare Parts Ordering Information](#)” on page 155.

Figure 3. DLW components



The DLW-2 option ships in one box. Check for the following items (see [Figure 4](#)):


1. DLW Pump Module
2. DLW Syringe
3. DLW Plunger Holder
4. DLW Syringe Holder assembly
5. CD-ROM
6. Wash station cable to PAL System
7. DLW Tubing Kit
8. DLW Holding Loop (installed in DLW Syringe assembly)
9. Needle guide length tool
10. DLW Wash Station incl. waste tube
11. 2 pcs. Solvent bottle transfer line including glass filter, solvent inlet, 40 µm pore size
12. 2 pcs. 1 liter solvent reservoir bottles

For a list of DLW-2 spare parts and ordering information, see “[DLW-2 Option Spare Parts Ordering Information](#)” on [page 159](#).

## 2 Installing the Accela Open Autosampler

Installing the Autosampler and DLW

**Figure 4.** DLW-2 components



### Assembling the Open Autosampler

This section contains instructions on how to assemble or install different pieces of the Accela Open Autosampler.

**Tip** Use the screwdrivers in Box 1 to install the different parts with the supplied screws.


### Assembling the Open Autosampler Table

The Accela Open Autosampler is installed on a table that comes with the product. Assemble the table before you assemble the Open Autosampler itself.

#### ❖ To assemble the autosampler table

1. Take the table top, screws, and table legs out of the shipping box (Box 4).
2. Using the supplied M5 × 30 mm flat head screws (qty 8), attach the table legs to the table top (see [Figure 5](#)).

**Figure 5.** Assembling the Open Autosampler table



3. Using the supplied M5 × 20 mm flat head screws (qty 4), secure the table legs to the gussets (see [Figure 5](#)).

## Installing the Cool Stack


Follow these instructions to install the cool stack on the table and the *x* axis on the cool stack.

**Note** A standard table plate is shipped with a left-side cool stack installation. This configuration works well with the TSQ Quantum™, Vantage™, and Velos™ mass spectrometers. On the Exactive™ mass spectrometer, the ion source is mounted to the right side of the mass spectrometer. To minimize the distance between the autosampler injection valve and the Exactive ion source, install the stack cooler on the right side of the table.

### ❖ To install the cool stack on the table


1. Decide on which side of the table you want the cool stack to be located.
2. If you want to relocate the cool stack, remove and relocate the foot stops to the desired location (see [Figure 6](#)).

**Figure 6.** Relocating the foot stops



3. Place the cool stack onto the table in the desired location, ensuring that the mounting feet reside within the designated cutouts resting on the foot stops in the table.
4. Using the supplied M5 × 8 mm pan head screws (qty 4), secure the cool stack in place (see [Figure 7](#)).

**Figure 7.** Installing the cool stack to the table



5. Using the supplied M5 × 8 mm pan head screws (qty 2), attach the remaining leg for the Open Autosampler itself to the opposite side of the cool stack (see [Figure 7](#)).


## 2 Installing the Accela Open Autosampler

Installing the Autosampler and DLW

### ❖ To install the *x* axis on the cool stack


1. Loosen the two Torx™ screws on the three mounting clamps (2 located on top of the stack and 1 on top of the the autosampler leg). [Figure 8](#) shows the stack model with 3 drawers.

**Figure 8.** A microplate stack with three drawers



2. Carefully lift the *x*-axis assembly on top of the stack with the mounting clamp teeth fitting into the grooves on the bottom of the *x* axis.
3. Ensure the clamps fit completely into the grooves. Alternately tighten the three Torx screws until the three mounting clamps are firmly in place.
4. Ensure the stack clamps are correctly attached to the *x* axis (see [Figure 9](#)). Also ensure the aligned attachment of the *x* axis to both the cool stack and autosampler leg.

**Figure 9.** Attachment of stack clamps




## Installing the Injection Unit

**Tip** Install the *x*-axis stand before you install the injection unit.

**Tip** Install the injection unit with caution. When installing it for the first time, have someone hold it in place while you insert the mounting screws.

**Figure 10.** Attaching the Open Autosampler injection unit




❖ **To install the injection unit**

1. Remove the three Torx mounting screws A, B, and C, used to fix the injection unit to the y axis.
2. Connect the ribbon cable A protruding from the front end of the y axis to the corresponding connector on the injection unit (see [Figure 11](#)).


**Tip** If the ribbon cable is not protruding, reach to the bottom of the y axis, stick in a finger, and push it out from within the y axis.

**Figure 11.** Connecting the injection unit ribbon cable




3. Hold the injection unit in place against the  $y$  axis. Make sure the two locating pins on the  $y$  axis fit into the two guide pin holes on the injection unit.
4. Place one of the screws onto the end of the supplied Torx driver. Slide the clear plastic cover on the injection unit all the way to the top. Locate the three large holes in the black anodized frame attached to the  $z$  axis inside the injection unit. Slide the frame upwards until the top hole is centered on the top threaded hole at the end of the  $y$  axis. Insert and securely tighten Torx screw A (see [Figure 12](#)).

**Figure 12.** Inserting the injection unit mounting Torx screws



5. Install the two remaining Torx screws, B and C, in the left and right mounting holes, respectively. You might have to move the elastic cord slightly to the left to insert Torx screw C into the right hole.

**Figure 13.** Open Autosampler with injection unit




## 2 Installing the Accela Open Autosampler

Installing the Autosampler and DLW

### Installing the Keypad Terminal


**Figure 14.** Installing the keypad terminal



#### ❖ To install the keypad terminal

1. Install the safety shield on the left and right sides to the outside of the x axis. Use the provided, longer thumbscrew on the side where you plan to install the keypad.
2. Install the keypad mounting bracket on either the right or the left side of the x axis.
3. Connect one end of the white coiled cable to the keypad and the other end to the TERMINAL (SER3) interface jack on the back side of the x axis (see [Figure 15](#)).

**Figure 15.** White coiled cable connection



4. Place the keypad terminal onto its mounting bracket.

## Installing the Power Supply

### ❖ To install the power supply


1. Locate the power supply, the DC power cable, and the AC power cable.
2. Set the power supply switch to OFF.
3. Connect one end of the DC power cable to the power supply and the other end to the POWER connector at the back of the *x* axis.
4. Connect the female end of the AC power cable to the power supply. Then connect the male end to an AC power outlet.

## Installing the LC Injection Valve

### ❖ To install the LC injection valve

1. Locate the valve drive, which has one clamp that is identical to the other object clamps (see [Figure 16](#)).

**Figure 16.** Installing the injection valve drive



2. Attach the valve drive to the *x* axis and tighten the mounting screw.

**Tip** To avoid delay volume between sample injection point and detection, place the injection valve near the detection device.

3. Connect the control cable from the valve drive to AUX1.

**Note** For information on installing another type or multiple valve drives, see [“Electrical Connections for 2- or 4-Injection Valves”](#) on [page 37](#).

The injection valve and rotor are preinstalled on the valve drive.


### Mounting the Pump Holder

You must always mount the pump holder on the far left of the  $x$  axis. The solvent lines are connected to the holder. Moving across the pump holder with the  $z$  axis could kink the stabilizing wire. The best way to install the holder is by dismantling the drive from the Open Autosampler  $x$  axis.

#### ❖ To mount the pump holder

1. Locate the pump holder and the two supplied Torx screws.
2. Attach the holder to the  $x$  axis as shown in [Figure 17](#).

**Figure 17.** Attaching pump holder bracket to  $x$  axis




The solvent line assembly is not preinstalled at the factory. The correct mounting is shown below.

3. Using the end of the guide wire with the longer tubing ends, connect the guide wire with the screw (M4 x 8) and the corresponding serrated lock washer to the back of the module. Pay attention to the guide groove, which orients the wire (see [Figure 18](#)).

**Tip** Always install the DLW tubing (from the kit) at the pump module first. Connect the other end, which should be connected while the assembly is not installed in the injection unit, to the DLW Syringe assembly.

**Figure 18.** Installation of the solvent tube assembly to the pump holder




4. Connect the solvent tubing of the DLW tubing kit with the premounted nut to the pump module. Maintain the order: Solvent 1 connected to the left, and Solvent 2 to the right pump module as viewed from the front of the PAL System. This avoids any confusion when refilling or changing solvents.
5. Connect the solvent lines from the solvent reservoir bottle to the inlet connectors of the pump module.

The electrical connections from the pumps to the PCB sockets, mounted on the bracket, are done at the factory.

6. Insert the provided cable into the middle socket, between the other two sockets on the PCB. For details see [Figure 19](#).

**Figure 19.** Electrical connections at the pump holder bracket




## 2 Installing the Accela Open Autosampler

Installing the Autosampler and DLW

The other end of the cable is connected to the wash station connector on the Control-xt board, as shown in [Figure 20](#).

**Figure 20.** Electrical connection from DLW pump holder to PAL-xt board



## Installing the DLW

This section provides instructions on installing the various parts of the DLW option.


### Installing the DLW Wash Station

You can connect the DLW Wash Station anywhere along the  $x$  axis. However, Thermo Fisher Scientific strongly recommends that you install it as close as possible to the injection valve. Make the travel path of the injection unit from the valve to the wash station as short as possible to keep the cycle time as brief as possible.

[Figure 21](#) shows two configurations for installing DLW modules, favoring a short connection from the injection valve to the other HPLC system components on the one hand, and always having the DLW Wash Station close to the injection valve on the other. Always attach the DLW Pump Module, with the connected DLW tubing from the kit, on the far left side of the  $x$  axis.

Such a configuration also has the advantage that you can connect the waste tube from the injection valve to the front waste inlet of the wash station module. This waste tube is part of the DLW option kit.

**Figure 21.** Mounting the DLW option modules in combination with the injection valve



❖ **To install the DLW Wash Station**

1. Locate the DLW Wash Station module.
2. Attach the holder to the  $x$  axis at the selected position as shown in [Figure 17](#).
3. Connect the waste from the injection valve to the DLW Wash Station.
4. Connect the waste tube to the wash station waste adapter.

Replace the dummy plug or plugs on the front if you are using them to connect the waste line coming from the injection valve. This simple connection of waste lines cleans up the system, avoiding several waste lines running to the waste container.


**Tip** Use the other two dummy plugs underneath the waste block for the DLW option.

You can connect the DLW tubing from the DLW pump outlet at these wash station inlet ports. The functionality of the fast wash station is then applied using this configuration.

## 2 Installing the Accela Open Autosampler

Installing the Autosampler and DLW

**Figure 22.** Attaching the DLW Wash Station to the  $x$  axis



**Tip** The waste tube must be positioned below the injection valve. Make sure that the waste liquid flows into the waste container without restriction. The waste tube must always be above the liquid level in the waste container.

### Installing the DLW Syringe Holder Assembly

**Tip** Before you insert a syringe, first verify the position, Change Syr. Do not locate the Change Syringe position above an object where the needle could collide with a vial, for example.

Path: **Menu > Utilities > Syringe > function key F3 (Change Pos).**


Move the PAL injection unit to a location where no collision can occur with the  $z$  axis by selecting the  $x$  and  $y$  axes appropriately. The value for the  $z$  axis is given as a default and a change of this position is not necessary in standard operation.

This precaution helps avoid needle damage during routine operation. Nevertheless, the description in the next section on how to install the DLW Syringe assembly recommends switching off the unit and inserting the assembly without using the Open Autosampler command, Change Syringe.

The DLW Syringe Holder differs from standard liquid syringe holders. The DLW manifold is attached to the syringe holder. The DLW Actuator/Solenoid and the Holding Loop connecting the syringe inlet (bottom) and Syringe Needle are attached to the DLW manifold. All of these parts are factory installed. See [Figure 23](#).

Figure 23. Front view of the DLW Syringe Holder assembly

### DLW Syringe Holder Assembly




### Preparing and Installing the DLW Syringe

This section contains information on how to prepare and install the DLW Syringe.

#### ❖ To prepare and install the DLW Syringe

1. Prepare the DLW Syringe by inserting the DLW Plunger Holder.
  - a. Move the plunger manually down to the stop position, and release a slight amount of pressure to the plunger tip by pulling a fraction of a millimeter backwards.
  - b. Install the DLW Plunger Holder and tighten the Allen screw (Allen Key #6) firmly.


**Figure 24.** Inserting DLW Plunger Holder on DLW Syringe



**Tip** Make sure the syringes are primed before beginning sample preparation. Prime all liquid syringes manually first before inserting them into the Open Autosampler system.

2. Screw the prepared DLW Syringe into the holder. Hold the syringe at the lower metal mount to tighten the syringe.

**Figure 25.** Inserting DLW Syringe into holder



**CAUTION** Make sure to hold the syringe on the metal mount to tighten the syringe. Holding the glass barrel while tightening can damage the seal where the glass meets the metal.

**Note** Do not mount the syringe needle at this stage.

## Connecting the DLW Tubing to the Syringe Holder

**Note** Thermo Fisher Scientific recommends connecting the DLW tubing from the kit to the syringe holder while the assembly is not inserted in the  $x$  axis.

**Note** The wetted parts of the DLW Actuator/Solenoid are PEEK for the body and FFKM (Simriz) for the seal material.

PEEK tubing exhibits excellent chemical resistance to most of the chemicals used. However, the following solvents are not recommended for use with PEEK: DMSO, THF, methylene chloride (dichloromethane), nitric acid, or sulfuric acid. For more details, refer to the compatibility tables provided by the manufacturer of PEEK material or components.

### ❖ To connect the DLW tubing to the syringe holder

1. Connect the end of the sleeved tubing with the short tubes to the DLW Syringe Holder assembly. See “[Mounting the Pump Holder](#)” on [page 24](#).
2. Use the groove in the block at the back of the DLW Manifold to orient the guide wire. To connect, use the provided screw (M3×5) and the corresponding serrated lock washer.
3. Test to see if the wire tension is enough to keep the tubing in an upright position but low enough to move the syringe holder manually along the  $x$  axis.

**Note** The design of the DLW Manifold and the concept of washing by active pumping and active closing of the lines by the DLW Actuator theoretically do not require a predefined solvent line position.

A problem could occur if solvent is refilled or exchanged while the tubing still contains solvent from the previous setup. Always keep the lines at the same position, and prime the entire system with caution to prevent unnecessary confusion. For further details, see [Chapter 5, “Operating Dynamic Load and Wash \(DLW\).”](#)

4. Connect solvent line 1 to the upper port and solvent line 2 to the lower port at the left side of the DLW Manifold.

Make sure the order of the tube connections, upper or lower, is consistent. In certain applications you cannot mix types of solvents; for example, biofluid sample solution should not come in contact with highly concentrated organic solvents.

### Inserting the DLW Syringe Holder Assembly into the Injection Unit


**Tip** Insert the DLW Syringe Holder assembly when the Open Autosampler is powered off.

❖ **To insert the DLW Syringe Holder assembly into the injection unit**

1. Manually move the PAL injection unit aside to allow free movement of the syringe slider. Lower the syringe slider (see [Figure 26](#)) in order to gain access to install the DLW Syringe assembly.

Match the magnetic pins of the syringe holder using the counter positions at the syringe slider.

**Figure 26.** Inserting the DLW Syringe Holder assembly into the injection unit




2. Press the syringe holder firmly against the z-axis slider to ensure that the holder engages.



**CAUTION** Do not press against the DLW Actuator/Solenoid. The mounting of the latter to the DLW Manifold is fragile and might break.


3. Tighten the knurled screw to fix the holder assembly to the syringe slider (see [Figure 27](#)).

**Figure 27.** Fixing syringe holder to syringe slider



4. Move the plunger up (plunger holder) until the thread of the screw catches the thread of plunger bushing. Tighten the screw to fix the plunger holder (see [Figure 28](#)).

**Figure 28.** Connecting the DLW Syringe plunger holder



5. Tighten the holding screw to secure the syringe holder position.

## 2 Installing the Accela Open Autosampler

Installing the Autosampler and DLW




**CAUTION** Make sure the removable needle fits leak-tight to the syringe. A Teflon seal is provided. When installing the seal, ensure that the hole is open and that no fuzzy (lint) polymer material, which might clog the needle, is in the path. When slipping the Teflon seal over the needle, pay attention to the sharp edges of the needle that can cut into the polymer, which again might cause the needle to clog.

6. Move the lower needle guide carefully up and down to make sure that the needle tip does not catch on the guide.

### Installing the Valve Needle Guide Assembly

This section describes how to install the Valve Needle Guide assembly. Perform the installation as illustrated in [Figure 29](#).

**Figure 29.** Installing the standard valve needle guide



### Injection Valve Plumbing and Connection to DLW Wash Station

#### ❖ To plumb the injection valve and connect it to DLW Wash Station


1. Connect the injection valve waste line from port 2 (for example, the standard Cheminert valve type), as shown in [Figure 30](#), to the front waste port of the wash station.

**Tip** If you use two injection valves in the PAL configuration, connect the second waste line to the lower front waste port of the DLW Wash Station. If you use only one connector, apply a dummy plug to the second port on the wash station.

2. Place the waste tube from the DLW Wash Station into the waste container.

**Tip** You must position the waste container below the injection valve. Make sure that the waste liquid flows into the waste container without restriction.

**Figure 30.** Solvent line plumbing on Cheminert valve types



## Electrical Connections

This section contains information on setting up the electrical connections of the Accela Open Autosampler.

### Electrical Connections for Single Injection Valve Setup




**CAUTION** Always power off the Open Autosampler before connecting or disconnecting the DLW cable or any other accessory cables.

The electrical connection of the DLW option is identical for the PAL HTS-xt and the HTC-xt models. Both models use the same board.

The diagram in [Figure 31](#) shows an installation using the valve drive connected to the AUX interface. If you use a serial or multiposition valve drive, see the diagrams for 2- or 4-injection valve combinations ([Figure 32](#) and [Figure 33](#)).


**Figure 31.** Electrical connection, DLW option on a PAL-xt



### DLW Option Installation in Combination with 2- or 4- Injection Valves

You can combine the DLW option with Open Autosampler systems using a setup of 2- or 4-injection valves (see [Figure 32](#)). The concept of the DLW option is that the crucial parts of the wash station are attached to the injection unit.

**Figure 32.** DLW option in combination with 4-injection valves



The sample is taken up into the Holding Loop, and the syringe is actually the prepared reservoir for the following wash step after the loop filling and injection step.

Following this concept allows for more than one injection valve in the Open Autosampler configuration. Neither a special setup nor additional modules are necessary to inject into and clean one or more valves connected to the Open Autosampler system. As mentioned, the crucial DLW parts are attached to the injection unit at any available position.


### Electrical Connections for 2- or 4-Injection Valves

Connect the valve drives as shown in [Figure 33](#).

Because you can only use the DLW option in combination with the PAL-xt systems, you must connect the first cable from the PAL Interface MODBUS to the serial valve drive connector A. Each drive is connected with daisy-chain cabling.

The last serial drive connector B remains open or unused. The interface MODBUS provides the electrical current and interface logic.

**Figure 33.** Electrical connections to 4-injection valves, daisy-chaining with PAL-xt system



## Installing the Power Supply for the Cooled Stack

The power supply for the cooled stack has a built-in control unit with display (P/N CH-952995).

### ❖ To install the power supply

1. Locate the power supply and the AC power cable.
2. Set the power supply switch to OFF.
3. Connect the open end of the DC power cable from the stack/tray cooler to the power supply connector labeled, Peltier Thermostat.
4. Connect the female end of the AC power cable to the power supply, and then connect the male end to an AC power outlet.
5. Set the switch on the power supply to ON.
6. Observe the display to ensure that it reads the preset temperature of +10 °C.

## System Synchronization Connections

The system interconnect cables and adapter cables that synchronize the run signals for an LC or LC/MS system with an Accela Open Autosampler depend on the Accela pump model, the mass spectrometer model, and whether the LC system includes an Accela detector.

Table 5 lists the system interconnect and adapter cables that Thermo Fisher Scientific supplies with the Accela Open Autosampler or by special order.

**Table 5.** Accela Open Autosampler contact closure and adapter cables

Cable description	Part number	Use
Accela Open Autosampler system interconnect cable  (supplied with autosampler)	60157-63024	Required for all hardware configurations
Accela detector and MS detector adapter cable  (supplied with autosampler)	60157-63026	Required for hardware configurations that include one or more of the following: <ul style="list-style-type: none"> <li>• Accela detector</li> <li>• TSQ or Exactive mass spectrometer</li> </ul>
Accela Pump adapter cable  (available by special order)	60157-63022	Required for the Accela Pump

**Note** Thermo Fisher Scientific has discontinued the Accela Pump.


To connect the required cables listed in [Table 5](#), follow these procedures as appropriate:

- [Connecting the Accela Open Autosampler Interconnect Cable](#)
- [Connecting the Adapter Cable for an Accela Detector or TSQ Series MS Detector](#)
- [Connecting the Accela Pump Adapter Cable](#)

## Connecting the Accela Open Autosampler Interconnect Cable

[Figure 34](#) shows the Accela Open Autosampler interconnect cable (P/N 60157-63024).

**Figure 34.** Accela Open Autosampler interconnect cable (P/N 60157-63024)



### ❖ To connect the Accela Open Autosampler interconnect cable to the LC or LC/MS system modules

1. Plug the DB15 connector (cable end labeled **TO A/S**) into the Interface 1 receptacle on the back panel of the Accela Open Autosampler (see [Figure 35](#)).
2. Depending on the Accela pump model, do one of the following:
  - a. If your LC system includes an Accela 600 or 1250 Pump, plug the 25-pin connector (cable end labeled **TO PUMP**) into the D-Sub25 receptacle on the back panel of the pump (see [Figure 35](#)).
  - b. If your LC system includes an Accela Pump, go to [“Connecting the Accela Pump Adapter Cable”](#) on [page 46](#).
3. Depending on the LC detector or MS detector setup, do one of the following:
  - If your LC or LC/MS system includes an Accela detector or a TSQ Series or Exactive mass spectrometer, go to [“Connecting the Adapter Cable for an Accela Detector or TSQ Series MS Detector”](#) on [page 42](#).


–or–

## 2 Installing the Accela Open Autosampler

### System Synchronization Connections

- If your LC/MS system includes an MSQ Plus Mass Detector or an LTQ Series mass spectrometer, but does not include an Accela detector, go to [step 4](#).
4. Connect the cable labeled **TO MSQ/LTQ/LXQ** to the mass spectrometer as follows:
    - For the MSQ Plus Mass Detector, connect the cable to the User I/O Start In pins on the MS detector's back panel (see [Figure 35](#)).
    - For the LTQ Series mass spectrometer, connect the cable to the Peripheral Control Start In pins on the MS detector's right panel (see [Figure 35](#)).


**Figure 35.** Accela Open Autosampler interconnect cable connections (back panel view of the LC/MS modules)



## Connecting the Adapter Cable for an Accela Detector or TSQ Series MS Detector

Use the Accela detector and MS detector adapter cable (see [Figure 36](#)) to connect the Accela Open Autosampler to an Accela detector, a TSQ or Exactive mass spectrometer, or both.


**Figure 36.** Adapter cable for an Accela detector and a TSQ Series MS detector (P/N 60157-63026)



### ❖ To connect the LC detector and MS detector adapter cable

1. If you have not already done so, connect the Accela Open Autosampler interconnect cable to the autosampler and the Accela 600 or 1250 Pump (see “[Connecting the Accela Open Autosampler Interconnect Cable](#)” on page 39).
2. Connect the adapter cable to the interconnect cable by plugging the 2-pin male connector labeled **TO 60157-63024** on the adapter cable into the 2-pin female connector labeled **TO MSQ/LTQ/LXQ** on the interconnect cable (see [Figure 37](#)).

**Figure 37.** Accela Open Autosampler interconnect cable to detector adapter cable connection




3. Using the adapter cable connectors, make the appropriate connections to an Accela detector, a Thermo Scientific mass spectrometer, or both as follows:
  - For an Accela detector (UV/Vis, PDA, or RI), connect the 8-pin connector attached to the cable labeled **TO PDA** to pins 1 through 8 on the detector's back panel.
  - For an MSQ Plus Mass Detector, connect the 2-pin connector attached to the cable labeled **TO LTQ/LXQ/MSQ** to the Start In pins on the mass spectrometer's back panel.
  - For an LTQ Series mass spectrometer, connect the 2-pin connector attached to the cables labeled **TO LTQ/LXQ/MSQ** and **TO LCQ FLEET** to the Start In pins on the right side of the mass spectrometer.
  - For a TSQ or Exactive mass spectrometer, connect the cable labeled **TSQ/EXACTIVE** to the Start In pins on the right side of the mass spectrometer.

Figure 38 and Figure 39 show the contact closure connections for a standalone Accela LC system and an LC/MS system, respectively.


## 2 Installing the Accela Open Autosampler

System Synchronization Connections

**Figure 38.** Contact closure connections (back panel) for a standalone Accela LC system with an Accela Open Autosampler



**Figure 39.** Accela Open Autosampler interconnect cable and detector adapter cable connections




## Connecting the Accela Pump Adapter Cable

Use the Accela Open Autosampler interconnect cable (see [Figure 34](#) on [page 39](#)) and the Accela Pump adapter cable (see [Figure 40](#)) to interconnect the system modules for the following hardware configurations:

- Accela Open Autosampler, Accela Pump, and MSQ Plus Mass Detector
- Accela Open Autosampler, Accela Pump, and an LTQ Series (LCQ Fleet, LXQ, LTQ XL, or LTQ Velos) mass spectrometer


**Figure 40.** Accela Pump adapter cable



### ❖ To connect the Accela Pump adapter cable

1. If you have not already done so, plug the DB15 connector of the Accela Open Autosampler interconnect cable into the Interface 1 port of the Accela Open Autosampler.
2. Connect the 25-pin connector of the Accela Pump adapter cable to the 25-pin connector of the Accela Open Autosampler interconnect cable (see [Figure 41](#)).

**Figure 41.** Accela Open Autosampler Interconnect cable to Accela Pump adapter cable connection




3. Connect the 8-pin connector of the Accela Pump adapter cable to pins 1 through 8 on the back panel of the Accela Pump (see [Figure 42](#)).

4. Connect the 2-pin connector of the Accela Open Autosampler interconnect cable to the mass spectrometer (see [“Connecting the Accela Open Autosampler Interconnect Cable”](#) on [page 39](#)).

## 2 Installing the Accela Open Autosampler

System Synchronization Connections

**Figure 42.** Accela Open Autosampler interconnect cable and Accela Pump adapter cable connections




## Connecting the Accela Open Autosampler to the Data System Computer

### ❖ To connect the autosampler to the data system computer

Using the serial cable that is supplied with the autosampler, connect the SER 1 port on the back panel of the autosampler to the serial port on the back panel of the data system computer (see [Figure 43](#)).

**Figure 43.** Data system connection (firmware 4.1.0)



## Accela Open Autosampler Object Positions

This section contains information about Accela Open Autosampler object positions.

### Defining Object Positions

**Note** Remove the syringe adapter from the injection unit before performing the following steps.


The objective is to define the reference positions for all Accela Open Autosampler objects. Make sure to properly mount the tray holders, valve drives, and wash station to the Accela Open Autosampler  $x$  axis. The following describes how to teach the reference position for a tray holder. The described procedure is common to all Accela Open Autosampler objects.

## 2 Installing the Accela Open Autosampler

### Accela Open Autosampler Object Positions

#### ❖ To teach the reference position for a tray holder


1. Switch on the Accela Open Autosampler power supply.
2. Observe the keypad display. The model name, Accela Open Autosampler, appears along with the software version number. The Job Queue menu screen then appears.
3. When the Job Queue menu appears, complete the following sequence (common to all objects):



where the Named Tray Holder represents a predefined tray holder (for example, TH1dr1 or Stack1).

After selecting Named Tray Holder, the  $x$ ,  $y$ ,  $z$  positions associated with the object are displayed (see [Figure 44](#)).

**Figure 44.** Menu screen object Tray Holder



4. Select **Position X** and press ENTER. The injection unit moves to the previously defined  $x$ -axis position.
5. Rotate the outer knob to adjust the  $x$ -axis position to the tray holder reference position.
6. Press the inner knob to enter the Position X value.
7. Repeat [step 4](#) through [6](#) for Position Y and Position Z.  
If the F3 button (Move to Zero) is activated, the injection unit moves to the HOME position.
8. Verify the defined  $x$ ,  $y$ ,  $z$  positions by pressing F1: Check Pos.

The release of PAL firmware level 4.1.2 makes possible the correction of all three axes,  $x$ ,  $y$ , and  $z$ , in the firmware class tray. You can correct the inclination for a tilted tray in the direction of the row, the column, or both. Teaching is possible in the Utilities section by using the path: **Menu > Utilities > Trays**.


## Description of Object Positions

This section contains a description of the object positions.

### Tray Holders Stack or Stack Cooler with 3 or 6 Drawers

The reference position for a stack or stack cooler is identical. The reference position in the case of a 3-drawer stack is a hole in the upper drawer and in a 6-drawer stack, in the second drawer from the top (same height level), as shown in [Figure 45](#).

**Figure 45.** Stack reference position



For the object stack/tray cooler, you must properly position the  $x$ ,  $y$ ,  $z$  axes in the Open Autosampler system.

After  $x$ -,  $y$ -,  $z$ -axis positioning of stack cooler model 6DW or 12MT, add the following steps to verify the correct installation of the module.

#### ❖ To verify the correct installation of the module

1. Close the drawer manually.

Go to **Menu > Setup > Objects > TrayHolders > *corresponding device***.

Press function key F1, Check Pos. The injection unit moves to the predefined position.

2. Open the bottom drawer manually.
3. Remember the  $z$  value. Turn the  $z$  axis all the way down to check that the black needle guide of the injection unit fits neatly into the position hole of the drawer.
4. If the position is proper, turn the injection unit slider back to the original  $z$  value. Then close the drawer.

## 2 Installing the Accela Open Autosampler

### Accela Open Autosampler Object Positions

5. If the position is off by one or two millimeters, compensate for any discrepancy in the  $x$ ,  $y$  position seen between the upper and lower drawer.
6. If the position is off by more than one or two millimeters, check the bracket attachment of the module to the  $x$  axis carefully. If in doubt, loosen the claws again and reposition the unit on the  $x$  axis.

If this action is not successful, check the  $x$ - to  $y$ -axis angle and the  $y$ - to  $z$ -axis angle. If one of these angles is not  $90^\circ$ , make corrections.

Ensure also that the  $y$  axis runs parallel to the open drawer. If this is not the case, the bracket alignment is probably out of square.

**Note** The  $y$  axis tolerance for the teaching point is limited to 129.4 mm (5.09 in.).

When defining the position of the stack cooler, make sure you stay within this tolerance with the reference point at the top drawer.



**CAUTION** Do not use vials without a sealing cap or a microtiter- or deepwell-plate without a plate seal. Vapor phase from organic solvents can be hazardous and flammable. Acidic vapor phase can cause corrosion to critical mechanical parts.

## Trays


Generally, you do not need to teach a tray position. The tray holder has a teaching position, as described earlier. The firmware assigns a tray to the tray holder. The numbers (values) for the relevant items are stored in the firmware object tray. To complete the combination of a tray holder and a tray, you must assign the corresponding tray type to the tray.

The tray type contains the geometric data for the tray and information, such as how many samples are in a row and a column in the tray. A tray type defines the pattern and sampling sequence of the sample location within a tray.

Again, the tray is physically placed in the tray holder, the firmware assigns the tray to the tray holder and the tray type to the tray. This is routine procedure as long as no special circumstances intervene, such as customized trays or tray types.

PAL Firmware level 4.1.2 or later now makes a correction possible if the tray surface is not exactly horizontal and planar but is inclined in one or more axes. The ability to make the correction is standard at level 4.1.x. A dialog box opens the moment the tray has been checked out at the corners to verify vial positions and heights. The following sections explain how to correct a possible inclination.


**Figure 46.** Demonstrating a possible inclination of the tray in x, y, z axes



### Definition of a Tray Row and Column

The Accela Open Autosampler defines rows and columns by the order in which samples are treated. A row is not associated with an *x* or *y* axis. [Figure 47](#) provides a visual definition with tray type VT54.

**Figure 47.** Tray type VT54




### Correction for Inclination in X, Y, or Z Axes

The following describes the correction using the path to the Utilities section.

### ❖ To correct for inclination in x, y, or z axes


1. After selecting the Utilities function, Tray, verify whether the tray type assigned corresponds to the tray placed into the tray holder. If so, check the vial positions at the three corners of the tray. The F3 function key activates this.



A message box opens, displaying a note: Adjust offset X-, Y-, Z for Position 001.

2. Select **OK** to adjust all three axes perfectly by the top of the vial. This step is only valid for position number 001. See [Figure 48](#).

**Figure 48.** Message to adjust offset x,y,z for position 001




3. To check the next corner of the tray, activate the F3 function key again, for example, tray type VT54, position 009.

The message that appears prompts you to correct a possible inclination of the row.

4. Select **OK** to adjust the three axes perfectly to match the vial top or, in case of a well-plate, the top of the plate. See [Figure 49](#).


**Figure 49.** Message to adjust row inclination at the second tray corner position



5. To move to the next corner of the tray, activate the F3 function key for position 54 in the example of tray type VT54.

You can correct a possible inclination of the tray column in the same manner as you did with the first two corners. See [Figure 50](#).

**Figure 50.** Message to adjust column inclination at the third tray corner position




The three corner points are now adjusted for a possible inclination of the tray in any axis. Without further teaching, the Accela Open Autosampler interpolates a possible deviation from an ideal axis position for the other vials, caused by variance from the horizontal.

**Note** For routine work using a standard vial, you do not need to compensate for a possible inclination as long as the vial detection is within the Z-Tolerance range.

## Wash Station: Wash1/Wash2 Reference Point

[Figure 51](#) shows the Wash Station Wash1/Wash2 reference point.

**Figure 51.** Wash station Wash1/Wash2 reference point



For a fast wash station, the reference positions are the two holes in the wash vial caps (see [Figure 51](#)). Be sure to center the lower needle guide in these holes with the bottom of the lower needle guide lightly touching the surface of the wash station assembly.


## 2 Installing the Accela Open Autosampler

### Accela Open Autosampler Object Positions

For the DLW Wash Station option, the reference positions for Wash1 and Wash2 are the two holes on top of the wash station assembly. See [Figure 52](#).

Center the lower needle guide in these holes with the bottom of the lower needle guide lightly touching the surface of the wash station assembly.

**Figure 52.** DLW Wash Station Wash1/Wash2 reference point



#### ❖ To make the reference position of Wash Station Wash1/Wash2

1. Press HOME on the handheld controller and select the sequence:

**Menu > Setup > Objects > Wash Stations > Wash1**

2. Enter **Wash1** and adjust the  $x$ ,  $y$ ,  $z$  positions until the lower needle guide of the injection unit centers on top of the wash station assembly. Fine-tune the  $z$  position until the bottom of the lower needle guide is flush with the top surface.
3. Repeat steps 1 and 2 for Wash2 by using the path:


**Menu > Setup > Objects > Wash Stations > Wash2**

### Waste Reference Point, Injectors (Waste)

The waste position represents an "Injector" within the Accela Open Autosampler software. It is defined in the object class, Injectors.

The reference position for the waste port—a hole (slightly larger than the needle guide)—has been placed in the middle position of Wash1 and Wash2 (see [Figure 53](#)). Center the lower needle guide in this hole with the bottom of the lower needle guide lightly touching the surface of the wash station assembly.

**Figure 53.** Waste reference position



❖ **To make the Waste reference position**

1. On the handheld controller, select the sequence:


**Menu > Setup > Objects > Injectors > Waste 1**

2. Select **Waste** and adjust the  $x$ ,  $y$ ,  $z$  positions until the lower needle guide of the injection unit centers on top of the wash station assembly. Fine-tune the  $z$  position until the bottom of the lower needle guide is flush with the top surface.
3. Press F1 to verify the position and F4 for Home.

### Injection Valve Reference Points

For an LC Valve the reference position is the valve needle guide fitting mounted on the top valve port (see [Figure 54](#)).

**Figure 54.** LC Valve reference point




The lower needle guide of the injection unit is centered in the valve needle guide fitting. Adjust the  $z$  position so that the bottom of the lower needle guide just touches the surface of the valve needle guide fitting. Then reduce the value by 2.0 mm. See [Figure 55](#).

## 2 Installing the Accela Open Autosampler

### Accela Open Autosampler Object Positions

**Figure 55.** Positioning z-axis needle guide on valve needle guide



### Defining the Valve Penetration Value

Before performing the following steps, make sure object positions X, Y, and Z for LC Vlv1 are properly defined and the complete DLW syringe assembly is inserted into the injection unit.


#### ❖ To define the valve needle penetration depth

1. On the handheld controller select the sequence:

**Menu > Setup > Objects>Injectors > LC Vlv1**

2. Press F1, Check Pos. The injection unit moves to the previously defined LC Vlv1 position.
3. Select the item **Needle Penetr** with the cursor bars by pressing ENTER.
4. Slowly rotate the outer knob to adjust the needle penetration depth. The syringe moves down stepwise into the injection port.
5. When the syringe needle tip enters the valve needle guide, slow down the Z-movement again. Always observe the syringe needle during this adjustment step.
6. Move down the syringe stepwise until the bottom of the cross bar of the DLW Needle holder assembly is flush with the lower line of the DLW needle adapter block. See [Figure 56](#).
7. Press ENTER to save the needle penetration depth value.
8. Verify the defined needle penetration depth value by repeating steps 3 through 6.


**Figure 56.** Teaching the needle penetration



9. If you hear a click and the ball-spring loaded needle holder is completely compressed, stop the Z-down movement immediately.
10. Rotate the outer knob stepwise in the opposite direction until the gap of the spring loaded needle holder is approximately 1 mm, or the bottom of the holder assembly is flush with the lower surface of the needle adapter block, as in [Figure 56](#). Repeat and verify the needle penetration test.

[Figure 57](#) shows an example of the correct and incorrect positioning of the syringe needle tip in the valve inlet port.

**Figure 57.** Valve needle penetration depth



The ball-spring loaded needle holder presses the square cut needle tip firmly against the bottom of the valve body. This ensures a constant seal during the injection process.

# Injection Valve

This section contains information about the injection valve.

## Valve Drives and Valves – General Remarks

An Accela Open Autosampler can be equipped with one LC injection valve connected and controlled through the auxiliary interface (AUX). If you need to configure more than one valve, or if an auxiliary interface is occupied by another module, such as a dilutor, then multiposition or serial valve drives are required. The serial valve drives are connected at MODBUS interface.

Accela Open Autosampler is equipped with the control board APR Control-xt, which provides two auxiliary interfaces, AUX1 and AUX2. You have the choice to connect one more valve drive.

## Injection Valve Flow Path

The six-port valves are connected to the detection system according to the flow paths as shown in [Figure 58](#).

### Standard LC Injection Valve, Cheminert 6-Port

The standard LC injection valve is a six-port, two-way switching valve with a flat rotary plate and has a special needle guide (see [Figure 58](#)).

**Figure 58.** Flow path of standard LC injection valve (Cheminert type)




Table 6 lists the specifications for a standard LC injection valve.

**Table 6.** Standard LC injection valve specifications

Component	Specification
Valco/VICI Cheminert	Flat plate rotary valve
Stator material	Stainless steel 316
Rotor material	Valcon H (inert mix-polymer)
Port size	1/16 inch
Fittings	Valco 1/16 inch ferrules and nuts
Actuator	PAL valve drive (micro-electric actuator)
Loop size	20 $\mu$ L (shipped), other loop sizes available
Bore size	0.25 mm
Port to port volume	320 nL for vertical port, 75 nL for standard ports, 75 nL for engraving


**Note** Sample loops of the different valve types are not interchangeable.

## Valve Needle Guide and Needle Seal

All valves are equipped with a special valve needle guide fitting. This fitting has a wide diameter to connect with the syringe needle guide on the injection unit. The valve needle guide also has a countersunk hole to facilitate insertion of the syringe needle into the injection port.

Figure 59 shows an example of the setup with the standard valve, Cheminert type.

**Figure 59.** Valve needle guide and valve needle seal



The valve needle guide holds the needle seal. The needle seal, which is a short length of FEP tubing, forms the seal around the syringe needle. A stainless steel ferrule is tightened around the FEP sleeve to ensure a leak-proof fit.

### ❖ To ensure reproducible sample injection and minimize carryover

1. Properly install the valve needle guide and the valve needle seal.
2. Change the valve needle seal at regular intervals.
3. Set the needle penetration depth accurately (see [“Injection Valve Reference Points”](#) on [page 57](#)).

To specify a maximum number of penetrations into the needle seal is not practical. You might want to check the tightness of the seal daily or weekly when first using the Accela Open Autosampler to gain experience with the specific use in the laboratory related to the application.

❖ **To test the tightness of the seal**

1. Take the needle seal out of the valve port.
2. Manually insert a syringe needle gauge 22 (or gauge 22S) from the top, down into the tube, and past the sealing point of the ferrule.
3. If you observe a restriction, continue to use the needle seal. If not, replace the needle seal.

**Interval to Replace Needle Seal**

The interval to replace the needle seal depends on the number of penetrations. Consider these two factors for the decision to replace the needle seal:

- Leak, seal not reliable

Remove the needle seal from the inlet port and insert a syringe manually with the corresponding needle gauge (standard Gauge 22 OD 18/25 mm). Move the needle below the seal point of the ferrule. If you do not observe resistance at this point, replace the needle seal.

- Carryover

If you suspect any contamination of the needle seal with a compound, replace the needle seal.

Contamination can occur if the sample solution is accidentally dispensed too fast into the valve system. The restriction of valve and loop might cause backpressure, forcing the sample solution into the inlet port of the valve.

**Note** PAL Firmware (level 2.4.x or later) provides a counter for the number of injections performed using the PAL System. This counter monitors the valve switches and not the number of penetrations into the injection port; for example, cleaning the valve requires an extra penetration. You might want to monitor this counter in conjunction with the test for the tightness of the needle seal as described above.

After running routinely for a few weeks, the warning limit for the inject counter gradually becomes evident and will be a valuable tool in routine work.

Path:

**Menu > Info > Maintenance > Inject Limit** (Inject counts reflect the actual number of injections.)

Table 7 lists the part numbers for replacement needle seals.

## 2 Installing the Accela Open Autosampler

### Injection Valve

**Table 7.** Part numbers for replacement needle seals

PN	Description
CH-9524511	Standard needle seal, pkg of 10 FEP Tubing transparent, ferrule sst, needle gauge 22 (OD 18/25 mm), for Valco/VICI sst valves, Cheminert and W-type
00950-01-00331	Needle seal, pkg of 10 FEP Tubing transparent, ferrule PEEK., needle gauge 22 (OD 18/25 mm), for Valco/VICI PEAK valves, Cheminert-type

# Operating the Accela Open Autosampler

This chapter describes how to operate the Accela Open Autosampler including how to use the control terminal, methods, job queue, utility functions, and logfile; and how to set up functions.

## Contents


- [Control Terminal](#)
- [Methods](#)
- [Job and Job Queue](#)
- [Utility Functions](#)
- [Logfile](#)
- [Info Functions](#)
- [Setup Functions](#)
- [Communicating with the Computer](#)

## Control Terminal

The following procedures present the key steps required to set up and process multiple groups of samples with the Accela Open Autosampler. These procedures provide an overview for new users and a reminder for infrequent users. Make sure that the Accela Open Autosampler and all accessories are installed with objects defined correctly. In addition, ensure installation of a syringe of the specific type called for by a particular method.

[Figure 60](#) illustrates the Open Autosampler control terminal and the conventions used to enter, edit, and view information.


**Figure 60.** Accela Open Autosampler control terminal and conventions



## Menu Screens

The control terminal displays different menu screens, depending on the Accela Open Autosampler operating status and the particular function that you are accessing. All menu screens have the same basic format. The menu title displays at the top of the screen. A list of items displays below the title. The date and time, or status, show in the highlighted area above the function key labels on the bottom of the screen.

**Figure 61.** Accessing a method screen



## Function Keys

Functions (keys F1, F2, F3, and F4) correspond to the options for a particular menu, directly above each function key label.

Pressing the function key labeled Home always returns to the Job Queue menu.

## ESC and STOP Keys

Press ESC to return to the previous menu. Press STOP to cancel the current cycle, job, or job queue.

## Scroll Knob and Enter Button

Rotate the outer knob to scroll through items in a menu list. To select a highlighted item, press the central knob (the Enter button). Then use the outer knob to scroll through available options for that item or to change a numeric value. Press the inner knob again to enter the displayed option. You can also use the inner knob for other operations that require an Enter operation to continue or complete an operation.


## Methods

This section contains information about how to create, edit, view, and delete methods.

### Creating Methods


You can define methods and assign them names up to eight characters in length. You can create, copy, edit, and view methods from the Methods menu. Although you can view methods from the Job Queue menus, you cannot edit them there.

You create methods by either copying an existing method or creating a new method.



#### ❖ To copy an existing method

1. At the prompt, enter a name for the new method.
2. Use the scroll knob and the left-right arrow function keys (F2 and F3) to select among alphanumeric characters and spaces.
3. Press the ENTER key to accept the name.



#### ❖ To create a new method


1. Enter a new method name. After you create a copy of the method, the method parameters appear and can now be edited. You can change the cycle and syringe entries.
2. If the method is new (that is, added), select and enter a cycle that is appropriate for the application.
3. Select the specific syringe to be used by the method.

**Note** Once you create and save a method, you cannot change the cycle and syringe. To use a different cycle or syringe, you must create a new method.

4. Assign parameter values according to the application requirements.

## Editing and Viewing Methods

You can view and change method parameters (cycle and syringe not included) from the Method menu as follows.




#### ❖ To edit or view a method

1. Scroll to and select the parameter you want to change. Assign the new value and press the ENTER key.
2. Exit the parameter list by pressing either Home function key (F4) to return to the top-level Job Queue menu or the ESC key to return to the previous menu.
3. To view method contents from the job queue displays, select the desired job, press ENTER, and then press the View Method function key.

## Deleting Methods

You can delete methods from the Methods menu, but you cannot delete methods in use by an active job. Complete the following menu selections to delete a method.




## Job and Job Queue

A job bundles the specified tray with the designated vials (samples) and with the method to run those samples. Another term often used for job in the chromatographic field is sequence.

If you prepare more than one job, use the term, job queue.

Before activating a job, you must verify that the tray type matches the specified tray and vial size (type) (see [Figure 62](#)). Perform this step in Utilities.

**Figure 62.** Verify tray with corresponding tray type




Select the corresponding tray type. By activating the function key F3 you can move the injection unit to the first position and to another two corner positions to verify the correct selection of the tray type and teaching position.

## Building and Starting a Job Queue

### ❖ To build and start a job queue

1. Power on the Accela Open Autosampler. The JOB QUEUE display opens.

**Figure 63.** JOB QUEUE



2. Load a sample tray onto an available location in a tray holder or stack. Note the corresponding tray name.
3. Add a new job for the tray. Press the Add Job key to bring up the default job.
4. For a tray, select the tray name (for example, **stk1-01**) that corresponds to the location of the tray you load.
5. Enter the first and last sample number for this job.
6. Select and enter the sample processing method for this job.
7. Press the Home function key (F4) to return to the JOB QUEUE display.
8. To add additional samples that you want to process, repeat steps 2 through 7.
9. If necessary, replace or clean the syringe (liquid versions only), or do both.

Press Menu to see the available options for changing (F1: Change Syringe) and cleaning (F2: Clean Syringe). To completely remove air bubbles, prime the syringe manually.

10. If processing only one job, select the job with the scroll knob. Press the Start key. In the Select Job(s) to Process dialog box, select one of the following options:
  - All (entire job queue starting from the top)
  - Selected (job selected with the cursor bar)
  - Resume (continue with the next job after the one that was cancelled)

## Cancelling a Job Queue

### ❖ To cancel a job queue

1. In the JOB QUEUE display, press STOP.
2. Select one of the available options:

Continue, Sample, Job, or Job Queue.

- To resume processing with the current sample, select **Continue**.
- If there is a problem with only the current sample, select **Sample**. Processing resumes with the next sample.
- To cancel processing all samples in the current job, select **Job**. Processing resumes with the next job. The cancelled job is marked with an X.)
- To cancel processing all jobs, select **Job Queue**. The JOB QUEUE display appears. The cancelled job is marked with an X.

## Restarting a Cancelled Job Queue

### ❖ To restart a cancelled job queue


1. In the JOB QUEUE display, press START.
2. Select **Resume**. The job after the last one marked as cancelled starts.

## Utility Functions

Utility functions, selectable from the Menu display, provide quick access to checking operations and parameters that you might need to change. These functions are available for the actual syringe, trays, injectors, and wash station. They provide access to key functions without having to set up and execute a method and job.

**Note** If the sample processing cycle uses an item, the method value overwrites the appropriate utility value.

**Figure 64.** Selecting Utilities functions



## Syringe

Table 8 lists the functions available for Syringe by pressing the appropriate function key.

**Table 8.** Utility function keys for Syringe

Function key	Description
F1 Chang Syr	The syringe is moved to a position where the syringe assembly can be completely lowered to ease removal of the syringe adapter. You can then remove the syringe from the adapter and replace it. A prompt is displayed to specify the new syringe. Install the syringe before pressing Enter.
F2 Clean Syr	Use to clean or prime the syringe prior to use. After pressing F2, select either Wash1 or Wash2.
F3 Set Pos	Use to define the Chang Syr position.
F4 Home	The injection unit moves to its Home position and the Job Queue menu displays.

Table 9 lists the items you can select to change the syringe configuration.

**Table 9.** Syringe items (Sheet 1 of 2)

Item	Description
Actual ID	Indicates the identification number (ID) of the currently inserted syringe. If the syringe detection system is set to manual, this message displays: Syringe: No syringe.
Fill Volume	Controls the filling of the syringe. Air bubbles might remain below the plunger after the first pull up. If the plunger moves up and down several times, these air bubbles work out. With this operation you can completely fill the syringe even when using very small sample volumes.

**Table 9.** Syringe items (Sheet 2 of 2)

Item	Description
Fill Strokes	Number of fill strokes. All fill strokes, except the last one, use the selected fill volume. If the selected sample volume is greater than the fill volume, the sample volume is used for all fill strokes. If you select zero, the plunger pulls up only once using the sample volume value.
Pullup Del	Allow the user to select a delay time between sample pullup and ejection while filling the syringe. When the plunger reaches the zero position during the fill strokes, the system waits half the Pullup Del time. This allows for an air bubble to float away from the needle tip. This feature is especially useful for removing any air bubble in the syringe and handling viscous fluids.
Fill Speed	Speed of plunger movement used in all syringe filling operations.
Eject Speed	Speed of plunger movement used in all syringe eject operations except sample injection.
Inject Speed	Speed of plunger movement for sample injection. Typically used for Fill Strokes.
Plunger Chnge Pos	Plunger position during the Change Syringe operation. The syringe plunger moves to a position where you can remove and replace the syringe. You may change the value for different types of syringes.

## Tray

Table 10 lists the functions available for tray by pressing the appropriate function key.

**Table 10.** Utility function keys for tray

Function key	Description
F2 Block NdlG	Activates needle guide blocking. The option after activation is Rel NdlG, which releases needle guide blocking. Use this function key to test the functionality of the solenoid that blocks the needle guide.
F3 Movto nnn	Serves as a quick check to determine if the <i>x</i> , <i>y</i> , <i>z</i> coordinates are defined correctly for the selected tray. To use this utility, the selected tray, including the sample vials, must be present. After pressing Movto 001 the injection unit moves to sample position No.1. You can repeat this procedure for the last sample position in the first row and the last sample position.
F4 Home	The injection unit moves to its Home position and the Job Queue menu displays.

Table 11 lists the items you can select to change the tray configuration.

**Table 11.** Tray items

Item	Description
Needle Penetr	Needle penetration depth into the sample vial. You can change the needle penetration depth for the selected tray by entering the desired value.
Tray Type	Shows the tray type. If the tray enables the use of different tray types, you can make the change at this position.
Tray Offset X	Use to correct the ideal $x$ position of Position 1 if necessary.
Tray Offset Y	Use to correct the ideal $y$ position of Position 1 if necessary.
Tray Offset Z	Use to correct the ideal $z$ position of Position 1 if necessary.
dxRow	Corrects any inclination of a tray (plate) in the $x$ axis of a row.
dyRow	Corrects any inclination of a tray (plate) in the $y$ axis of a row.
dzRow	Corrects any inclination of a tray (plate) in the $z$ axis of a row.
dxCol	Corrects any inclination of a tray (plate) in the $x$ axis of a column.
dyCol	Corrects any inclination of a tray (plate) in the $y$ axis of a column.
dzCol	Corrects any inclination of a tray (plate) in the $z$ axis of a column.

## Injector

Table 12 lists the functions available for injector by pressing the appropriate function key.

**Table 12.** Utility function keys for injector

Function key	Description
F3 Movto Inj	The injection unit moves to the selected injector position. With this function, for example, the injectors GC-Inj1, Waste, Waste2, and Flush can be accessed. By selecting the Needle Penetr parameter on the same screen, you can check or change the injector needle penetration value.
F4 HOME	The injection unit moves to its HOME position and the Job Queue menu is displayed.

Table 13 lists the item you can select to change the injector configuration.

**Table 13.** Utility item

Item	Description
Needle Penetr	By selecting the Needle Penetr parameter, you can check or change the injector needle penetration value. To ensure reproducible sample injections and minimize carryover, it is critical that the needle penetration depth be accurately set.

## Wash Station

Table 14 lists the functions available for wash station by pressing the appropriate function key.

**Table 14.** Utility function keys for wash station

Function key	Description
F3 Movto Wash	The injection unit moves to the selected wash station port. By selecting the Needle Penetr parameter on the same screen, you can check or change the wash station needle penetration value.
F4 HOME	The injection unit moves to its HOME position and the Job Queue menu is displayed.

Table 15 lists the items you can select to change the wash station configuration.

**Table 15.** Wash station items

Item	Description
Needle Penetr	By selecting the Needle Penetr parameter, you can check or change the wash station needle penetration value.
Rinse Time	If rinse time is activated (value > 0), the solenoid of a fast or active wash station opens for the specified time after the syringe needle has been removed from the wash port (after completion of the syringe wash cycle).  The solvent flows into the wash port without the restriction of the needle; be aware of higher solvent consumption.

## Vial

Table 16 lists the functions available for a vial by pressing the appropriate function key.

**Table 16.** Utility function keys for a vial

Function key	Description
F3 Movto Vial	The injection unit moves to the selected vial type. By selecting the Needle Penetr parameter, you can check or change the wash station needle penetration value.
F4 HOME	The injection unit moves to its HOME position and the Job Queue menu is displayed.

Available Vial types:

- Standard: Vial in standard wash station for gas chromatography (front position).
- Fiber Exp: Position to block needle guide. Mainly used for SPME application. Refer to the SPME User Manual.

Table 17 lists the item you can select to change the vial configuration.

**Table 17.** Vial item

Item	Description
Needle Penetr	By selecting the Needle Penetr parameter, you can check or change the wash station needle penetration value.

## Dilutors

Table 18 lists the functions available for dilutors by pressing the appropriate function key.

**Table 18.** Utility function keys for dilutors

Function key	Description
F1 Prime	Primes the dilutor syringe with solvent.
F2 Chang DSyr	Moves the plunger of the dilutor syringe to standby position to allow easy access to change the syringe.
F4 HOME	The injection unit moves to its HOME position and the Job Queue menu is displayed.

Table 19 lists the items you can select to change the dilutors configuration.

**Table 19.** Dilutors items

Item	Description
Syringe	Indicates the dilutor side-port syringe inserted in the z axis. Use this function to select another syringe size.
Syr Dilut Pos	Moves the plunger of the side port syringe up by the specified distance. This allows adjustment of the plunger tip of the side port syringe exactly above the lower side port (solvent inlet). You must fine-tune after changing a side port syringe to allow unrestricted solvent flow.
Dilutor Syr	Indicates dilutor syringe is installed. If you change the syringe size, this item must be adapted accordingly. This function coordinates the syringe-specific dimensions.
Prime Volume	Specifies the volume to prime the dilutor syringe can be specified. The allowed range can be fourfold higher than the actual syringe volume. This allows filling and emptying a dilutor syringe more often than just once.
Pullup Delay	Permits selecting a delay time between solvent filling and ejection while filling (or priming) the syringe.
Fill Speed	Speed of plunger movement of dilutor syringe used in all syringe filling operations.
Eject Speed	Speed of dilutor syringe plunger movement used in all dilutor syringe eject operations.
Eject Delay	Permits selecting a delay time between solvent ejection and filling while filling (or priming) the syringe.

## Tools

**Note** The Object class Tools is available with PAL Firmware level 3.0.x , 4.1.x, or later.

Table 20 lists the functions available for tools by pressing the appropriate function key.

**Table 20.** Utility function keys for tools

Function key	Description
F1 Chk Offs	Use Check Offset to verify the offset from the syringe needle tip to the tool tip. This function is mainly used for the MALDI tool; it is not active for the MHE tool.
F4 HOME	The injection unit moves to its HOME position and the Job Queue menu is displayed.

Table 21 lists the items you can select to change the tools configuration.

**Table 21.** Tools items

Item	Description
Teach Point	The reference point at which to teach the Object (Tool; MHETool) is selectable. The MHETool needs no extra position. The Parking Station is the fix point. Select None.
ToolOffset X	Corrects the ideal <i>x</i> position of the MHETool if necessary.
ToolOffset Y	Corrects the ideal <i>y</i> position of the MHETool if necessary.
ToolOffset Z	Corrects the ideal <i>z</i> position of the MHETool if necessary. You must have a ToolOffsetZ of -48.0 mm to position the MHETool on the sample vial.

## Logfile


You cannot directly read the PAL logfile on the terminal display. However, the F3 function key does allow a printout. You must have a serial printer connected to port SER2 for the PAL System and to port SER1 for PAL-xt system. If a serial printer is not available, use a serial or parallel converter.

## Info Functions

Info functions, selectable from the Menu screen, provide quick access to viewable information. These Info functions are available for the hardware, software, maintenance, free objects, and free items.

All items with the exception of maintenance are read-only.

**Figure 65.** Selecting Info functions



## Hardware

Table 22 lists Info functions items for hardware.

**Table 22.** Info functions items for hardware

Item	Description
CPU SNo	The serial number (S/N) of the PCB APR CPU is displayed.
CPU ID	Version number of the PCB APR CPU.
MOTIO ID	Version number of the PCB APR CPU.

## Software

Table 23 lists Info functions items for software.

**Table 23.** Info functions items for software

Item	Description
PAL Firmware	Firmware level of PAL System
Head Firmware	Version level of the firmware PAL Injection Unit
Terminal FW	Version level of the firmware PAL Terminal
Altera Firmware	Version level of the Altera component firmware

## Maintenance

Table 24 lists Info functions items for maintenance.

**Table 24.** Info functions items for maintenance (Sheet 1 of 2)

Item	Description
PlgStrokeCnt	<p>A counter for syringe plunger movements. The actual number of strokes is displayed. If the counter reaches the set limit (PlgStrikeLim), a warning is displayed at the next start of a job (run). The system continues but signals the user to verify syringe conditions. You can restart the counter by setting it back to zero.</p> <p>A Syringe has only one counter. If you change syringe types, the system continues to count as if it were the same type.</p>
PlgStrokeLim	Sets an upper limit for the syringe plunger strokes.

**Table 24.** Info functions items for maintenance (Sheet 2 of 2)

Item	Description
Inject Count	Monitors the number of injections. The number of injection valve switches is a helpful tool for deciding on replacement parts for the injector system. The actual number of injections (valve switches) is displayed. If the counter reaches the set limit (Inject Limit), a warning appears at the next start of a job (run) (Inject Limit). The same counter is used for injector penetrations with a GC technique.
Inject Limit	Sets an upper limit for the number of injections.

**Note** Counters for the plunger movement and injector penetrations are available with PAL Firmware level 2.5.x or later.

## Free Objects/Free Items

In addition to the core software, the PAL Firmware contains data for firmware objects. There are different classes of Objects, such as Syringes, Trays, Tray Holders, and so on. Each class of objects contains items. The items contain the actual data, such as  $x$ ,  $y$ ,  $z$  positions.

The data are stored in a flash memory backed up by a battery.


To optimize RAM and Flash memory use, the software has a reserved section of memory for each of the Objects and Object Items.

The percentage shown in the Info section indicates how much of the reserved software space is still available.

## Setup Functions

The Setup functions, selectable from the Menu screen, allow access to various functions for the PAL System. The Sound, Time, and Objects are basic functions that you use at installation or if changes have been made over time.

**Figure 66.** Selecting Setup functions



## Sound

Table 25 lists Setup functions for Sounds.

**Table 25.** Setup functions for sound

Item	Description
Message Box	A specific dual beep tone signals that a message box for user intervention appears on the screen. You can turn this beep signal on or off.
Warn Move	Sounds a beep at the start of the PAL movement. Keep this function turned on for safety reasons.
End Cycle	Sounds a beep at the end of a cycle. Select as desired.
End Job	Sounds a beep at the end of a job. Select as desired.

## Time

Table 26 lists Setup functions for Time.

**Table 26.** Setup functions for time

Item	Description
Year	Sets the year for the PAL internal clock.
Month	Sets the month for the PAL internal clock.
Day of Month	Sets the day for the PAL internal clock.
Hours	Sets the hours for the PAL internal clock.
Minutes	Sets the minutes for the PAL internal clock.
Seconds	Sets the seconds for the PAL internal clock.

### 3 Operating the Accela Open Autosampler

#### Communicating with the Computer

After setting or resetting the date and time, use the F1 function key (F1 Set Time) to save your changes.

## Objects

You can directly access common functions for the various PAL Firmware Object classes. For a detailed listing, see “[PAL Firmware Overview](#)” on [page 191](#).

## Communicating with the Computer

This section describes how the Accela Open Autosampler communicates with a computer.


The PAL System provides a serial communication protocol with a PC. The Accela Open Autosampler system requires a dedicated APR Control-xt board and PAL Firmware level 4.1.x or later.

The COM port settings are normally defined in:

Windows\Control Panel\Device Manager\Ports

[Figure 67](#) shows the standard settings for the serial communication. Be aware that the application (for example, PAL Loader software) does actively set the communication parameters, and the baud rate is set for optimized use.

Figure 67. COM Port Settings



A quick way to check whether serial communication with the PAL System can be established is to use the PAL Loader software. For further information, see “PAL Loader” on page 211.



## Installing Cycle Composer Macros or ICC Cycles Used for the DLW Option

You can only operate the Open Autosampler DLW option in combination with PAL control software, such as Thermo PAL driver for Xcalibur or Cycle Editor, for ICC interpretation in another data handling system software.

For software control, three macros or three cycles are provided.

The first of three macros covers the initial and daily priming of the solvent lines and covers a complete injection cycle, a second macro is used for Standard speed with optimized washing possibilities, and the last for a Fast cycle for optimized throughput and less focus on carryover. See [Table 27](#).

For detailed descriptions of all macros (or cycles), see [Table 27](#), [Table 28](#), and [Table 29](#).

**Table 27.** The DLW macro definitions

Macro name	Macro description
Priming Accela Open	For initial and daily routine priming of the solvent lines and DLW manifold. The Clean Time for both wash solvents is a variable for the user to define the intensity of washing.
Standard Injection Accela Open	Standard injection cycle using all possibilities of the DLW option. The injection valve inlet port and the needle are washed with both wash solvents (inside and out). You can add an extra Stator Wash for intensive washing of the injection valve (valve toggle).
Fast Injection Accela Open	Tuned for speed and high-throughput application. It differs from the Standard DLW macro in that some steps are left out to shorten the cycle time.

# Installing the Thermo PAL Driver Macros or ICC Cycles

The Accela Open Autosampler is shipped with a CD-ROM containing various cycles for the DLW option. Macros for the Xcalibur data system are installed by the LC Devices 2.5 installer.

Copy these macros to your Thermo PAL driver method folder or corresponding folder for application within the integrated system.

### ❖ To copy cycles to your Cycle Composer

1. Navigate in Windows™ Explorer to the Thermo PAL driver folder. The usual folder location is as follows:

*drive:\Thermo\Instruments\LC Devices\ThermoPAL\PAL*

2. If you wish to add the DLW option macros to an existing method folder, copy the macros (\*.pma) and the methods (\*.pme) files from the DLW Option folder on the CD-ROM to the method folder.

If the PAL System is integrated in a data system software that controls the PAL using the Cycle Editor for PAL ICC interpretation (for example, Analyst, ChemStation, Empower, EZChrom, MassLynx, Xcalibur), an ICC Cycle is used and not the Cycle Composer Macro. The cycle extension is \*.cyx.

**Note** You can convert a Cycle Composer macro to a cycle (extension \*.cyx) by using the Cycle Editor software. Conversion is available starting with Cycle Editor version 1.4.0.4.

**Note** The provided macros are written for standard injection valve drives, which are controlled and activated through the AUX interface.

## General Considerations

You must establish the duration of the wash steps for each configuration and application. Consider factors such as the viscosity and surface tension of the individual wash solvent composition and the backpressure of the system.

Be aware that a higher backpressure builds up if the valve bore size (standard valve bore 0.25 mm) or the installed loop internal diameter is lower. Standard loop internal diameter (ID) for Thermo-defined loops with a volume of 5, 10, and 20 µL is 0.25 mm. The loop with 2 µL content volume has an ID of 0.125 mm.

Keep the tubing internal diameters of the tubing in line with the valve dimensions, loop ID, and flow rate.

## Priming the Solvent Lines, Wash1 and Wash2

This macro is used at installation to prime the entire system. Set the wash time to approximately 120 seconds for each solvent.

After installation, for best results prime the system before activating the first run. For daily preparation of the system, the wash time can be much shorter: approximately 20 seconds. The goal is an entire liquid system free of any air bubbles.

### Macro Name: Priming Accela Open AS\_Rev01

**Table 28.** Macro Priming Accela Open AS (Sheet 1 of 2)

Macro description	Macro variable
The injection unit moves to the DLW Wash Station, position Wash1.	Clean Time solvent 1 Eject Speed DLW Syringe
The injection unit moves to the DLW Wash Station, position Wash2.	Clean Time solvent 1 Eject Speed DLW Syringe
The DLW system is rinsed with Wash Solvent 1 in position Waste.	
The injection valve is cleaned first with the content of DLW syringe (Wash Solvent 1), followed by Wash Solvent 2 and finally, the last wash to prepare the system for injection cycle, rinsed with Wash Solvent 1 again.  Remark: The Atom Rinse Inj is new, available starting with FW 4.1.x. The DLW Actuator/Solenoid is activated; the Wash Solvent (pump), the Needle Gap, and the Rinse Time are selectable.	Needle Gap is a parameter from Rinse Inj Atom. The variable in this macro is Needle Gap Valve Clean.  The function of this parameter is to raise the needle in the injection port very little to allow rinsing around the needle tip.  The pressure of the spring-loaded balls in the DLW Syringe Holder assembly is released by moving approximately 3 mm up (default). This leaves a gap, between the needle tip and the valve bottom, of approximately. 1 mm to enable a flush at this contact point.
A Repeat-End loop enables adding an extra rinsing step, valve toggle.	Stator Wash: Counter 0 = disable valve toggle steps Counter 1 = enable valve toggle steps
If the counter is set to 1, follow the described steps below. If the counter is set to 0, the macro finishes at this point.	
The injection moves to the injection valve. The valve is switched to the Active position.	

**Table 28.** Macro Priming Accela Open AS (Sheet 2 of 2)

Macro description	Macro variable
The valve is rinsed with Wash Solvent 2, followed by Wash Solvent 1	Stator Wash Time Solvent 2 Stator Wash Time Solvent 1  Remark: The loop is filled with the last rinse with Wash Solvent 1. Verify the composition of Wash Solvent1. The solvent should have a lower elution power than the solvent gradient starting conditions or sample solvent composition. This is important for partial loop filling.
The injection valve is switched back to the Standby position.	
End of macro DLW Priming	

## Standard DLW Injection Cycle

### Macro Name: Standard Injection Accela Open\_Rev03

**Table 29.** Macro Standard Injection Accela Open (Sheet 1 of 3)

Macro description	Macro variable
The PAL System waits first for the Sync Signal Ready before the injection cycle is started.	Remark: Sync Signal setting Start
The injection valve is brought in a defined Standby position.	Inject to Standby
The Rear air segment is pulled into the Holding Loop.	Airgap Volume Filling Speed
The sum of Rear-, Sample List-, and Front-Volume is aspirated into the Holding Loop.	Front Volume Rear Volume (SL.volume)
The Front air segment is aspirated.	Airgap Volume Filling Speed Pullup Delay
The injection unit moves to the DLW Wash station, Wash1 position.	
The needle is inserted (dipped) for 1 second to wash the outer needle surface. No plunger movement at this step.	

**Table 29.** Macro Standard Injection Accela Open (Sheet 2 of 3)

Macro description	Macro variable
The injection unit moves to the specified injection valve. The Front- and Airgap-Volume is ejected.	Inject to Front Volume Airgap Volume Injection Speed
The PAL System waits for the data system.	Wait for DS
The injection valve is switched to Active position. The time Pre Inject Delay is awaited.	Inject to Pre Inject Delay
The loop is filled with the sample volume as specified in the Sample List.	(SL.volume) Injection Speed
The injection valve is switched to Standby position; the loop content is injected. Timer 1 Delay Stator Wash is started and a Start signal to the HPLC system is sent.	Post Inject Delay Timer 1
The plunger of the DLW Syringe is pushed down to dispense the Rear Sample and Air Segment to Waste. The Holding Loop is still filled with Wash Solvent 1.	(Syr. Eject Speed)
The DLW Actuator/Solenoid is activated to deliver Wash Solvent 2 into the Holding Loop to clean the injection valve from Port 1 to Port 2.  For this step the needle tip is lifted, releasing the sealing pressure to enable rinsing around the tip sealing point.	Wash2 Inject to Needle Gap Valve Clean Valve Clean Time Solvent 2  Remark: For a detailed explanation of the Needle Gap Valve Clean, see DLW Priming.
The injection unit is moved to the DLW Wash Station, Wash2 position.	Wash2 (Syr.Eject Speed)
The needle is rinsed inside and out with Wash Solvent 2.	Post Clean Time Solvent2
The injection unit is moved back to the injection valve. The Inlet Port and engraving to waste Port are flushed with Wash Solvent 1 to prepare the valve for the next injection.	Wash1 Inject to Needle Gap Valve Clean Valve Clean Time Solvent 1

#### 4 Installing Cycle Composer Macros or ICC Cycles Used for the DLW Option

##### Standard DLW Injection Cycle

**Table 29.** Macro Standard Injection Accela Open (Sheet 3 of 3)

Macro description	Macro variable
The injection unit is moved back to the DLW Wash Station, Wash1 position to flush the syringe needle inside and out with Wash Solvent 1.	Wash1 Post Clean Time Solvent 1
This is a preparation step for next injection, and especially important for biofluid samples.	
Cycle end for LC-Inj DLW Standard macro.	
An optional cleaning step is attached to the DLW Standard injection cycle: Stator Wash or valve toggle.	Stator Wash Stator Wash count: 1 = Cleaning step active Stator Wash count: 0 = Cleaning step disabled
A Repeat-End loop can be activated with the Count.	
If Stator Wash is activated, the following steps will be executed.	
The injection unit is moved to the injection valve. From the last step above, the Holding Loop is filled with Wash Solvent 1.	Inject to Delay Stator Wash (Active)
Timer 1 is awaited to switch the valve (Toggle) into Active position (fill loop).	
The DLW Actuator/Solenoid is activated to deliver Wash Solvent 2 to the Holding Loop and into the valve system.	Inject to Wash2 Stator Wash Time Solvent 2
The first solvent flush arriving at the valve is Wash Solvent 1 parked in the Holding Loop at the beginning, followed by Wash Solvent 2.	
Wash Solvent is changed to Wash Solvent 1.	Inject to Wash1 Stator Wash Time Solvent 1
The injection valve is switched back to the Standby position.	Inject to (Standby)

## Fast DLW Injection Cycle

The Fast injection cycle differs from the Standard cycle as follows:

- The needle is not dipped in the Wash station Wash1 after sample pickup and before it moves to the injection valve.
- The wash steps after injection are reduced to Valve Clean with Wash Solvent 1 and Wash Solvent 2. The DLW needle is flushed in the DLW Wash Station with Wash Solvent 1 only.
- Stator Wash (valve toggle) is not available.

### Macro Name: Fast Injection Accela Open\_Rev03

**Table 30.** Macro Fast Injection Accela Open (Sheet 1 of 2)

Macro description	Macro variable
The PAL System waits first for the Sync Signal Ready before the injection cycle is started.	Remark: Sync Signal setting Start
The injection valve is brought to a defined position: Standby.	Inject to Standby
The Rear air segment is pulled into the Holding Loop.	Airgap Volume Filling Speed
The sum of Rear-, Sample List-, and Front-Volume is aspirated into the Holding Loop.	Front Volume Rear Volume (SL.volume) Airgap Volume
The Front air segment is aspirated.	Filling Speed Pullup Delay
The injection unit moves to the specified injection valve. The Front- and Airgap-Volume is ejected to Waste.	Inject to Front Volume Airgap Volume Injection Speed
The PAL System waits for the data system	Wait for DS
The injection valve is switched to Active position. The Pre Inject Delay time is awaited.	Inject to  Pre Injection Delay
The loop is filled with the sample volume as specified in the sample list.	(SL.volume)
The injection valve is switched to Standby position, the loop content is injected.	Injection Speed Post Inject Delay

**Table 30.** Macro Fast Injection Accela Open (Sheet 2 of 2)

Macro description	Macro variable
The plunger of the DLW Syringe is pushed down to dispense the Rear Sample and Air Segment to Waste. The Holding Loop is still filled with Wash Solvent 1.	Injection Speed
The DLW Actuator/Solenoid is activated to deliver Wash Solvent 2 into the Holding Loop to clean the injection valve from Port 1 to Port 2.	Inject to Wash2 Needle Gap Valve Clean Valve Clean Time Solvent 2
For this step the needle tip is lifted, releasing the sealing pressure to enable rinsing around the tip sealing point.	Remark: For complete details on the Needle Gap Valve Clean, see <a href="#">“Priming the Solvent Lines”</a> on page 93.
Wash Solvent 1 follows to prepare the valve for the next injection.	Wash1 Inject to Needle Gap Valve Clean Valve Clean Time Solvent 1
The injection unit is moved back to the DLW Wash station, Wash1 position to flush the syringe needle inside and out with Wash Solvent 1.	Wash1 Post Clean Time Solvent 1
This is a preparation step for the next injection, and is especially important for biofluid samples.	
Cycle end for LC-Inj DLW Fast macro.	

# Operating Dynamic Load and Wash (DLW)

This chapter describes how to operate the Dynamic Load and Wash (DLW) option.

## Contents

- [Priming the Solvent Lines](#)
- [Location of Solvent and Waste Bottles](#)
- [Functionality of the DLW Option](#)
- [DLW Cycle Step-By-Step](#)

## Priming the Solvent Lines

**Tip** For trouble-free DLW operation, make sure the two solvent lines are free of air bubbles at all times. If the solvent lines are being connected for the first time or during a solvent change, you must prime the solvent lines properly until air bubbles are no longer visible. For best results, use solvent degassing.

In order to make the initial and daily priming efficient and controllable, the Open Autosampler comes with a Thermo PAL driver macro, or ICC cycle.

For information on macros, see [“Installing Cycle Composer Macros or ICC Cycles Used for the DLW Option”](#) on page 85.

### ❖ To prime the solvent lines

1. Load the macros and methods into the folder.
2. Start the corresponding macro for initial or daily priming.
3. Check the solvent lines and prime until air bubbles are no longer visible.
4. Press F4 for Home.

## Location of Solvent and Waste Bottles

The DLW option contains self-priming membrane pumps. The solvent bottles can be placed either in the fast wash station holder or on the lab bench.

## 5 Operating Dynamic Load and Wash (DLW)

### Functionality of the DLW Option

You must place the Waste bottle greater than 30 cm (12 in.) below the injection valve. Make sure that the waste liquid can flow into the waste bottle without restriction. Place the waste tubing above the level of the liquid. Ideally, the tube is fixed at the neck of the waste bottle.

**Tip** Use good laboratory practice to avoid contaminating the wash solvents and the wash bottles. Avoid biological growth in pure water by either replacing it regularly or adding a small percentage of organic solvents, such as methanol or acetonitrile. Certain buffer solutions can decompose at room temperature when exposed to light. Filtering the wash solvents before filling the bottle, especially if using salt buffers, is mandatory to avoid any clogging of the solvent paths.

## Functionality of the DLW Option

This section contains information about the functionality of the DLW option, including the DLW pumps and the DLW Actuator/Solenoid.

### DLW Pumps

From the control viewpoint, the DLW pumps respond in the same manner as the fast wash station. Power-out signals activate the pumps. Because the electric current setting for the DLW is different, the corresponding PAL Firmware Objects must be loaded for the DLW wash station type.

The wetted parts in the pump are made from the following materials:

- Membrane: Kalrez (FFPM)
- Body, valves: Ryton PPS

The pumps are self priming with a suction lift of up to a 3 m water column.

### DLW Actuator/Solenoid

The DLW Actuator/Solenoid has the function of separating and completely shutting off the lines in the direction of the syringe (sample loading) or the wash solvent lines.

After opening the DLW Actuator/Solenoid for the wash solvent lines, you can pump the desired wash solvent into the system by activating the corresponding DLW pump.

Figure 68 illustrates this functionality.

The wetted parts in the DLW Actuator Solenoid are made from the following materials:


- Solenoid body: PEEK
- Seal material: FFKM (Simriz)

**Note** PEEK exhibits excellent chemical resistance to most of the chemicals used. However, the following solvents are not recommended for use with PEEK: DMSO, THF, methylene chloride (dichloromethane), nitric acid, or sulfuric acid. For more details, refer to the compatibility tables provided by the manufacturer of PEEK material or components.


**Note** Current applied from the actuator control PCB to the actuator/solenoid activates a green LED.

This activation does not indicate that the solenoid opens or closes.

**Figure 68.** DLW manifold and actuator/solenoid



**Figure 69.** Inserting DLW flow diverter



## DLW Cycle Step-By-Step

This section provides illustrations to demonstrate a step-by-step DLW cycle.

### Cycle for Standard Injection

Figure 70 to Figure 83 illustrate a step-by-step cycle for the standard injection.

**Figure 70.** Standard: Cycle start





Figure 71. Standard: Step 1 – Aspirate rear air segment



**Figure 72.** Standard: Step 2 – Get sample, aspirate rear, inject, and front volume







Figure 73. Standard: Steps 3 - 4 – Aspirate front air segment




**Figure 74.** Standard: Steps 5 - 6 – Clean outside passive needle (dip) in wash position 1




**Figure 75.** Standard: Steps 7 - 8 – Dispense front air segment and front sample volume to waste



**Figure 76.** Standard: Steps 9 - 10 – Valve is switched to LOAD position, loop is filled with Inject Volume



**Figure 77.** Standard: Step 11– Valve is switched to INJECT position, start chromatographic process



**Figure 78.** Standard: Step 12 – Rear sample volume and air segment are dispensed to waste





Figure 79. Standard: Steps 13 - 14 – Clean valve with wash solvent 2



## 5 Operating Dynamic Load and Wash (DLW)

DLW Cycle Step-By-Step

**Figure 80.** Standard: Steps 15 - 16 – Active syringe needle wash with wash solvent 2





Figure 81. Standard: Steps 17 - 18 – Clean valve with wash solvent 1



**Figure 82.** Standard: Steps 19 - 20 – Wash active syringe needle with wash solvent 1





Figure 83. Standard: Cycle end



## Additional Valve Toggle Step to DLW Standard Cycle

This section contains information about additional steps that are necessary for a DLW Standard Cycle.

## Considerations for Additional Stator Wash Cleaning Step

The DLW Standard Cycle has the built-in option for the user to toggle the injection valve at the end of the chromatographic run before equilibration of the column to the start conditions.


If the method variable Stator Wash is set to 1, the extra cleaning process for the valve, using the Valve Toggle, is part of the standard cycle.

If the method variable is deactivated (setting, 0), the DLW Standard cycle ends as shown in Figure 83.

The macro (cycle) is written so that the optional valve toggle steps can be executed before re-equilibration of the column. You must synchronize the time to switch the valve with the chromatographic method using the method variable Delay Stator Wash. The two wash solvents are timed by the method variables Stator Wash Time Solvent 1 and Stator Wash Time Solvent 2. After these wash times have elapsed, the valve is switched back to the start position.

Figure 84 illustrates the recommended retention time for Stator Wash or Valve Toggle times.

**Figure 84.** Timing for Stator Wash step



From the chromatographic viewpoint, the optional cleaning step is important to understand. Assuming that the valve stator between ports 1 and 6 (for example, a standard Cheminert valve) is contaminated and cannot be cleaned during the injection process, the valve toggle brings the engraving back between the two ports. Flushing the valve with both wash solvents eliminates remaining sample material located between stator ports 1 and 6.

What points must you consider when you use the Stator Wash or Valve Toggle option?

Observe the rules if biofluid samples are injected. The first sample contact should always be with an aqueous solution to avoid protein precipitation. After washing with organic solvent (higher elution power), you must flush the system again with wash solvent 1.

The first toggle near the end of the chromatographic cycle provides the advantage that the sample loop is already flushed out first with the mobile phase with a solvent of high elution power (assuming gradient application).

The second valve toggle time follows immediately after finishing the second solvent flush. You cannot program a second switching time. The waiting time for the second valve toggle should be long enough so that the entire system is flushed out by both wash solvents.

Consider the entire delay volume to determine the second valve switch. The DLW internal volumes are as follows:

Manifold, 90  $\mu$ L  
Holding Loop, 108  $\mu$ L  
Syringe Needle Gauge 22, 6.7  $\mu$ L  
Installed Injection Loop

Total delay volume: 205  $\mu$ L + Loop content volume

Toggle the second valve (back to the starting condition) before the system equilibration time has started. The loop content is ideally a solvent of a low elution power when switched back.


If isocratic chromatography is applied, the remaining contaminants might be washed into the system and can build up higher background noise for the column, the detector, or both over a longer period of time.

### Additional Stator Wash Cleaning Step or Valve Toggle Step-by-Step


Figure 85 to Figure 90 illustrate additional cleaning steps for Stator Wash.

#### Stator Wash: End of Standard Injection Cycle


**Figure 85.** Start for additional cleaning step Valve Toggle




**Figure 86.** Stator Wash: Step 1 - 2 – Valve switched to Load Position (toggle), clean valve with wash solvent 1




**Figure 87.** Stator Wash: Step 3 – Clean valve with wash solvent 2




**Figure 88.** Stator Wash: Step 4 – Wash solvent 2 dispensed by wash solvent 1



**Figure 89.** Stator Wash: Step 5 – Clean second valve with wash solvent 1



**Figure 90.** Stator Wash: Step 6 – Valve switched back to Inject position (toggle)



## Cycle for Fast Injection

Figure 91 to Figure 102 illustrate a step-by-step cycle for the Fast Injection.

**Figure 91.** Fast: Cycle start





Figure 92. Fast: Step 1 – Aspirate rear air segment



**Figure 93.** Fast: Step 2 – Get sample, aspirate rear, inject, and front volume







Figure 94. Fast: Step 3 - 4 – Aspirate front air segment




**Figure 95.** Fast: Steps 5 - 6 – Dispense front air segment and front sample volume to waste




**Figure 96.** Fast: Steps 7 - 8 – Valve is switched to LOAD position, loop is filled with Inject Volume



**Figure 97.** Fast: Step 9 – Valve is switched to INJECT position, start chromatographic process



**Figure 98.** Fast: Step 10 – Rear sample volume and air segment are dispensed to waste



**Figure 99.** Fast: Steps 11 - 12 – Clean valve with wash solvent 2





Figure 100. Fast: Steps 13 - 14 – Clean valve with wash solvent 1



## 5 Operating Dynamic Load and Wash (DLW)

DLW Cycle Step-By-Step

**Figure 101.** Fast: Step 15 – Wash active syringe needle with wash solvent 1





Figure 102. Fast: Cycle end





# Operating the Temperature Controllable Stack Coolers

This chapter describes how to set the temperature, temperature control, and alarm. It also discusses temperature stability and condensation build-up.

## Contents

- [Temperature Setting, Control, and Alarm](#)
- [Temperature Stability](#)
- [Condensation Build-Up](#)

## Temperature Setting, Control, and Alarm

This section contains information about the temperature setting, temperature control, and temperature alarm.

### Temperature Setting

Turning the power on (I) at the power supply module puts the control unit into self-check mode. The set value for the temperature appears after a few seconds.

The stack/tray cooler temperature is preset by the factory to 10 °C.

#### ❖ To change the value

1. Press P briefly (less than two seconds) until SP1 appears.
2. Use the increment/decrement keys to select the desired value.
3. Press P again.

**Note** Pressing the P button for two seconds or longer will access the programming level. You can access values, such as OPEr, ConF, OFF, rEG, tune and OPLO, in the menu by selecting the increment/decrement keys. The user is blocked from all of these menu items. Leaving the unit untouched for approximately two minutes returns the display to the current temperature reading information. Turning the device off/on reinstates the temperature display.

Factory programming blocks the U key.

There are indicators below the display digits that show which relay is in use, OUT1 or OUT2. The arrows indicate if the unit is heating or cooling.

◀ heating      — temperature within range of set point      ▶ cooling

## Temperature Control

As described in the Specifications section, the cooling/heating capacity of a temperature control device based on the Peltier technique is always related to room temperature. Only a limited maximum temperature difference from ambient temperature can be achieved. PAL stack/tray cooler modules should reach a minimum difference of 14 °C ( $\Delta T$ ).

The controller provides the following temperature setting range:

- Stack cooler: +1 to 45 °C
- Tray cooler: +1 to 70 °C

This wider control range, which is greater than the specification limits (+4 to 40 °C and +4 to 70 °C, respectively), provides cooling or heating when the ambient temperature is too high or too low to easily reach the desired temperature. Heating to a higher temperature could be important for metabolism or kinetics studies at the human body temperature level of 37 °C.

The cooling option is usually necessary to protect the sample from ambient temperature during the analytical run time. Stack/tray cooler devices are rarely used to store a sample at a given temperature for a longer time period.

The measured and displayed temperature represents the temperature in the compartment and not in the sample liquid. To check the temperature control, an independent temperature probe is inserted from the front by removing one plastic screw from the front cover. Position the probe in the middle of the drawer where the tray separator projects up. Tape the probe to the metal plate of the drawer.

To reach +4 °C in the analytical solution, program a set value lower than +4 °C. The material used for the sample may be glass, polypropylene, polyethylene, or similar polymer products. All of these have excellent insulating properties.

If the sample has to be cooled as low as +4 °C, cool the sample tray first in a refrigerator before the tray is placed into a stack/tray cooler module. This shortens cool-down time considerably.

## Temperature Alarm

An internal alarm point of 55 °C protects the upper limit of a stack cooler module; it is 72 °C for a tray cooler. Reaching this point in a single fault situation causes the temperature control unit to automatically force cooling to the fullest extent possible. (The alarm is not audible.) At the same time a corresponding Error message is displayed. For explanations of these messages, see “Cooled Stack Power Supply Error Messages” on page 141.

A fuse to prevent overheating is built in for unattended automated runs.

The Peltier element turns off automatically at  $+72 \pm 5$  °C.

Only an authorized representative of Thermo Fisher Scientific can replace a damaged over-temperature fuse.

In case of error, do the following systematically:

1. Check the corresponding error message (see “Cooled Stack Power Supply Error Messages” on page 141).
2. Verify whether the appropriate power supply is being used for the stack cooler and tray cooler.
3. Turn off the power supply, wait a few minutes, and turn it on again.

Ensure that the alarm is off. If the alarm is still on, observe the corresponding error message.

## Temperature Stability

The stack/tray cooler is basically a thermostatted sample tray that keeps the analytical sample below or above ambient temperature.

Thermo Fisher Scientific recommends the following guidelines:

- Switch on the stack/tray cooler at least 30 minutes before the analytical routine run is to be started at +10 °C or 75 minutes, if operated at +4 °C.
- For high-throughput analysis—typical cycle time of 60 seconds or less per analysis—leave the drawers open between injections.
- For longer cycle times, use the Accela Open Autosampler option to close the drawer after each sampling.

You can change the Restore mode to keep the drawer open or closed during a run

**Note** The preset mode for the stack cooler in combination with the PAL System closes the drawers after sampling during an analytical run.

❖ **To change the Restore mode**

Complete the following steps starting at the top-level command from the control terminal:

- a. Choose **Menu > F3-Setup > Objects > Trayholders > Cstack > Restore Mode**.
- b. Change the default value from Sample to **Auto**.
- c. Press HOME.

## Condensation Build-Up

This section contains information about condensation build-up in in stack coolers and tray coolers.

### Condensation Build-Up in Accela Open Autosampler Stack Coolers

Condensation build-up is directly related to the temperature and relative humidity/temperature in ambient air (dew point). Long-term tests showed very little build-up of condensation in an environment of relative humidity up to 60 % and  $22 \pm 2$  °C ambient temperature.

Condensation at the back of the compartments is channeled to the drain outlet labeled Condensation Drain at the lower back portion of the stack cooler. The outlet is plugged with a paper filter. This helps to evaporate the collected water in the drain line using the excess heat from the Peltier element. A drain line from the outlet to a reservoir bottle is not necessary under normal conditions.



**CAUTION** If a flush gas is used as described below, you are responsible for ensuring that a two-stage safety pressure regulator device is installed between the gas supply and the stack cooler.

Do not use any flammable or explosive gas such as hydrogen.

If you operate the stack cooler under severe conditions, you can use a flow of dry and clean (oil-free) air or nitrogen to dry the compartments continually. Connect the corresponding gas line to the Swagelok fitting (1/8 in.) at the back of the stack cooler DW labeled Flush Gas. A flow of approximately 300 to 400 mL/min is required to keep the compartments moisture-free.

If acidic vapor phase is anticipated due to the application, use the same gas line connection to flush a stream of inert gas, such as nitrogen or helium, into the compartments. A stream of a few mL/min can help to prevent corrosion of the rolls.

Thermo Fisher Scientific recommends checking regularly for condensation build-up. It is good practice to clean the inside of the stack cooler when changing the analytical samples, dry out the stack cooler at ambient temperature at regular intervals, and open the drawers 1 cm to 5 cm (0.5 in. to 2.0 in.) for air circulation. The compartment drying frequency depends greatly on surrounding conditions.

## Condensation Build-Up in PAL Tray Coolers

Condensation build-up is directly related to the temperature and relative humidity/temperature in ambient air (dew point). Long term tests showed little build-up of condensation in an environment of relative humidity up to 60 percent and  $22 \pm 2$  °C ambient temperature.

A built-in drain line, as installed in stack coolers, is not provided in a tray cooler.

It is also good practice to install the Plexiglass lid whenever possible to avoid condensation build-up. You might not be able to install a lid for certain applications, for example, if a vial has to be transported to an Agitator or a Barcode Reader. In certain situations, the height of the vial is the limiting factor for installing a lid. Operating a tray cooler under less than optimal conditions requires some on-site improvisation. A simple foil or lid with cut-outs for the vials will limit condensation build-up dramatically.

Thermo Fisher Scientific recommends checking regularly for condensation build-up. Clean the inside of the tray cooler when changing the analytical samples, and dry out the tray cooler at ambient temperature at regular intervals.

**Note** For certain applications, a change from a tray cooler to Stack 2DW Cooler might be indicated. As long as deep well, microtiter plates, or 2 mL vials (TrayType VT54) are being handled, this change is positive with respect to condensation build-up. It would also double the capacity of the trays.



# Troubleshooting

This chapter describes the troubleshooting procedures based on different error messages. It also includes some special considerations for troubleshooting and standard chromatographic tests.

## Contents

- [Troubleshooting Using Observed Symptoms or Error Messages](#)
- [Cooled Stack Power Supply Error Messages](#)
- [Troubleshooting Considerations](#)
- [Standard Chromatographic Tests](#)

## Troubleshooting Using Observed Symptoms or Error Messages

Table 31 lists the symptoms or error messages and how to troubleshoot them.

**Table 31.** Troubleshooting using symptoms and error messages (Sheet 1 of 5)

Symptom or error message	Possible cause	Recommended action
Detector signal not detected or very low	Clogged syringe	Remove syringe and aspirate/dispense liquid manually. Clean syringe.
	Bent needle	Inspect and change syringe if necessary.
	No sample liquid injected	Check and adjust Needle Penetration into sample vial if necessary.
	Sample volume too low	Increase sample volume.
	Improperly installed valve needle guide and/or needle seal	Check valve needle guide and seal.
	Valve ports not plumbed correctly to the pump, the detection system, or both	Check plumbing connections.
	Wrong valve type specified	Check valve type by choosing the path: <b>Menu\setup\Objects\Injectors\LCV1v1\valve</b>

## 7 Troubleshooting

Troubleshooting Using Observed Symptoms or Error Messages

**Table 31.** Troubleshooting using symptoms and error messages (Sheet 2 of 5)

Symptom or error message	Possible cause	Recommended action
Flow of mobile phase and/or sample from the wrong ports on LC injection valve	The valve rotor is reversed (180 degrees out of alignment).	Remove the rotor and reinstall in the correct position. For a Cheminert valve, check for marking points. For a W-type valve, look for a letter (for example, H) stamped on the rotor. The letter must be on the lower half of the rotor.
Detector signal not detected or very low	Clogged syringe, needle, or holding loop	Remove syringe and aspirate/dispense liquid manually. Clean syringe, needle/holding loop, or both of these.
	Bent needle	Inspect and change syringe if necessary.
	No sample liquid injected	Check and adjust Needle Penetration into sample vial if necessary.
	Sample volume too low	Increase sample volume.
	Improperly installed valve needle guide, needle seal, or both	Check valve needle guide and seal.
Sample backing up on the valve needle guide	Valve ports not plumbed correctly to the pump, detection system, or both.	Check plumbing connections.
	Wrong valve type specified	Check valve type by choosing: <b>Menu\setup\Objects\Injectors\LCVlv1\valve</b>
	Syringe OD too small	Check the syringe needle for the correct gauge.  Gauge 22 = 0.72 mm OD
	Leaking valve needle seal	Change valve needle seal.
	Needle penetration depth set incorrectly for the injection valve	Adjust the injection valve needle penetration.
	The syringe plunger speed set too high, resulting in excessive pressure in inlet	Reduce inject speed in method.

**Table 31.** Troubleshooting using symptoms and error messages (Sheet 3 of 5)

Symptom or error message	Possible cause	Recommended action
Syringe not filling properly	DLW Actuator/Solenoid not functioning	Load PAL Firmware level smaller than 4.0 or PAL Firmware Object for DLW option onto the system.
		Solvent path is blocked. Prime the system or inspect it to identify the reason for clogging.
		Air bubbles are trapped in the system, caused by loose connections or tubing not cut square.
	Worn out syringe plunger tip	Replace syringe plunger. Check if glass barrel is scratched (damaged). If in doubt, replace the entire syringe at once.
	DLW Actuator Control PCB defect	If possible, verify the DLW Actuator Holder assembly on another PAL System. If defect is definite, replace PCB.
	DLW Flow Diverter	Check the Flow Diverter: <ul style="list-style-type: none"> <li>• Is the Flow Diverter inserted? Inserted in full up position?</li> <li>• Is the solvent flowing freely in the tube?</li> </ul>
	Fitting replaceable needle	Check the fixation and seal of the replaceable syringe needle: <ul style="list-style-type: none"> <li>• Is the retaining nut tight?</li> <li>• Is the PTFE seal installed?</li> <li>• Is the needle entry free of debris, not clogged?</li> <li>• Is the correct needle diameter (gauge 22) used?</li> </ul>

## 7 Troubleshooting

Troubleshooting Using Observed Symptoms or Error Messages

**Table 31.** Troubleshooting using symptoms and error messages (Sheet 4 of 5)

Symptom or error message	Possible cause	Recommended action
Sample peaks/responses not reproducible	Dirty syringe or Holding Loop	Increase Pst Cln Slv1/Slv2 values in method. Use PreClnSlv1/Slv2 and PreClnSpl.
	Syringe pressure differences	Increase Pullup Delay value.
	Vacuum created in sample vial	Reduce sample volume in sample vial. Use setting under <b>F3-Setup &gt; System &gt; PrePressureVial</b> .
	Method parameters	Check recommended Method parameters in “ <a href="#">PAL Firmware Overview</a> ” on <a href="#">page 191</a> . First verify these critical parameters: <ul style="list-style-type: none"><li>• Fill speed</li><li>• Pullup delay</li><li>• Injection Speed</li><li>• Post Inj Delay</li></ul>
Excessive carryover between samples	Loose, unstable, or wrong connection	Check all connections within the DLW system, such as needle, Holding Loop, injection loop connections, and so on.
	Inappropriate wash solvent or solvents	Use appropriate wash solvents.
	Waste tubing ID too small at injection valve, causing waste liquid to be pulled back, by capillary action, into rotor groove	Replace the waste tubing with larger ID tubing.
	Air gaps not formed. Liquids of different type blending into each other.	Verify the DLW method parameter for Airgap Volume.  Prime entire system.

**Table 31.** Troubleshooting using symptoms and error messages (Sheet 5 of 5)

Symptom or error message	Possible cause	Recommended action
Excessive carryover between samples	Dirty needle, holding loop, and/or valve injection port	Increase Pst Inj Slv1/Slv2 values in method (cleaning time).  Use PreClnSlv1/Slv2 and PreClnSpl.
	Inappropriate wash solvent or solvents	Use appropriate wash solvents.
	Waste tubing ID too small at injection valve, causing waste liquid to be pulled back, by capillary action, into rotor groove.	Replace the waste tubing with larger ID tubing.
	Damaged or grooved valve rotor	Replace valve rotor.
	Leaking valve needle seal	Change valve needle seal.
	Inappropriate wash solvent composition	Use appropriate wash solvent. Also observe the order of use for biological samples. First wash is always an aqueous solution followed by organic solvents.
	Tube of holding loop at end not cut square or nut/ferrule fixation not correct.	Check the connections from the holding loop: <ul style="list-style-type: none"> <li>• Is the pilot distance appropriate?</li> <li>• Is the tube end damaged?</li> <li>• Is the tube end cut absolutely square?</li> <li>• Are the right nuts and ferrules used?</li> </ul>
	DLW Actuator/Solenoid questionable or defective	Verify the functionality of the DLW Actuator.  Is solvent flowing when active? Use command <b>Utilities &gt; Wash Station</b> to test.
	Blocked solvent frits in wash solvent reservoir	Clean the frits in an ultrasonic bath with an appropriate solvent. If flow is not ensured after cleaning, replace frits.  Replace wash solvent and clean reservoir bottle and tubing carefully.

## Cooled Stack Power Supply Error Messages

The temperature control unit for the stack cooler can display feedback messages in the form of error messages. See [Table 32](#).

**Table 32.** Stack cooler controller error messages

Message	Description	Reason	Check/Solution
-----	Error probe	DC cable disconnected or in short circuit	Check connection between power supply and Stack/TrayCooler.
		Connection mistake	Check signal probe (for example: NTC measures the resistance: 25 °C = 10kOhm).
		Damaged Probe	
uuuu	Under range	Measured variable below the sensor limit	Check the set point for the desired temperature.
oooo	Over range	Measured variable above the sensor limit	Turn the unit off/on. Initialize the Temp. Control Unit to normal level.
			Check the set point for the desired temperature.
LbA	Loop break alarm	Interruption of loop break alarm	Check the set point for the desired temperature.
			Turn the unit on/off. Initialize the Temp. Control Unit to normal level.
ErEP	EPROM	Error in Eprom	Press P.

Other messages, such as ErAT and noAT, are suppressed and are not of use in this application.

**Note** The Temperature Control Unit for the stack/tray cooler does not allow the user to enter different levels of programming functions. The program is factory set, downloaded to each Temperature Control Unit at the factory. A power supply programmed for the PAL Stack Cooler cannot be used for a PAL tray cooler.

## Troubleshooting Considerations

This section contains information about special troubleshooting considerations, including tubing connections and solvent delivery pumps not priming or not functioning.


### Tubing Connections

You must pay special attention to all tubing connections, including these common mistakes in routine practice:

- Nut and ferrule not connected leak tight (see [Nut and Ferrule Tightening](#))
- Incorrect pilot distance (see [Incorrect Pilot Distance](#))
- Tube not cut square (see [Tube Not Cut Square](#))
- Wrong type of ferrule or nut used (see [Wrong Nuts or Ferrules Used](#))
- Trapped air bubbles (see [Avoiding Trapped Air Bubbles](#))

Figure 103 provides an illustration of the terms used for tubing connections.

**Figure 103.** Terms for tubing connections



Such mistakes lead to:

- Dead volume
- Peak deformation or peak splitting
- Carryover effects
- Decreased resolution of the tubing between column and detector

You can prevent issues with tubing connections by observing the following basic rules.

## Nut and Ferrule Tightening

### ❖ To tighten a nut and ferrule stepwise

1. The first important rule when tightening a nut and ferrule is to proceed stepwise.
  - a. Tighten the nut by hand as much as possible.
  - b. Continue to tighten using a wrench until you feel resistance. Add one or two quarter turns to reach the sealing point.
  - c. Open the connection and remove the assembly to inspect the pilot distance. See [Figure 103](#).
  - d. Install the assembly again and, first, manually tighten the nut. Then, use the wrench to reach the same sealing or resistance point as reached in step 2 and add one quarter turn extra for the final seal.
  - e. Check the seal when liquid is pumped through the system. In case a leak is observed, tighten once more by another quarter turn. Always move from a leaking to a tight seal; never move backward from an over-tightened seal.

Do not over-tighten the nut/ferrule. If a connection proves to be leaky, use another quarter turn to tighten. Step-by-step tightening is the correct approach. Over-tightening even once will damage the seat, and the next connection can only be sealed using force. If the seat is damaged, the ferrule will likely stick and require force or special tools (such as a drill) to remove it.

If you use different materials, such as a polymer tubing and nut, together with a stainless steel ferrule, then over-tightening is always a danger. The ferrule will bite into the polymer tube and block the flow.

When installing a tube with a narrow bend, typically a loop, fix one connection first; do not simultaneously insert the second nut into the female counterpart. After tightening open the connection as described above, start preparing the second connection without inserting the first nut. Open the second connection again and check the pilot distance. The last step is inserting the complete tubing with the two connections and making a final seal as described earlier.

This stepwise installation of a bended tube is mandatory for PEEKsil tubing (fused silica tubing sheathed with PEEK polymer).

2. The second rule to observe when installing nuts and ferrules is to never reuse them for any other connection.

Do not install a tube for any other application with a nut/ferrule that is set for a specific purpose. Cut a portion of the tube end until straight tubing is reached and remove the ferrule.

This rule is valid for a loop as well. Never reuse a loop for another valve or reuse a valve after exchanging the stator.


If a finger-tight nut has been installed, replace it as well. If a stainless steel nut has been used, ensure that you use the correct type.

Newly installed finger-tight ferrules can hold a backpressure of up to 200 bar.

## **Incorrect Pilot Distance**

When making a new tube connection, be sure to follow these guidelines:

1. Slip the nut and ferrule over the tube. Make sure the end of the tube sticks out approximately 50 mm (2 in.).
2. Press the tube end firmly into the female counterpart for the connection.
3. Move the nut and ferrule together into the female counterpart for the connection. Make sure to maintain pressure on the tube to avoid the tube slipping backwards, out of position.
4. Tighten the nut as described in the previous section.

**Figure 104.** Pressing the tube into place

Failure to observe this procedure will lead to an incorrect pilot distance, which will result in actual dead volume, not delay volume.

## Tube Not Cut Square


All tubes have to be cut absolutely square. Any deviation from square causes a dead volume which yields carryover and other chromatographic effects. This rule is valid for stainless steel, PEEK, or Polymer tubing. The material is not decisive, but using the correct tool for each material when cutting a tube is.

Stainless steel tubes are often cut by using pliers. Often, an egg-shaped profile results, which no longer seals and causes dead volume. Dedicated pliers for HPLC tubing are available on the market; nevertheless, for best results, use precut tubing which is cut smooth and clean, and is passivated.

Because polymer tubes, such as PEEK, Teflon, PFA, and so on are soft, you might choose to cut them with any handy tool. Commercially available tubing cutters from many manufacturers are available. If the blade does not provide a clean, right-angle cut, however, use a different technique.

The most reliable and common way to cut tubing of any material is with a cutter that has an adjustable blade. Carry out the initial turns, readjust the blade, turn once more, and adjust again until approximately half of the tubing wall is cut. Hold the tube on the two sides of the cut with flat-nose pliers and twist the tube until it breaks. You can use the same procedure for polymer tubing by replacing flat-nose pliers with tweezers with a flat tip.

**Figure 105.** Illustration of various tubing cuts




## Wrong Nuts or Ferrules Used


Do not use a nut or ferrule from a vendor other than those specified for the product. [Figure 106](#) illustrates the resulting dead volume when you use an incorrect nut or ferrule type for connecting.

[Figure 107](#) shows the various forms of the ferrules from different manufacturers. Although some of them are close in shape to what you need, they are not close enough to exchange without risk.

**Figure 106.** Dead volume created due to wrong ferrule type



**Figure 107.** Ferrule types from various vendors



### Avoiding Trapped Air Bubbles

It is common practice to make a connection only if the ports are wetted. The liquid helps to prevent trapped air bubbles, which are often tedious to remove or work out of a system.

### Solvent Delivery Pumps Not Priming

The solvent delivery pumps of the Pump Module can fail to prime at initial operation.

You must wet the pump at the solvent inlet port or, preferably, prime the tubing from the Solvent reservoir to the pump and make the connection.

Dry running the pump for a short time will not harm it.

### Solvent Delivery Pump Not Functioning

The pump flow rate depends greatly on the viscosity of the selected wash solvent and the given backpressure of the entire system. Consider the valve bore size (standard Cheminert valve 0.25 mm), as well as the tubing and injection loop internal diameter.

If in doubt about the delivered volume of a pump, run the following test (Test 1). If the result of the test is negative, check the flow from the pump directly (Test 2).

❖ **(Test 1) To test the pump flow delivered throughout the entire system**

1. Prepare a graduated cylinder with a volume of 10 or 20 mL.
2. Test a solvent, for example, water.
3. Select the path from the local terminal workstation.

**Menu\Utilities\Wash Station\the desired wash station**

The delivery pump and the DLW Actuator are activated, and you can collect the delivered flow at the DLW syringe needle.

Expected result: Collection of approximately 8 mL

(Water, DLW syringe needle, gauge 22)

❖ **(Test 2) To test the pump flow delivered at the pump outlet**

1. Disconnect the outlet tube from the pump module.
2. Connect PEEK tubing with the following dimension to the outlet of the pump module:  
85 mm (3.35 in.) ID, 0.25 mm (0.010 in.) ID.
3. If necessary, replace the solvent in the reservoir bottle with water.
4. Activate the pump by selecting this path:

**Menu\F3-Setup\Objects\Events\Pwr-Out1 or Pwr-Out2**

5. Collect the pumped water in a graduated cylinder.

Expected Result: Within 30 seconds, pump delivery of approximately 10 mL

This short test can indicate whether the system is performing as expected. If you observe no or very little flow, systematically check using a process of elimination. For more details, see [Table 31](#).

## Standard Chromatographic Tests

This section describes standard chromatographic tests for carryover and repeatability. These tests provide basic information for both users and technical support.

The tests described are examples only; vary them accordingly if the configuration of the HPLC system changes.

The first test uses PAL standard valves with a bore size of 0.25 mm to provide a flow rate range of 10 to 500  $\mu\text{L}/\text{min}$ .

Both tests, carryover and repeatability, test conditions for UV and LC/MS detection.

Details are listed in the next section. Note that the given levels to reach for carryover and repeatability do not reflect the specification value. These described tests should give you confirmation if the system is working to expectation using reasonable effort and time. The tests are more comparable with an OQ Test (Operational Qualification Test).

**Note** The levels provided in these tests do not reflect the specification value for careover or repeatability. The test results will confirm if the system is working properly with reasonable effort and within the expected time frame. The tests are comparable to Operational Qualification (OQ) tests.

## Carryover Test with UV-Detection

Table 33 lists the specifications for carryover tests with UV-detection.

**Table 33.** Specifications for carryover tests with UV-detection

Component	Specification
Test Sample	Chlorhexidine, 0.6 mg/mL dissolved in Water: Acetonitrile = 90: 10 + 0.1%TFA
Blank Solution	Water : Acetonitrile + 0.1%TFA
HPLC System	<ul style="list-style-type: none"> <li>Binary solvent delivery pump</li> <li>UV-Detector, wavelength: 257 nm</li> <li>HPLC column: C18 (Halo), 2.1 x50 mm spherical 2.7 <math>\mu</math>m</li> <li>Column temperature: Ambient</li> <li>Mobile Phase:               <ul style="list-style-type: none"> <li>A: Water + 0.1%TFA</li> <li>B: Acetonitrile +0.1% TFA</li> </ul> </li> <li>Gradient:               <ul style="list-style-type: none"> <li>10% A hold for 0.5 Min, to 90% B in 7.5 min</li> <li>hold for 1 min</li> </ul> </li> </ul>
Wash Solvents	<ul style="list-style-type: none"> <li>Wash1: Water +0.1% TFA</li> <li>Wash2: Acetonitrile +0.1% TFA</li> </ul>
Loop Size	2 $\mu$ L; Loop ID 0.13 mm
Injection Valve	VICI/Valco (CH-106678), bore size 0.25 mm
Cycle Composer Macro or Cycle (ICC-CE)	DLW Standard

### Cycle Composer Method Parameter Settings

Table 34 lists the Cycle Composer Method parameter settings for carryover tests with UV-detection.

**Table 34.** Carrover tests with UV-detection (Sheet 1 of 2)

Parameter	Value
Syringe	100 $\mu$ L DLW
Sample Volume	7 $\mu$ L
Airgap Volume	3 $\mu$ L
Front Volume	5 $\mu$ L
Rear Volume	5 $\mu$ L

**Table 34.** Carrover tests with UV-detection (Sheet 2 of 2)

Parameter	Value
Needle Gap Valve Clean	3 mm
Fill Speed	5 µL/s
Fill Strokes	0
Stator Wash	0
Pullup Del	500 ms
Inject to	Specified Inj. Valve
Inject Speed	5 µL/s
Pre Inj Del	500 ms
Pst Inj Del	500 ms
Valve Clean Time Solvent 2	2 s
Post Clean Time Solvent 2	2 s
Valve Clean Time Solvent 1	3 s
Post Clean Time solvent 1	2 s

## Repeatability Test with UV-Detection

Table 35 lists the specifications for repeatability tests with UV-detection.

**Table 35.** Repeatability tests with UV-detection (Sheet 1 of 2)

Component	Specification
Test Sample	<ul style="list-style-type: none"> <li>• Loop overfill: Caffeine, 520 mg/L</li> <li>• Partial loop: Caffeine, 52 mg/L dissolved in water : Acetonitrile = 90:10 + 0.1%TFA</li> </ul>
HPLC System	<ul style="list-style-type: none"> <li>• Binary solvent delivery pump</li> <li>• UV-Detector, wavelength: 273 nm</li> <li>• HPLC column: Hypersil Gold C18, 2.1 ×50 mm spherical 1.9 µm</li> <li>• Column temperature: Ambient</li> <li>• Mobile phase Water: Acetonitrile = 90:10 +0.1% TFA</li> <li>• Gradient: Isocratic for 2 min</li> </ul>
Wash Solvents	<ul style="list-style-type: none"> <li>• Wash1: Water + 0.1% TFA</li> <li>• Wash2: Acetonitrile +0.1% TFA</li> </ul>

**Table 35.** Repeatability tests with UV-detection (Sheet 2 of 2)

Component	Specification
Loop Size	<ul style="list-style-type: none"> <li>• 2 µL (Loop overfill, 7 µL)</li> <li>• Loop ID: 0.13 mm</li> <li>• 20 µL (partial loop, 10 µL)</li> <li>• Loop ID 0.25 mm</li> </ul>
Injection Valve	VICI/Valco C72VX-1696D-CTC, bore size 0.25 mm
Cycle Composer Macro or Cycle (ICC-CE)	DLW Standard

### Cycle Composer Method Parameter Settings

Table 36 lists the Cycle Composer Method parameter settings for repeatability tests with UV-detection.

**Table 36.** Repeatability tests with UV-detection

Parameter	Value
Syringe	100 µL DLW
Sample Volume	7/10 µL
Airgap Volume	3 µL
Front Volume	5 µL
Rear Volume	5 µL
Needle Gap Valve Clean	3 mm
Fill Speed	5 µL
Fill Strokes	0
Stator Wash	0
Pullup Del	500 ms
Inject to	Specified Inj. Valve
Inject Speed	5 µL/S
Pre Inj Del	500 ms
Pst Inj Del	500 ms
Valve Clean Time Solvent 2	2 s
Post Clean Time Solvent 2	2 s
Valve Clean Time Solvent 1	3 s
Post Clean Time Solvent 1	2 s



# Replacement Parts

This chapter describes the replacement parts for the Accela Open Autosampler and the Dynamic Load and Wash (DLW) option.

## Contents

- [DLW Pump Module](#)
- [DLW Wash Station](#)
- [DLW Syringe](#)
- [DLW Syringe Holder Assembly](#)
- [DLW Option Spare Parts Ordering Information](#)
- [Control-xt Board](#)
- [Injection Valve and Valve Rotor](#)
- [Injection Unit](#)



## CAUTION

- Before attempting any type of maintenance, always disconnect the power cords from the power supply or from the various power supplies if optional devices are installed.
- To prevent possible shock, do not touch the capacitors. Capacitors inside the instrument can remain charged, even if the instrument is turned off.
- To avoid damaging electrical parts, do not disconnect an electrical assembly while power is supplied to the PAL System. Once the power is turned off, wait approximately 30 seconds before you disconnect an assembly.

This section provides short descriptions of parts that can be replaced in the field.

## DLW Pump Module

You can exchange the following parts individually from the DLW pump module:

- Single-pump module (incl. electrical connection)
- Solvent tubing kit
- Electrical cable (from pump module to PAL System)
- Pump control PCB
- DLW tubing kit

## DLW Wash Station

You can exchange the following parts individually from the DLW wash station module.

- Wash station block
- Wash station inserts
- Waste tube
- Waste tube (valve-to-wash station)
- Dummy plugs

**Note** The inserts and individual parts of the wash station block will be available in an update for this system part.

## DLW Syringe

You can exchange the following parts individually from the DLW syringe assembly:

- DLW syringe 100  $\mu$ L
- DLW syringe plunger (for syringe 100  $\mu$ L)
- DLW syringe plunger holder
- DLW syringe retaining nut
- DLW syringe replaceable needles

## DLW Syringe Holder Assembly

You can exchange the following parts individually from the DLW syringe holder assembly:

- DLW syringe holder assembly (complete assembly)

- DLW needle adapter block
- DLW needle holder assembly
- Holding loop
- DLW manifold




(Entire unit assembled, consisting of DLW solvent selector and DLW syringe adapter with Perfluor O-ring installed)

- DLW flow diverter
- DLW actuator/solenoid
- DLW actuator control PCB (incl. cable)
- DLW syringe holder fixation screw

## DLW Option Spare Parts Ordering Information

Table 37 contains spare parts ordering information for the DLW option.




**Table 37.** DLW option spare parts ordering information (Sheet 1 of 5)

Part name/number	Description	Illustration
<b>DLW Pump Module</b>		
00950-01-00310	PAL DLW Pump Kit (single module), incl. electrical connections, 24 V	
00950-01-00311	Aspiration Tube Kit, consisting of: <ul style="list-style-type: none"> <li>• 1 pc. Tube PFA</li> <li>• 1 pc. PEEK solvent filter 10 µm</li> <li>• 1 pc. Plug with feed through hole</li> </ul>	
00950-01-00312	Cable for PAL-xt wash station round connector, 130 cm long	




## 8 Replacement Parts

DLW Option Spare Parts Ordering Information

**Table 37.** DLW option spare parts ordering information (Sheet 2 of 5)

Part name/number	Description	Illustration
00950-01-00313	PAL DLW Pump Control Module PCB Kit	
00950-01-00314	PAL DLW Wash Station Tubing Kit, consisting of: 2 pcs. tubing, wire supported and connections	
<b>DLW Wash Station</b>		
00950-01-00315	PAL DLW Wash Station Block, complete assembly (incl. centering plate)	
00950-01-00334	PAL DLW Wash Station Insert Kit, consisting of: <ul style="list-style-type: none"><li>• 2 pcs. Inserts</li><li>• 1 pc. Waste Connector</li><li>• 5 pcs. Dummy Plugs</li></ul>	
00950-01-00335	Tube waste for wash station, length 2 m	
<b>DLW Syringe</b>		





**Table 37.** DLW option spare parts ordering information (Sheet 3 of 5)

Part name/number	Description	Illustration
00950-01-00325	Syringe for PAL DLW Option, 100 $\mu\text{L}$ gastight; $\text{\O}7.7$ mm; Scale Length 60 mm; Thread $\frac{1}{4}$ -28 UNE. Removable needle, not included	
00950-01-00326	Replacement plunger for syringe SYRC DLW-R.; pkg of 10	
00950-01-00327	PAL DLW Plunger Holder	
00950-01-00328	Needle Kit for PAL DLW Option, gauge 22 PST 3, / 51 mm (3 pcs. per pack); incl. needle retaining nut	
<b>DLW Syringe Holder assembly</b>		
00950-01-00316	PAL DLW Syringe Holder assembly; complete assembly with 100 $\mu\text{L}$ syringe, without syringe needle	



## 8 Replacement Parts

DLW Option Spare Parts Ordering Information

**Table 37.** DLW option spare parts ordering information (Sheet 4 of 5)

Part name/number	Description	Illustration
00950-01-00317	Kit PAL DLW Holding Loop with needle adapter mounted	
00950-01-00318	PAL DLW Manifold Kit, complete, assembled	
00950-01-00319	PAL DLW Flow Diverter, pkg of 1	
00950-01-00320	PAL DLW Actuator/Solenoid Kit, incl. screws, without cable	
00950-01-00321	PAL DLW Actuator Control PCB Kit, incl. cable and screw set	
00950-01-00322	Syringe Holder Fixation Screw, pkg of 1	

**Table 37.** DLW option spare parts ordering information (Sheet 5 of 5)


Part name/number	Description	Illustration
00950-01-00323	PAL DLW Needle Length Guide tool, pkg of 1	
00950-01-00324	PAL DLW Needle Holder Kit	

**Note** Individual parts or the total composition of spare part kits can change without notice.



## DLW-2 Option Spare Parts Ordering Information

Table 38 contains spare parts ordering information for the DLW-2 option. The complete list of the DLW-2 spare parts include all DLW spare parts and the parts in Table 38.

**Table 38.** DLW-2 option spare parts ordering information (Sheet 1 of 2)

Part name/number	Description	Illustration
<b>DLW Pump Module</b>		
00950-01-00359	PAL DLW-2 Syringe Holder assembly; complete assembly with holding loop and 100 $\mu$ L syringe installed	

**Table 38.** DLW-2 option spare parts ordering information (Sheet 2 of 2)

Part name/number	Description	Illustration
00950-01-00360	Kit PAL DLW-2 holding loop with need and adapter mounted	
00950-01-00361	PAL DLW-2 Needle Holder Kit	
00950-01-00362	PAL DLW-2 Actuator Control PCB Kit, incl. cable and screw set	

## Control-xt Board

**PN: 000950-01-00329**

### ❖ To install the control-xt board


**Note** The Control-xt board replaces the control board (PN: CH-952589). This board is required for the Accela Open Autosampler system and operates only at PAL Firmware level 4.1.x or later.

1. Follow the sequence shown in [Figure 108](#) to detach and release the Control-xt board from its position inside the x axis. As shown, remove the dummy cover first.
2. Carefully pull the two ribbon cable connectors upwards to free them from the board.

3. Install the replacement board in the reverse order.

**Tip** After reconnecting the two ribbon cables to the board, ensure that the cables are folded flat and can slide inside the *x* axis without damage.

**Figure 108.** Replacing Control-xt board



## Injection Valve and Valve Rotor

This section describes the commonly used injection valves with 6-ports.

### Cleaning or Replacing Injection Valves


This section contains information about cleaning or replacing the injection valve for the VICI/Valco Cheminert.

#### Cheminert

❖ **To clean or replace the Cheminert injection valve (see [Figure 109](#))**

1. Remove the sample loop, needle guide fitting, and connection tubes from the valve body.
2. Unscrew the Torx screw at the valve adapter, which holds the valve to the valve drive.
3. Check that the valve guide pin remains at its position and observe the guide marks as shown in [Figure 57](#) on [page 59](#).
4. Install the replacement valve in the reverse order.

**Figure 109.** Replacing the VICI/Valco Cheminert injection valve



## Cleaning or Replacing Valve Rotors

This section contains information about cleaning or replacing valve rotors for the VICI/Valco Cheminert.


### Cheminert Valve Rotor

❖ **To clean or replace the valve rotors for VICI/Valco Cheminert (see [Figure 110](#))**

1. Do not remove the valve from the valve drive. For improved access, you may remove all tubing or the loop.
2. Unscrew the two hex screws, which hold the valve stator to the valve body.

3. Carefully lift out the rotor disk with a protected tool (with tips protected to avoid scratching the surface).
4. Insert the new rotor. The size-coded positioning tabs prevent you from inserting the rotor upside down.
5. Tighten the hex screws carefully and evenly to reach a parallel seat of valve stator and body.

**Figure 110.** Rotor replacement of Cheminert valve



## Injection Unit

For details on the parts of the injection unit, see [“Installing the Injection Unit”](#) on page 18.



## Maintenance

This chapter describes the maintenance procedures that can help you operate the Accela Open Autosampler under optimal conditions.

To ensure accuracy and precision of the Accela Open Autosampler. Follow the maintenance procedures at the suggested intervals in [Table 39](#).

If you use the system extensively (for example, nights and weekends), or if you use corrosive solvents, you might need to perform the maintenance procedure more frequently.

**Table 39.** Routine maintenance for Accela Open Autosampler (Sheet 1 of 2)

Maintenance step	Interval
Clean the outside of the instrument. Use only a soft, lint-free cloth dampened with mild soap and water.	Weekly or as needed
Clean instrument, syringe, and surfaces.	Weekly or as needed
Replace the valve needle seal.	Check the tightness of the needle in the needle seal.
Replace the valve rotor.	Annually or more often, depending on the throughput and quality of sample solution and mobile phase
Clean the outside of the instrument. Prime the entire DLW system by using the dedicated macro (cycle).	Daily or as needed (required before routine running)
Replace the DLW syringe plunger.	The syringe plunger for a gas tight syringe (polymer tip) has to be replaced on a regular basis. The interval is highly dependent on the application, throughput, and quality of the sample solution (particles, and so on) washing solvent. Check the tightness of the plunger on a regular basis to gain experience with the application.
Replace the DLW syringe needle. Observe the correct placement of the Teflon seal.	Only as needed (for example, if bent)
Check all connections for tightness.	Weekly or as needed

**Table 39.** Routine maintenance for Accela Open Autosampler (Sheet 2 of 2)

Maintenance step	Interval
Replace the DLW holding loop.	Recommended once a year as preventative maintenance
Check the spring-loaded needle holder assembly for functionality. Check the spring compression in particular.	Weekly or as needed
Wash and waste solvent reservoirs: check flow restriction of frits.	Weekly or as needed
Quality of solvents, biological growth	
Check the functionality of the DLW actuator/solenoid.	Weekly or as needed Change once a year as preventative maintenance.

Specific kits for the GC or the HPLC techniques are available. The kits include parts that you must change annually.

## Cooled Stack Maintenance

If you use the system extensively (for example, nights and weekends), or if you use aggressive solvents, you might need to perform maintenance procedures more frequently.

**Table 40.** Stack/tray cooler maintenance (Sheet 1 of 2)

Maintenance step	Interval
Clean the outside of the instrument. Use only a soft, lint-free cloth dampened with mild soap and water.	Weekly or as needed
Clean and dry the inside of the instrument if necessary, including compartments, rolls, and rails. Use only a soft, lint-free cloth.	Daily or as needed

**Table 40.** Stack/tray cooler maintenance (Sheet 2 of 2)

Maintenance step	Interval
Clean and grease the rolls and the rails*.	<p>Once a year without acidic vapor exposure</p> <p>If acids are used for the sample solution and the stack cooler is exposed to the vapor, clean more frequently, as required.</p> <p>A positive stream of inert gas, such as nitrogen, dried and clean air, or helium, can prevent corrosion. See “<a href="#">Condensation Build-Up</a>” on <a href="#">page 134</a>.</p>
Verify the position and condition of the stopper and holding magnet of the drawer or drawers.	Monthly or as needed

\* Only valid for stack cooler modules

**Note** Recommended Grease and Supplier:

- Grease (PN: CH-952961): approx. 8 g grease and brush
- Grease Temperature Range: -130 to +150/+200 °C
- Supplier: Thermo Fisher Scientific

**Note** There are no operator-serviceable or replaceable parts inside the power supplies or the PAL System. In case of failure, contact a Thermo Fisher Scientific representative.

**Note** In the Power Supply (PN: CH-952995), revision level F, a fan is installed in the housing to cool the electronic components. Fan cooling prolongs the life of the electronic components.

**WARNING** Check the fan regularly. If the fan fails, the power supply still operates and can pass safety tests, even when the temperature is dangerously high and might damage the system electronics.



# Appendix

This appendix contains the following reference information.

## Contents

- [Glossary](#)
- [Naming Convention](#)
- [Special Functions](#)
- [PAL Firmware Overview](#)
- [PAL Firmware Error Codes](#)
- [External Connectors for Accela Open Autosampler](#)
- [System Limitations](#)
- [Interfacing the Open Autosampler to Other Devices](#)

## Glossary

Table 41 provides a list of glossary terms related to the Accela Open Autosampler.

**Table 41.** Accela Open Autosampler glossary (Sheet 1 of 3)

Terms	Description
Cycle	The specific operations necessary to process one sample. The cycle operations are repeated for each sample within a job. Cycles are designed for specific applications.
Job	The information needed by the Accela Open Autosampler to process multiple samples by the same processing steps. The elements of a job are a method and a tray that define the location of the samples to be processed. For identification, jobs are automatically numbered from 01 to 99 and then restart with 01 when they are added to the Job Queue.
Job queue	A list of sample processing jobs. Jobs are executed in the order displayed on the JOB QUEUE menu screens. You can add new jobs to the queue while samples are being processed.

**Table 41.** Accela Open Autosampler glossary (Sheet 2 of 3)

<b>Terms</b>	<b>Description</b>
Method	How the samples are processed. The elements of a method are a cycle, a syringe, and a parameter list. Methods have names with up to eight characters and can be edited, copied, and deleted.
Method parameters	<p>Associated with the cycle operations. User-assigned parameter values define how a processing operation is performed.</p> <p>A zero parameter value will disable a cycle operation. Cycle parameters are application-specific.</p>
Module	<p>PAL hardware module, either part of a standard PAL configuration (for example, Combi PAL, HTS PAL) or an optional addition (for example, cooled stack, MALDI tool, dilutor).</p> <p>The term <i>Module</i> is intentionally used to differentiate from object, which is reserved for the PAL firmware object.</p>
Objects	Data structures describing the properties of physical modules. Certain modules (for example, a stack) require several objects.
Object class	<p>Each object belongs to an object class (for example, syringes, trays, injectors).</p> <p>The object class defines the Items of an object.</p>
Object Item	<p>An object contains several Items, which can be numerical values with a physical unit (for example, <i>x</i>-, <i>y</i>-, <i>z</i>-position, penetration, syringe scale length, syringe volume) or references to other objects.</p> <p>Note that the term, <i>Parameter</i>, is reserved for ATOM Parameter.</p> <p>(PAL firmware commands are to be used for a PAL cycle or macro).</p>
PAL Object list	<p>If you add a PAL module (hardware) to an instrument, you must load several objects into the firmware. These objects are collected in an object list and stored in a file with the extension *.pol.</p> <p>Object lists are delivered together with object manager software and are grouped into folders for the different kind of modules (for example, syringes, tray holders, valve drives). The name of an object list starts with the module part number with variants added (for example, first or second stack). The name of the root folder includes the revision which depends on the firmware version (for example, object lists Rev. K for firmware 2.x and 3.x).</p>
PAL Object Manager	Software to load a PAL object list to an instrument if a module (hardware module) has been added to the PAL System. In a special mode, you can also use the Object Manager to create and maintain object lists.

**Table 41.** Accela Open Autosampler glossary (Sheet 3 of 3)

Terms	Description
Stack	A particular type of tray holder that is designed to hold microplates. A six-drawer stack holds 12 standard microplates, two in each drawer.  A three-drawer stack holds six deep-well microplates, two in each drawer.
Tray	Holds multiple samples. Trays are defined by designating the tray type (see below) and the tray holder. Tray names are used to identify the sample source within an autosampler job.
Tray holder	Holds one or more trays. Each tray holder has a reference position ( $x$ , $y$ , $z$ coordinates) that defines its location.
Tray type	The pattern and sampling sequence of sample locations within a tray.

## Naming Convention

This section recommends the standard naming convention for the Accela Open Autosampler. Following this convention will allow the PAL setup to be preconfigured for certain applications. This will simplify software backups and application development, and will improve technical support and training.

**Table 42.** Naming conventions (Sheet 1 of 2)

Tray type	Tray description
VT200	Vial tray, 200 positions (10×20)  For 7 mm micro vials 1 mL
VT98	Vial trays, 98 positions (7×14)  For 12 mm vials 2 mL
VT78	Vial tray, 98 positions (6×13)  For 7 mm micro-vials, 1 mL (opposite side of 98 positions tray)
VT54	Vial tray, 54 positions (6×9)  For 12 mm vials, 2 mL
VT21	Vial tray, 21 positions (7×14)  For 12 mm vials, 2 mL
VT32-10	Vial tray, 32 positions (4×8)  For 23 mm headspace vials, 10 mL

**Table 42.** Naming conventions (Sheet 2 of 2)

Tray type	Tray description
VT32-20	Vial tray, 32 positions (4×8) For 23 mm headspace vials, 20 mL
VT15-10	Vial tray, 15 positions (3×5) For 23 mm vials, 10 mL
MT96	Standard 96-position shallow microplate
DW96	Deep well 96-position microplate
MT384	High density 384-position shallow microplate

## Special Functions

This section describes special functions that you can activate by applying the Extended User mode.

The purpose of having two software access levels is to display discrete items and sections of the firmware at each level. Settings that you set rarely—perhaps at the time of the Accela Open Autosampler system installation—are hidden at level 1 (User Level) and revealed at level 2 (Extended User Level). This also protects the Accela Autosampler in group use. Nevertheless, you should become familiar with the important points as described.

## Accessing Extended User Mode

Access the Extended User mode by the following path:



You can navigate to the Extended User mode in one of three ways:

- Choose **Menu > Setup**.
- Press the F3 function key.
- Activate **Setup** by pressing the center of the selector knob.


For the purpose of the PAL user manual or technical notes, use the following only:

**Menu > F3-Setup.**

## Section F3-Setup

This Setup section at the Extended User Level provides various options to access other classes that are not visible at the User Level. You might already be familiar with some of the classes but others might be new. See the details in [Table 43](#).

**Figure 111.** Selecting Setup in Extended User mode



**Table 43.** Extended User Level options (Sheet 1 of 2)

Object	Description
Ident	The Identification of the system provides the opportunity to assign users, site, and system names. You can enter the serial number of the Accela Open Autosampler at this level. After loading a fresh PAL Firmware backup file, the SNo. is displayed as XXXXXX.
Access	Selectively open or limit access to different users for the Job, Method, or Setup.
Sounds	An adjustable beep sound for specific needs. For safety reasons, keep the default settings, especially the Warn Move, turned on to signal the start of the PAL System to the user.
Time	Sets the PAL internal clock.  If the clock is fast, reset all items, from Year to Seconds and use the mandatory function key F1 (for Set Time).
Communication	Define the communication mode, serial or LAN, and define conditions.  The current Accela Open Autosampler does not support LAN communication.
System	Predefine basic parameters for specific needs.

**Table 43.** Extended User Level options (Sheet 2 of 2)

Object	Description
Service	Activate basic service tests.
Objects	Accessing the PAL Firmware Class Objects in the Extended User mode provides more detailed possibilities for object items. At this level, you can copy or delete an Object by using the specific function keys. This provides quick access to add, for example, a second or third injector.

## System

Select the particular item to change system settings.

PAL Firmware level 4.1.x adds an intermediate step. After selecting System, the new Settings level follows. Activating Settings opens the described items in [Table 44](#).

**Table 44.** System items (Sheet 1 of 3)

Item	Description
Syr Detect	Turns off the syringe detection if the sensor fails or if a special syringe with unknown ID is installed. Turning the syringe identification sensor off displays a dialog box for selecting a syringe identification.
Start Ref	Provides the choice of referencing all axes at the start of the system or suppressing the referencing. Use this function to detect a possible loss of steps.
Stop XY Error	<p>Turns off the automatic recovery of the PAL System after detecting a collision (loss of steps of a stepper motor).</p> <p>Stop XY Error = ON: Automated recovery turned OFF</p> <p>Stop XY Error = OFF: Automated recovery turned ON</p> <p>If recovery is turned off, the PAL System always checks its position before moving to the injection port for injection. This can result in an extra move, crossing over the <i>x-y</i>-axes sensors, if the injection port is at the opposite end of the <i>x</i> axis relative to the sample location, (zero <i>x</i>-axis position in between sample location and injection port).</p> <p>For critical application fields (for example, clinical analyses), turn off the automated recovery; Stop XY Error= ON.</p>

**Table 44.** System items (Sheet 2 of 3)

Item	Description
<i>PlgPathCheck</i>	Monitors the plunger travel path to ensure that the plunger tip reaches the syringe zero point in all cases as compared to the original plunger referencing and defining the syringe zero point. If an error is detected, the PAL System stops. This feature is useful if: sample solutions with particles need to be handled, the syringe type is not adequate for the solution composition, or the syringe plunger is blocked or bent.
PlgChnge Pos	Changes a syringe using the Chnge Syr menu function and moves the plunger up to the position specified by this item. For normal use, accept the default values.
Init Syr at	<p>Initializes the syringe plunger at the Home or Waste position.</p> <p>If samples with a high danger of toxicity are treated, use the Waste position for referencing.</p>
Inj Signal	<p>An autosampler is the master instrument in a chromatographic system. The other components send a Ready signal to enable the autosampler to start. At the moment of injection, the PAL System sends a Start signal to the other components. The Inj Signal item defines the status when the signal is sent. The syringe is filled with the defined sample volume.</p> <p>PlgUp = The Start signal is sent at the moment the plunger starts moving down for injection.</p> <p>PlgDown = The Start signal is sent at the moment the plunger reaches zero point from syringe. (Recommended for large volume injection, but not in combination with Agilent Chemstation.)</p> <p>ValveSw = The Start signal is sent at the moment the injection valve is switched, HPLC technique.</p> <p>PreInj = Start signal sent at a time before injection, as with a sample preparation device started before a GC or LC system. Minus time relative to chromatographic start time.</p>

**Table 44.** System items (Sheet 3 of 3)

Item	Description
Vial PrePress	<p>Avoids a vacuum if a relatively large amount of sample is taken out of a small volume vial. If, for example, a volume of 50 µL is specified for injection, the PAL System first takes 50 µL of ambient air and injects this volume into the sealed vial, and causes overpressure in the vial. Then, the sample volume is aspirated without forming a vacuum. This functionality is only valid for liquid sampling, and not valid for the Headspace technique.</p> <p>Starting with PAL Firmware level 4.1.x, this item is also active in combination with Thermo PAL driver.</p>
LC-Inj	<p>The standard cycle for the HPLC technique. For details, see “DLW Cycle Step-By-Step” on page 96, and “PAL Firmware Overview” on page 191.</p>
LC-Cut	<p>The cycle for column switching with two valves for the HPLC technique. Control both valve drives through the AUX interfaces.</p> <p>For details, see “PAL Firmware Overview” on page 191.</p>
GC-Inj	<p>The standard cycle for the GC technique. For details, see “PAL Firmware Overview” on page 191.</p>
GC-InS	<p>The standard cycle for the GC Sandwich technique. For details, see “PAL Firmware Overview” on page 191.</p>
GC-Dual	<p>The cycle for the GC technique that allows the injection of two samples in two different injectors. The start signal is sent after both sample solutions are injected.</p> <p>For details, see “DLW Cycle Step-By-Step” on page 96 and “PAL Firmware Overview” on page 191.</p>
HS-Inj	<p>The standard cycle for the GC headspace technique. For details, see “DLW Cycle Step-By-Step” on page 96 and “PAL Firmware Overview” on page 191.</p>
SPME	<p>The standard cycle for the GC SPME technique, solid phase micro extraction, and fiber techniques. For details, see “PAL Firmware Overview” on page 191.</p>
TTS Sotax	<p>These two cycles are dedicated cycles for dissolution applications. The TTS cycle is used for transdermal patches and the Sotax cycle is used for tablet dissolution.</p>
<p>Items displayed in <i>italics</i> are available beginning with PAL Firmware level 4.1.x.</p>	

**Note** You can select and activate standard injection cycles directly from the Accela Open Autosampler. You must program any deviation from a standard cycle, such as a Cycle Composer Macro or Cycle Editor (ICC-CE) Cycle, for customized requirements.

**Note** In PAL Firmware levels < 4.0 the standard cycles are grouped in the Cycles item.

## Service

Select the particular item to change service settings.

**Table 45.** Service items (Sheet 1 of 2)

Item	Description
Check Motors	<p>Allows every stepper motor to be moved separately. This function is useful to check out a specific motor or to perform an endurance test after a repair.</p> <p>You can select the Start and Stop positions of the test path, as well as the motor Current, Speed, and Acceleration. You can specify a Pause time. A Cycle Limit and Actual Cycle Counter are useful tools for endurance tests.</p> <p>Phase A: Verifies the functionality of the stepper motor. Manually increase the current for tests. Use this item for troubleshooting only.</p> <p>Phase B: Verifies the functionality of the stepper motor. Manually increase the current for tests. Use for troubleshooting only.</p> <p>MicroStep Inx: Moves the motor within a range of up to four full steps by applying the assigned current.</p> <p>Warning: These items are typically used for service. If applied, do not leave the test settings for longer than a few minutes. Leaving the current setting in a critical range can damage the motor.</p>
Test Head	<p>Tests the functionality of the PAL injection unit (Head).</p> <p>Two tests are available by using the function keys:</p> <p>F1 Check Plg: Tests the stepper motor of the plunger drive. Performs a sensor check.</p> <p>F2 Check Z: Tests the vial detection sensor and Needle Guide Blocking function.</p> <p>These tests are only required when the Accela Open Autosampler operates erratically. In such cases, contact a Thermo Fisher Scientific representative.</p>

**Table 45.** Service items (Sheet 2 of 2)

Item	Description
Test Switches	<p>X-Limit = The actual status of the <i>x</i>-axis sensor. Moves the X-Y-Carriage manually across the limit switch to verify sensor activation.</p> <p>Y-Limit = The actual status of the <i>x</i>-axis sensor. Moves the <i>y</i> axis manually to the <i>y</i>-zero point (at <i>x</i> axis), crossing over the limit switch to verify sensor activation.</p> <p>Z-Limit = The actual status of the <i>z</i>-axis sensor. Moves the syringe slider assembly manually up to the zero <i>z</i>-axis point, crossing over the limit switch to verify sensor activation.</p> <p>Aux1 Limit = The actual status of Aux1 limit sensor.</p> <p>Aux2 Limit = The actual status of Aux2 limit sensor.</p> <p>Plg –Pos = The actual status of Plg–Pos.</p> <p>Needle Guide = The actual status of needle guide sensor.</p>

---

Items displayed in *italics* are available beginning with PAL Firmware level 4.1.x.


---

## Section F3-Setup/Objects

Use the Objects section opened in the Extended User mode to visualize new classes and known classes that might contain new items accessible only at the Extended User level.

To open this level, use the following path (see [Figure 112](#)).

**Figure 112.** Selecting Objects in Extended User mode



**Table 46.** Objects in the Extended User mode (Sheet 1 of 4)

<b>Object</b>	<b>Description</b>
Syringes	All loaded syringes are selectable. At the Utilities User Level only the active syringe is visible.
Vials	The Firmware Objects accessed on the PAL Extended User mode have more specific items selectable than at the User Level. Tolerances or ranges such as Maximum Penetration can be defined and limited for the user so that this value cannot be exceeded.
Tray Types	The object class Tray Type is only accessible via the PAL Extended User Level. All loaded Tray Types are visible and selectable.
Tray Holders	The Firmware Objects accessed on the PAL Extended User Level have more specific items selectable than at the User Level. Depending on the tray holder type, an Access and Restore Path or a Heater and Agitator (motor) is assigned.
Trays	All loaded trays are visible and accessible. A tray must be assigned to a tray holder. A TrayTypeGroup identification checks if the specified tray type is allowed in this combination.  The path offset $x, y, z$ is used only if a path is assigned to the specified tray holder. Typically a stack or agitator uses a path.
Wash Stations	The wash station and its positions, Wash1 and Wash2, are visible and selectable.
Injectors	The Firmware Objects accessed on the PAL Extended User mode have more specific items selectable than at the User Level. Tolerances or ranges such as Maximum Penetration can be defined and limited for the user so that this value cannot be exceeded.
Valves	The valves and valve drives connected and controlled by an AUX interface are listed in this Object class.  The valves controlled by serial communication (serial valves or multiposition valves) are in the PAL Firmware Object class Serial Valves.
Agitators	Items such as Motor Drive, Minimum Speed, and Maximum Speed are selectable for the Agitator Object. You can set the range for the speed. The other items are available directly as Method parameters.

**Table 46.** Objects in the Extended User mode (Sheet 2 of 4)

<b>Object</b>	<b>Description</b>
Dilutors	<p>The Firmware Objects accessed in the PAL Extended User mode have more specific items selectable than at the User Level. Tolerances or ranges such as Maximum Fill Speed can be defined and limited for the user so that this value cannot be exceeded.</p> <p>Items such as Prime Volume, Waste to, Motor Drives, or Scale Length are specific items that remain hidden at the User Level.</p>
Tools	<p>The object class Tools is used to handle another device, such as the MHE-Tool (Multiple Headspace Extraction Tool) or MALDI Tool.</p>
Positions	<p>The various positions used with the PAL System are selectable at this level. Positions such as Home, Change Syringe, or a Path Point, reference the Paths for a specified tray holder directly, such as Agitator or Stack.</p> <p>Selecting an item (for example, Home) enables the F1 function key and displays Check Pos on the screen. Activating this function provides the possibility of verifying <i>x</i>, <i>y</i>-, <i>z</i>-axes values for this particular position.</p>
Paths	<p>A Path defines specific movements for the injection unit, which represents a repetitive task assigned to a tray holder. Typical examples are opening and closing a drawer from a Stack or opening the lid of an Agitator.</p> <p>The Path is composed of several steps (points) that are added up in a sequence. Each individual step (point) can be positioned by teaching <i>x</i>, <i>y</i>, <i>z</i> axes. In most cases the return path is in the reverse order of the starting path, for example, AgiOpnL and AgiClsL. If one setting of a point is changed, this change is valid for the return path as well.</p>
Sync Signals	<p>At this level no other functionality, as shown at the User Level, is provided.</p>
Out Signals	<p>At this level no other functionality, as shown at the User Level, is provided.</p>
Events	<p>At this level no other functionality, as shown at the User Level, is provided. Three events are available at this Extended User Level:</p> <p>Pwr-Out1, Pwr-Out2, and FlushVlv. The main purpose of these power-out signals is to activate a solenoid, such as for the wash station or the gas flush valve. You can test the functionality of the signal at this level.</p>

**Table 46.** Objects in the Extended User mode (Sheet 3 of 4)

<b>Object</b>	<b>Description</b>
Serial Valves	Serial valves, or multiposition valve drives are powered and controlled by the serial (RS232) control and not through the AUX interface. Starting with firmware level 4.1.x, you can select a mode. The mode refers to the setting of the valve drive, whether the current for the motor is set to High Speed or High Torque.
Out Exp Box	The Out Expansion box provides 8 TTL contacts and 8 relay contacts (24 V contact closure). The optional module (box) is connected and controlled by Interface 2.
RS232	Use this object to select the serial ports for specific needs. The choices are:  Remote, Terminal, Printer, Barcode, ExtDev, VICI-Vlv (for serial valve drives), or None.

**Table 46.** Objects in the Extended User mode (Sheet 4 of 4)

Object	Description
<i>Motors</i>	<p>In the class Motors the object Motor-Y is accessible in order to select the items Strategy and Path Speed.</p> <p>Three different settings are selectable for the Y-Motor movement strategy:</p> <ul style="list-style-type: none"> <li>• <b>Rectang</b> = normal movement as used for PAL System. (On firmware level &lt; 4.1.x, this mode was called Auto.)</li> </ul> <p><i>XY-Simul</i> = <i>x</i>, <i>y</i> axes move simultaneously, which allow movement in a diagonal direction. (At firmware level &lt; 4.1.x this mode was called Rectang, but it was not active at lower levels.)</p> <ul style="list-style-type: none"> <li>• <b>Retract</b> = <i>y</i> axis moves from any point first to zero Y (back to the <i>x</i> axis) before the X-movement is started. This mode allows bypassing an object (such as a large GC detector), which might be in the travel path if using the default mode Rectang.</li> <li>• <b>Path Speed</b> = <i>y</i>-axis motor speed in conjunction with a Path, example: Opening and closing a drawer of a Stack. In certain situations you will need to slow down the speed to open and close a drawer. A typical application example is fraction collection, collecting directly into a well plate. If the liquid level is high, the liquid can wash over into the next row if drawer movement is too fast.</li> </ul> <p>Remark: At PAL Firmware level 4.1.x, these items of the Y motor have been made available at the Extended User Level.</p> <hr/> <p>Items displayed in <i>italics</i> are available beginning with PAL Firmware level 4.1.x. Items displayed in <b>bold</b> are explained in detail below.</p>

## Tray Type

You may change the following object, Tray Type Items, by selecting the particular item. First select the desired Tray Type, such as **VT32-20**.

**Table 47.** Tray type items (Sheet 1 of 4)

Item	Description
Row Length X	Defines the Row length in the X-direction from the center of the first to the center of the last vial position, measured in mm.
Row Length Y	Defines the Row length in the Y-direction from the center of the first to the center of the last vial position, measured in mm.

**Table 47.** Tray type items (Sheet 2 of 4)

<b>Item</b>	<b>Description</b>
Col Length X	Defines the Column length in the X-direction from the center of the first to the center of the last vial position, measured in mm.
Col Length Y	Defines the Column length in the Y-direction from the center of the first to the center of the last vial position, measured in mm.
Spl Per Row	Number of samples per Row.
Spl Per Col	Number of samples per Column.
<i>Pattern</i>	<p>The pattern of the Row or Column arrangement has to be defined.</p> <ul style="list-style-type: none"> <li>• Regular = square arrangement (standard)</li> <li>• Staggrd+ = Rows are arranged in a staggered pattern. Offset of second Row is shifted by +50% of hole pattern.</li> <li>• Staggrd- = Rows are arranged in staggered pattern. Offset of second Row is shifted by -50% of hole pattern.</li> </ul>
TrayTypeGroup	Software protection so that not every tray type can be placed on any tray holder. Example: You cannot fit VT32-20 into a Stack.
Plate Thickn	Thickness of tray plate bottom (not the total height of the tray). Measured in mm.
Vial Height	<p>Total height of the vial including cap to seal if applicable. Measured in mm.</p> <p>Remark: The sum of the plate thickness and vial height adds up to the total height This is the point where the injection unit expects an object.</p>
Vial Trnsprt	<p>The mode to transport a vial is defined by:</p> <ul style="list-style-type: none"> <li>• <b>None</b> = No transport required. Example liquid sampling.</li> <li>• <b>Magnet</b> = Magnetic Transport. Requires magnetic vial caps. The injection unit moves to the side to slide the vial off when moved away.</li> <li>• <b>Needle</b> = Device is transported with the syringe needle inserted. Example: special vials where a magnetic cap cannot be crimped, for example, Vacutainer.</li> </ul> <p>Remark: This item became active beginning with PAL Firmware level 2.5.x.</p>

**Table 47.** Tray type items (Sheet 3 of 4)

<b>Item</b>	<b>Description</b>
<i>ZSlideOffRetr</i>	If magnetic transport is selected, the distance can be defined to move the syringe slider up (Z-direction), lifting up the vial by magnetic force. Measured in mm.
<i>YSlideOffDist</i>	If magnetic transport is selected, the distance can be defined to move the injection unit to the side, Y-direction, to slide the vial off. Measured in mm.
Barcode	If a Barcode Reader is installed, the mode has to be set for <b>AutoFix</b> .  <b>None</b> = No Barcode Reader option requested for this tray type.
Z Tolerance	A tolerance window to give a plus/minus range (expressed in mm) where the injection unit must expect an object.  If the value of this item is > 0, this is a relative detection mode and the sensor from the injection unit needle guide is active.  If the value of this item is set to 0 the sensor of the needle guide is turned off and the syringe slider moves to an absolute value, z-axis position as specified in the object.
Z Retract	The distance to lift up the syringe slider before the y-, z-axes assembly moves across the unit can be specified, expressed in mm.
Max Penetr	The maximum allowed Needle Penetration can be defined as a safety so that the user cannot destroy the needle tip by going too far down.  The tray type is prepared for a specific vial size; this value is therefore unique to this combination. The maximum needle penetration must not exceed the length of the syringe needle, considering the loss due to the needle guide, and so on. Typical needle length is 51 mm, and maximum penetration must not exceed 48 mm.
Needle Penetr	This item is identical to that used on the User Level or, if available, as a method parameter of a local cycle. The value defined on these levels is mirrored to the Extended User Level.
Spl1 Offset X	The X offset is defined as the distance from the outer edge of the tray in the X-direction to the center of the vial position 1. Measured in mm.
Spl1 Offset Y	The Y offset is defined as the distance from the outer edge of the tray in Y-direction to the center of the vial position 1. Measured in mm.

**Table 47.** Tray type items (Sheet 4 of 4)

Item	Description
Spl1 Offset Z	The Z offset can be selected for special cases where, for example, the syringe needle has to reach a deeper point before penetration into a vial. A Z offset value = 0 considers the tray surface or vial top as the reference point. Measured in mm.

Items displayed in *italics* are available beginning with PAL Firmware level 4.1.x.


**Note** The dimensions used for Row/Column Length or X-, Y-, Z-Offsets for Sample Number 1, are specific for a particular tray type. If you must make a general adjustment for a tray from a specific vendor—for example, for a Deepwell Plate, you should do it in the Tray Type class of Object. For fine tuning, you can use the Offset items from the class Trays.

### Explanation for Various Patterns in Tray Type

- Pattern Type, Regular

The sample or well positions are equally distributed.


**Figure 113.** Pattern tray type of Regular



- Pattern Type, Staggrd+.

The sample or well positions are arranged in a staggered pattern. Offset of second Row is shifted by + 50% of hole pattern.


**Figure 114.** Pattern tray type -of Staggered+



- Pattern Type, Staggrd-

The sample or well positions are arranged in a staggered pattern. Offset of second Row is shifted by  $-50\%$  of the hole pattern.

**Figure 115.** Pattern tray type of Staggered-



## Trays

You can change the following object Tray Items by selecting the particular item. First select the desired tray, such as **Tray1**.

**Table 48.** Tray items (Sheet 1 of 2)

Item	Description
Tray Holder	Specifies the tray holder that the tray is assigned to.
TrayTypeGroup	Displays all tray type groups that are allowed for this particular combination of tray and tray holder. The TrayTypeGroup for the tray type itself is specified for each tray type.
Tray Type	Links the tray type to be used to the tray. This item is usually set at the User Level in Utilities/Trays.
Offset X	<p>The X offset is defined as the distance from the center of the teaching position from the tray holder to the edge of the tray in X-direction. Measured in mm.</p> <p>This item is available at the User Level in the section, Utilities/Tray, and can be used for fine tuning a tray installed in a tray holder. Important for well-plates 384 installed in a Stack.</p> <p>Remark: Position#1 is the only correction point.</p>
Offset Y	<p>The Y offset is defined as the distance from the center of the teaching position from the tray holder to the edge of the tray in Y-direction. Measured in mm.</p> <p>This item is available at the User Level in the section, Utilities/Tray, and can be used for fine tuning a tray installed in a tray holder. Important for well-plates 384 installed in a Stack.</p> <p>Remark: Position#1 is the only correction point.</p>
Offset Z	<p>The Z offset is defined as the distance from the plate surface of the tray holder to the teaching point, the black needle guide that is flush underneath the tray holder plate (which corresponds to the tray holder plate thickness). Measured in mm.</p> <p>This item is available at the User Level in the section, Utilities/Tray, and can be used for fine tuning a tray installed in a tray holder. Important for well-plates 384 installed in a Stack.</p> <p>Remark: Position#1 is the only correction point.</p>
Path Offset X	<p>The Path Offset X can be specific for a tray, adjustment in X-direction. Expressed in mm.</p> <p>Remark: This item is only valid if a path is assigned to the tray holder as specified in this combination.</p>

**Table 48.** Tray items (Sheet 2 of 2)

<b>Item</b>	<b>Description</b>
Path Offset Y	The Path Offset Y can be specific for a tray, adjustment in Y-direction. Expressed in mm.  Remark: This item is only valid if a path is assigned to the tray holder as specified in this combination.
Path Offset Z	The Path Offset Z can be specific for a tray, adjustment in Z-direction. Expressed in mm.  Remark: This item is only valid if a path is assigned to the tray holder as specified in this combination.
<i>dxRow</i>	Correction for inclination of a tray in X-row direction. For details, see Section 4.2.3.2 above.
<i>dYRow</i>	Correction for inclination of a tray in Y-row direction. For details, see Section 4.2.3.2 above.
<i>dzRow</i>	Correction for inclination of a tray in Z-row direction. For details, see Section F, “Description and Installation,” point 4.2.3.2 above.
<i>dxCol</i>	Correction for inclination of a tray in X-column direction. For details, see Section F, “Description and Installation,” point 4.2.3.2 above.
<i>dyCol</i>	Correction for inclination of a tray in Y-column direction. For details, see Section F, “Description and Installation,” point 4.2.3.2 above.
<i>dzCol</i>	Correction for inclination of a tray in Z-column direction.
Items displayed in <i>italics</i> are available beginning with PAL Firmware level 4.1.x.	

## Wash Stations

You can change the following object Wash Station items by selecting the particular item. First select the desired wash station, such as **Wash1**.

**Table 49.** Wash station items (Sheet 1 of 3)

<b>Item</b>	<b>Description</b>
Position X	<i>x</i> -axis position for the wash station
Position Y	<i>y</i> -axis position for the wash station
Position Z	<i>z</i> -axis position for the wash station

**Table 49.** Wash station items (Sheet 2 of 3)

Item	Description
Z Tolerance	<p>A tolerance window for a plus/minus range (expressed in mm) where the injection unit has to expect an object.</p> <p>If the value of this item is &gt; 0, a relative detection mode occurs and the sensor from the injection unit needle guide is active.</p> <p>If the value of this item is set to 0, the sensor of the needle guide is turned off and the syringe slider moves to an absolute value, <i>z</i>-axis position as specified in the object.</p>
Z Retract	Specifies the distance to lift up the syringe slider before the <i>y</i> -, <i>z</i> -axes assembly moves across the unit, expressed in mm.
Max Penetrat	<p>Defines the maximum allowed Needle Penetration as a safety so that the user cannot destroy the needle tip by going too far down.</p> <p>The maximum needle penetration must not exceed the length of the syringe needle, considering the loss due to the needle guide and so on. Typical needle length is 51 mm; maximum penetration must not exceed 48 mm.</p>
Needle Penetr	This item is identical to that at the User Level. The value defined at this level is mirrored in the Extended User Level.
Type	<p>The specific mode for the wash station in use has to be defined:</p> <ul style="list-style-type: none"> <li>• <b>Standard</b> = Standard wash station. Syringe is filled with wash solvent and expelled into Waste.</li> <li>• <b>Pulse</b> = A pulsed signal is sent to activate the device. Used for the fast wash station and active wash station.</li> <li>• <b>Flow</b> = Continuous flow of liquid by gravity. No electrical contact required for a solenoid.</li> <li>• <b>DLW</b> = Dynamic Load and Wash. Item used to activate specific solenoid for DLW Wash Station.</li> </ul>
Flow Control	Specifies the power source to activate a wash station. Uses the Event Power-Out1 and Power-Out2 for the Fast, Active wash station and DLW.
Ndl Cln Path	To assign a path to the wash station.
Waste to	To assign the Waste position to the wash station.
Clean Volume	Defines a percentage of the syringe maximum volume for the cleaning step.


**Table 49.** Wash station items (Sheet 3 of 3)

<b>Item</b>	<b>Description</b>
Clean Count	The counter monitors the number of wash cycles. The setting in the method has the same functionality and the value is mirrored in the Extended User Level.
Max Fill Spd	Defines the fill speed for the syringe. If the maximum value of the Fill Speed (10.0 mL/s) is selected, the system takes the injection syringe Fill Speed as defined in the method.
Max Eject Spd	<p>The Eject Speed is the speed used to eject the wash solvent during the wash cycle. This speed is usually higher than the Fill Speed.</p> <p>If the maximum value of the Eject Speed (10.0 mL/s) is selected, the system takes the injection syringe Eject Speed as defined in the object class Syringe.</p>
Rinse Time	<p>The time to rinse the wash port with wash solvent after the wash cycle of the syringe is finished.</p> <p>In the case of a fast/active wash station, the syringe needle is pulled out of the wash port. The wash solvent flows without restriction. As a result, you must consider higher solvent consumption.</p>
Items displayed in <i>italics</i> are available beginning with PAL Firmware level 4.1.x.	

# PAL Firmware Overview

Figure 116. PAL Firmware Overview, Page 1

## Firmware Overview




**Notes:**  
Plunger Stroke and Valve Switch Counter  
Menu/Info/Maintenance

The standard software does not include every Object as shown in the overview.  
The layout depends on the hardware configuration for each individual PAL-System

Revision H / Firmware 4.0.X / June 2009


**Figure 117.** PAL Firmware Overview, Page 2



**Note:**  
The standard software does not include every Object as shown in the overview.  
The layout depends on the hardware configuration for each individual PAL System

Revision H / Firmware 4.0X / June 2009

**Figure 118.** PAL Firmware Overview, page 3



PAL is a registered trademark of CTC Analytics AG | Switzerland

**Figure 119.** PAL Firmware Overview, Page 4

Method Cycle	Recommended PAL Method Parameters	Method Cycle	Recommended PAL Method Parameters	Remarks
<b>LC-Inj</b>		<b>LC-Cut</b>		
CYCLE	LC - Inj	CYCLE	LC - Cut	
SYRINGE	100 µl	SYRINGE	100 µl	
Sample Volume	80 µl	Sample Volume	80 µl	
Air Volume	0 nl	Air Volume	0 nl	
Pre Cln Slv1	1	Pre Cln Slv1	1	
Pre Cln Slv2	0	Pre Cln Slv2	0	
Pre Cln Spl	2	Pre Cln Spl	2	
Fill Speed	10 µl/s	Fill Speed	5 µl/s	
Fill Strokes	3	Fill Strokes	3	
Pullup Del	3-10 s	Pullup Del	3-10 s	
Inject to	LC Vlv 1	Inject to	LC Vlv 1	
Inject Speed	10 µl/s	Inject Speed	5 µl/s	
Pre Inj Del	500 ms	Pre Inj Del	500 ms	
Pst Inj Del	500 ms	Pst Inj Del	500 ms	
Pst Cln Slv1	2	SplTransfDel	Sample Transfer Delay	Time needed to transfer sample from Loop onto 2nd valve (pre - or analytical column)
Pst Cln Slv2	0	Pst Cln Slv1	2	
Vlv Cln Slv1	2	Pst Cln Slv2	0	
Vlv Cln Slv2	0	Vlv Cln Slv1	2	
		Vlv Cln Slv2	0	
		Cut Valve	LC Vlv 2	Specify name of 2nd valve, switching valve
		Cut Delay		Time needed for clean-up. Switch to backflush sample, to analytical column or detector
		MinCondTime		Minimum Conditioning Time: Time needed to condition pre - column on 2nd valve

Example for the following conditions:

- Loop Size 20 µl, overfill 3 - 5 times  
Partial Loop filling: Allowed sample volume range: 20 - 60% of loop content for loops ≤ 100 µl  
Larger Loops: 20 - 80% of loop content
- Syringe:  
Syr X G100 - 225 - 3: Gauge 225 limits fill speed to max 20 µl/s (5-20 µl/s depends on viscosity of solvent)  
Syr X G100 - 22 - 3: Gauge 22 allows fill speed up to 200 µl/s (depends on viscosity of solvent)
- Eject speed for 100 µl Syringe: 50 to 150 µl/s (Utilities/Syringe)
- Pre - and post Washing:  
Use Solvent 1 and 2 for samples with components of extremely different polarities.  
Samples containing proteins should not contact organic solvents.
- Wash Steps for biological samples:  
1st Wash Cycle: Aqueous solvent  
2nd Wash Cycle: Organic solvent  
1st Wash Cycle before next sample:  
Pre-wash with aqueous solvent (eliminate organic solvents in Syringe and Valve)

LC-Cut Cycle controls 2 valves.  
LC Valve 1: Injection valve with loop.  
LC Valve 2: Switching valve.  
- Example 1: Pre - column for sample clean-up, backflushing to analytical column. Cut Delay > 0.  
- Example 2: 10 - port valve with 2 analytical columns. Loading column 1, condition column 2.  
Valve toggle after Cycle time. Loading column 2, condition column 1. Cut Delay = 0

Part No.: PAL\_FirmOverTCH

## PAL Firmware Error Codes

Table 50 lists PAL firmware error codes for firmware version 4.1.x.

**Table 50.** PAL firmware error codes (Sheet 1 of 7)

Error code number	Error message
0	Okay = No Error
1	FPGA not present error
2	FPGA configuration error
3	External Event is INPUT only
4	Items list is full
5	Duplicate Object Name found

**Table 50.** PAL firmware error codes (Sheet 2 of 7)

<b>Error code number</b>	<b>Error message</b>
6	Table String is empty
7	Table String Index is invalid
8	Table String is too long
9	Object list is full
10	Invalid Terminal Firmware
11	Object Name not found
12	Real Time Clock bad Data read
13	Number to String Conversion Error
14	String to Number Conversion Error
15	Object Level too deep
16	Too many Items per Object
17	Item Name not found
18	Axis Position Error
19	Module Trigger not valid
20	Module CRC not valid
21	MenuProc Index out of Range
22	MenuProc Address contains NIL Pointer
23	FuncProc Address contains NIL Pointer
24	Invalid Function Key
25	Invalid MenuTable Index
26	MenuTable Pointer contains NIL
27	Invalid Object Focus in GetItemPtr
28	Invalid Item Focus in GetItemPtr
29	Invalid Select String Array Index
30	Unknown Select Array
31	Invalid Select String Index
32	Requested Select String is empty
33	Select String is too long
34	Invalid Batch Name
35	Object is not on expected Position
36	A200S Protocol non Decimal Digit Received

**Table 50.** PAL firmware error codes (Sheet 3 of 7)

<b>Error code number</b>	<b>Error message</b>
37	A200S Protocol invalid Termination Character
38	Unknown Object Class
39	No Index found for requested SSL_String
40	Command Value out of Range
41	Parameter Value out of Range
42	HostComm Parser found Invalid Keyword
43	Invalid StrToNum Conversion
44	Parser missing Parameters
45	Invalid Character in Numeric Parameter
46	Parameter Value out of Range
47	Invalid Baud rate Selected
48	PAL Status is < > PAL_IDLE
49	Invalid Sample Number From Remote
50	Answer Count Plunger Move Detection not valid
51	Invalid Plunger Move Detection Parameter
52	Answer Count Needle Magnet not valid
53	Invalid Needle Magnet Parameter
54	Answer Count Head Tool ID not valid
55	Invalid Head Tool Parameter
56	Answer Count Head Board Revision Level invalid
57	Invalid Head Board Revision Level Parameter
58	Answer Count Heater Power Count Invalid
59	Invalid Heater Power Parameter
60	Load Firmware not successful
61	RS232 Communication Parameter Error
62	RS232 Channel already Open
63	RS232 Channel not Open
64	RS232 Channel Timeout While Reading/Writing
65	RS232 Parity Error
66	RS232 Framing Error
67	RS232 Overrun Error

**Table 50.** PAL firmware error codes (Sheet 4 of 7)

<b>Error code number</b>	<b>Error message</b>
68	RS232 RX fifo overflow
69	No serial Channel defined for requested Function
70	Unknown Data Type detected
71	Unknown Item Element detected
72	Unknown Temp Channel
73	Unknown RPM Channel
74	Temperature out of Range
75	Invalid Cycle Detected
76	Answer Count Heater GetRawTemp invalid
77	Invalid Heater GetRawTemp Parameter
78	Parenthesis "(" expected
79	Parenthesis ")" expected
80	Current is too high
81	Speed is too high
82	Acceleration is too high
83	Target position is below low_limit_steps
84	Target position is above high_limit_steps
85	No Syringe Found
86	Syringe Volume out of Range
87	Tray Index out of Range
88	Not Appropriate Object Class
89	Temperature is out of Heater Limits
90	Motor Axis Target Position Error
91	Motor Current Fault Phase A
92	Motor Current Fault Phase B
93	Motor Current Fault Both Phases
94	PAL is in PAL_ERROR Status
95	Syringe ID Mismatches
96	Timeout when waiting for answer
97	Answer to big, buffer overflow
98	Timeout during send, SW error

**Table 50.** PAL firmware error codes (Sheet 5 of 7)

<b>Error code number</b>	<b>Error message</b>
99	Checksum error in received frame
100	Wrong toggle bit in rx frame
101	Invalid procedure parameter >127
102	Could not load head firmware
103	Motion Fault
104	Unknown Atom
105	Not Implemented
106	Object Name is too long, max. 8 Characters
107	Object Named 'None' requested
108	No Syringe installed
109	Invalid SoftTimer
110	SoftTimer Timeout occurred
111	ReportLog Index out of Bounds
112	Invalid Vial Transport mode
113	Invalid Barcode mode
114	Memory Full
115	Found No Vial
116	Address Error detected
117	Bus Error detected
118	Zero Division detected
119	Spurious Interrupt detected
120	Format Error and uninitialized Interrupt
121	Input Voltage below trip point
122	Unknown Motor
123	Temperature Sensor failed
124	Valve Position Error
125	Restricted Object Class
126	Heaters are not supported by this Hardware
127	Invalid Host Frame State detected
128	Invalid Host Sequence Number detected
129	Invalid Host Frame Data detected

**Table 50.** PAL firmware error codes (Sheet 6 of 7)

<b>Error code number</b>	<b>Error message</b>
130	Host Frame ETX Expected
131	Is Not a Hexadecimal Digit
132	Invalid Host Frame Length detected
133	Invalid Host Checksum detected
134	Unexpected STX detected
135	Unexpected ETX detected
136	Unexpected Character detected
137	Needle Guide not Released
138	Wrong Dilutor Syringe inserted
139	Axis stuck on Limit Switch
140	Axis could not detect Limit Switch
141	Axis Low Limit Error
142	Axis High Limit Error
143	Axis Target Position Error
144	Motor Current fault
145	Time Table Full
146	No Tray found at this position
147	z-Axis Collision Error
148	Mandatory Parameter Missing
149	Invalid Vici Valve Drive
150	Invalid Vici Valve Position
151	Invalid Vici Valve Status
152	Aux Motors are not supported by this Hardware
153	OutExpBox is currently disabled
154	Output currently used by OutExpBox
155	Invalid Dilutor Motor Status
156	Serial Valves are currently disabled
157	Serial Valve Communication Error
158	Invalid Object Name
159	Invalid Tray Type Group
160	Invalid manual syringe selection


**Table 50.** PAL firmware error codes (Sheet 7 of 7)

Error code number	Error message
161	Stop on XY Position Error
162	Object used by other object
163	Plunger Position Error Detected
164	Duplicate syringe ID found
165	Washstation is not of type DLW
-1	Unknown Exception received


## External Connectors for Accela Open Autosampler

This section contains information about external connectors for the Accela Open Autosampler.


### Connector SER1

Pin	Signal name
	
1	NC
2	RXD
3	TXD
4	DTR bridged with Pin7; Special grounding, do not alter.
5	GND
6	NC
7	RTS bridged with Pin 4; do not alter.
8	NC
9	NC


### Connector TERMINAL or SER3

Pin	Signal name
	
1	GND
2	RXD
3	TXD
4	NC
5	NC
6	+5V
7	NC
8	GND


### Connector SER2

Pin	Signal name
	
1	GND
2	RXD
3	TXD
4	NC
5	NC
6	+5V
7	NC
8	GND


### Connector INTERFACE 1

Pin	Signal name
	
1	Pwr-Out1 +
2	Pwr-Out2 +
3	SW-Out1 NO
4	SW-Out1 COM
5	SW-Out2 NO
6	Opto-In1 +
7	TTL-In1
8	GND
9	Pwr-Out1 -
10	Pwr-Out2 -
11	TTL-In2
12	SW-Out2 COM
13	TTL-In3
14	Opto-In1 -
15	+5V


## Connector INTERFACE 2

Pin	Signal name
	
1	TTL-In1
2	TTL-In2
3	TTL-In3
4	TTL-Out1
5	TTL-Out2
6	TTL-Out3
7	Opto-In1 +
8	Opto-In2 +
9	SW-Out1 NO
10	SW-Out2 NO
11	Pwr-Out1 +
12	Pwr-Out2 +
13	+5V
14-19	GND
20	Opto-In1 –
21	Opto-In2 –
22	SW-Out1 COM
23	SW-Out2 COM
24	Pwr-Out1 –
25	Pwr-Out2 -


### Connector AUX1

Pin	Signal name
	
1,2	Motor A1
3,4	Motor B1
6	Temp +
7	Sens
8,9	Heater
11,12	Motor A2
13,14	Motor B2
16	Temp -
17	+5V
15,18,19	GND
20,10	36V


### Connector AUX2

Pin	Signal name
	
1,2	Motor A1
3,4	Motor B1
6	Temp +
7	Sens
8,9	Heater
11,12	Motor A2
13,14	Motor B2
16	Temp -
17	+5V
15,18,19	GND
20,10	36V


### Connector wash station

Pin	Signal name
	
1	PWR – Out1+
2	PWR – Out1-
3	PWR – Out2+
4	PWR – Out2-


### Connector Power

Pin	Signal name
	
1	+36 V
2	GND
3	NC

### Connector MODBUS

Pin	Signal name
	
1	TXD
2 – 7	+36 V
8	RXD
9 – 14	GND

## Connector LAN

Pin	Signal name	DIR	Primary function
			
1	TX+	Out	Transmit Data +
2	TX-	Out	Transmit Data -
3	RX+	In	Receive Data +
4, 5	Not used		Terminated
6	RX-	In	Transmit Data -
7, 8	Not used		Terminated

## Connector Fuse

Fuse type	Description
Fuse Type	FST 5x20
Rating	6.3A
Rated Voltage	250 VAC

## System Limitations

This section contains information about system limitations.

### Accela Open Autosampler

You can operate the DLW Option only with an Accela Open Autosampler, which requires PAL Firmware level 4.1.x and the APR Control-xt board.

### Sample Volume

The current version of the DLW Option can handle sample volumes from 2 to 100 µL.

### Wetted Parts and Material

Some components are not compatible with certain solvents or chemicals that are used in given applications.

## Tubing Internal Diameter (ID) and System Backpressure

Any tubing and component in the flow path, such as an injection valve, will contribute to the system backpressure. For example, short tubing with an 0.13 mm (0.005 in.) ID can build up high backpressure when using standard wash pump flow rates.

The wash solvent pumps operate in the range of mL/min. Such a flow rate in combination with a high system backpressure, caused by small ID tubing, will slow down the pump and, as a result, the flow rate.

The described situation is only critical if you select an HPLC setup dedicated for nano flow.


## Interfacing the Open Autosampler to Other Devices

This section contains information about interfacing the Open Autosampler to other devices.

### Synchronization and Output Signals

Synchronization Signals (**Sync Signals**) are inputs that tell the Accela Open Autosampler when to wait or proceed with a sample-processing step. Output Signals (**Out Signals**) are sent from the PAL to external devices to indicate status or completion of particular processing steps. These signals are classified as Objects. Physical Events (for example, TTL-In1) are also Objects and may be assigned to named signals. PAL Cycles require that certain signals, such as **Start**, **Inject**, and **Injected**, be defined. For the PAL Events and signal assignments associated with the standard PAL **LC-Inj** and **LC-Cut** cycles, see [Table 51](#).

Certain types of integration of the PAL System into data handling or control software, such as ChemStation, Xcalibur, Galaxie or Chromeleon, accomplish synchronization of the Ready/Start signal directly via software control (RS232/LAN).



To assign a physical Event (for example, SW-Out 1) to an existing signal Object (**Injected**), complete the following menu selections:


The Accela Open Autosampler is shipped with all cycle events predefined, as shown in [Table 51](#). If you need a different physical signal, then you must assign a new Event to the Object signal.

For a signal to be ignored, its corresponding Event must be set to Immediate.

**Table 51.** PAL Events and signal assignments for the standard PAL LC-Inj and LC-Cut cycles

Standard assignment for Open Autosampler injection cycles		Description	Default events	INTERFACE1 pin #
Start JobQueue	(Sync Signal)	Start a Job Queue (Job). Prerequisite is a defined Job with a method assigned. Useful for automated, unattended, timed sampling.	Immediate	
Start	(Sync Signal)	Start a cycle (Input from GC or data system)	Immediate	
Start2	(Sync Signal)	Continue the cycle GC-Dual for the second sample	Immediate (Ignore)	
Inject	(Sync Signal)	Inject READY to INJECT	Immediate (Ignore)	
Inject2	(Sync Signal)	Inject the second sample for GC-Dual cycle	TTL1 Interface pin7, pin8 (GND)	
Injected	(Out Signal)	Activated at the moment the sample has been injected	SW-Out1	3 4
Injected2	(Out Signal)	Activated at the moment the second sample has been injected	SW-Out2 Interface pin5, pin12	
Running	(Out Signal)	Active as long as the Job Queue is being processed and the PAL is not in an error state	Off	

If you assign an item of the class **Sync Signal** to an output signal, such as **TTL-In1**, then you must define this TTL contact as either **Active High** or **Active Low**, as expected by the HPLC system. This is defined in the PAL Firmware class **Events**.



Select the corresponding item and set the mode accordingly.

If you ordered a dedicated cable, the setting is provided with the schematic description of the LC Sync Cable.

An LC Sync Cable is supplied, which has the PAL Interface 1 connector mounted. The HPLC system side has a 25-pin connector for 600 pump and 1250 pump, and a 2-wire connector for the detectors.



# PAL Loader

This chapter describes how to use the PAL Loader software version 2.5.0 (or later).

## Contents

- [Introduction](#)
- [New Features of PAL Loader Software 2.1.x](#)
- [Installation of PAL Loader Software](#)
- [Multiple Shortcuts Assignment](#)
- [PAL Loader Software Operation](#)
- [Troubleshooting](#)
- [Limitations](#)

## Introduction

The purpose of the PAL Loader software is to create a backup file for the complete Accela Open Autosampler firmware. The core software (firmware) and all PAL Firmware Objects, including all settings (Items), local methods, and jobs, are saved as one file.

The PAL Loader software has a second function of loading the firmware or a complete backup file to the Accela Open Autosampler. The PAL Loader application has always been part of the Accela Open Autosampler.

The following PAL Loader software versions are in use:

- PAL Loader version 1.0.1
- PAL Loader version 1.1.1

A new PAL Loader software, version 2.1.0 or later, has been developed for the Accela Open Autosampler.

The Accela Open Autosampler requires PAL Firmware 4.1.x or later, which calls for the new PAL Loader software.

The new PAL Loader software version 2.1.0 (or later) is backwards compatible. The software can be used for all PAL Firmware levels.

The name of the \*.exe file has been changed intentionally to avoid conflicts when old and new versions are installed on the same computer:

PAL Loader version 1.1.1: PALLOAD.exe  
PAL Firmware level up to and including 3.x.x.

PAL Loader version 2.1.x: Setup PALloader.exe  
PAL Firmware level as of 4.1.x or later  
but backwards compatible with lower levels.

## New Features of PAL Loader Software 2.1.x

The following features, new since version 1.1.1, are available in the new PAL Loader software:

- The installation software is executable directly from a CD-ROM or any transportable storage device, such as a memory stick.
- The software installation procedure is different from that of Loader version 1.1.1. If they do not already exist, directories are created in the Microsoft™ User Profile.
- The read/write speed for a file is significantly higher. The initial COM Port settings, such as the baud rate, are identical to previous versions. The baud rate is adjusted dynamically during program startup and is displayed on the status line, in the lower right corner of the application window.
- You can create multiple shortcuts and for each one assign a dedicated IP or COM address. This setup facilitates the handling of a number of PAL Systems from a single computer.

## Installation of PAL Loader Software

This section contains information about installing the PAL Loader software.

### Requirements

PAL Loader software version 2.1.x requires Windows 2000, XP, or Vista™. It does not support lower Windows versions, such as Windows 95, 98, or NT. If installation is necessary in this environment, use PAL Loader version 1.1.1.

Software communication from a PC to the PAL System can be done one of two ways:

(Serial control, requiring a serial cable provided with the PAL System, crossed wiring)

- P/N 00950-01-00332 (cable length 3 m, standard cable)
- or–
- PN: 00950-01-00333 (cable length 6 m, optional cable length)

## PAL Loader Software Version 2.1.x Installation

The software is provided with every PAL-xt System, with an enclosed CD-ROM.


The PAL Loader .exe file is embedded in a wizard software package. Starting the wizard will execute the installation software. If no changes are made to the proposed installation path, the Loader version 2.1.x uses the following default installation path to install the software:

*drive:\Program Files\PAL Loader*

**Note** You can start the wizard for the installation software by double-clicking the icon of the file Setup PALloader.exe.

You can use the second file, PALloader.msi, for the installation as well. Double-click the icon of the file, right-click, and choose **Install** from the shortcut menu. This path for installation requires an up-to-date Windows Installer. If the current version is not installed, a corresponding error message appears.

**Figure 120.** Installation path for the PAL Loader software




The two subfolders Backup and Update are automatically created at installation in this directory:

*drive:\Users\Public\Public Documents\PAL\Loader*

The directory allows writing temporary files, with no write protection and, in a network environment, the User Profile is always provided to the user at logon.


**Figure 121.** Installation path for public documents



A Loader INI file is created at installation and stored in this directory:

*drive:\ProgramData\PAL\Loader*

**Figure 122.** Installation path for PAL Loader INI file



Note that the folder ProgrammData can be hidden if a standard installation of the Windows Operating system is executed.


## Multiple Shortcuts Assignment

The PAL Loader version 2.1.x or later provides for the handling of multiple shortcuts on the desktop; each one can be assigned to a specific TCP/IP address or COM port. A mix of the two communication protocols is possible as well.

This setup facilitates the handling of a number of PAL Systems from a single computer.

You can create a shortcut of the PALloader.exe file to the desktop. After you create the shortcut, right-click the shortcut icon and choose **Properties** from the shortcut menu. See [Figure 123](#).

**Figure 123.** Shortcut Properties dialog box



The Target command line uses the installation path of the PAL Loader software:

*drive:\Program Files\PAL\Loader\PALloader.exe*

**Tip** Create a shortcut from the data application file located in the above described path (in Explorer) and not from the PAL Loader desktop icon.

## Dedicated Shortcut for Serial Communication

Add this extension to the command line:

`... .exe /CommunicationType=0 /ComPort=x`


See [Figure 124](#).

Where:

- Type=0: Serial Communication Protocol
- x= Com Port Number

**Tip** Insert a blank space after **...exe** followed by a slash (“/”, not a backslash), then **...Typ=0**, and another slash, “/”.

**Figure 124.** Extending target command for serial communication




## Creating Multiple Shortcuts

You can use the same procedure as described in the previous section to create and save several shortcuts on the desktop.

For each shortcut icon, right-click and choose **Rename** from the shortcut menu to define a unique name. [Figure 125](#) shows an example of two LAN shortcut icons with IP address 20 and 21 as well as two serial shortcut icons with COM port numbers 1 and 3.

Double-clicking the icon opens the PAL Loader software with the assigned communication protocol and address (port).

**Figure 125.** Example of multiple shortcuts



If several PAL Loader applications are open, as shown in [Figure 125](#), and you close them successively, the address of the last closed application is written back to the Loader INI file.

Reopening any of the PAL Loader applications with a dedicated communication protocol and address (port) will use the specified setting and overwrite the INI-file settings.

## PAL Loader Software Operation

This section contains information about how to operate the PAL Loader software.

### Starting the PAL Loader Software

Click the PAL Loader icon located on the desktop.


**Figure 126.** PAL Loader software icon



The application opens and displays the various user buttons (Figure 127).

The previously used communication mode is displayed in the status bar.

**Figure 127.** PAL Loader application buttons



## Setting up COM Ports


Clicking the Setup button opens the dialog box to select serial communication (Figure 128).

The COM Port is user selectable. The message displays the number of COM ports detected.

**Note** The limitation of PAL Loader software version 1.1.1—that only ports COM1 to COM4 can be addressed—has been eliminated in version 2.1.x.

Also, COM ports do not need to be in consecutive order.

**Figure 128.** Setup dialog box for Serial Communication



## COM Port Settings


The port settings are normally defined in the following:

Windows\Control Panel\Device Manager\Ports

The standard settings for serial communication are shown in [Figure 129](#).

**Note** The application (PAL Loader software) actively sets the communication parameters, and the baud rate is set for optimized use.

**Figure 129.** COM1 Properties dialog box – Port Settings page




## Serial Communication

This section contains information about serial communication.


### Establishing Serial Communication

To quickly check whether serial communication with the PAL System can be established, click **Info**.

**Figure 130.** Clicking the Info button



**Figure 131.** PAL information received



When the PAL Loader application receives information from the Accela Open Autosampler, the red LED on the back of the electronic board blinks. This blinking LED indicates that the processor is in so-called Loader Mode, which means that the processor enables receiving the firmware or writing to memory. For more details, see [LED Status and Position](#).

**Note** The Target Information list displays the version levels of the different components of the Accela Open Autosampler.

The various types of information received might be important for troubleshooting. For example, if the line for the PAL Firmware release is not shown, the firmware is most likely corrupt.

## LED Status and Position

The following are the various states for the LED indicator on the Open Autosampler:

- **Turned off:** The autosampler is in normal operating mode.
- **Blinking or flashing:** The autosampler is prepared in Loader Mode to create a backup or update—that is, to receive data from, or write to, memory.
- **Constantly on:** Data transfer process is in progress.

The position of the LED in the APR Control-xt board is between the buzzer and the connector for the wash station.

## Explanation for the Communication Protocol Settings

**Table 52.** Accela Open Autosampler communication parameters

Parameter	Explanation	Remarks
CommPort	Setup for serial (SER1) or LAN communication	If serial communication is selected, all other parameters in PAL-xt Firmware, Communication class, are ignored.

## Reset PAL-xt to Serial Communication

If the PAL-xt communication is set to LAN and for any reason the PAL Firmware became corrupt, you can reset or force back the communication protocol to Serial by using the button, Reset PAL to Serial Comm, in the Setup dialog box of the PAL Loader (see [Figure 128](#) on [page 218](#)).

## Backing Up the PAL Firmware

**Note** Perform the following backup procedure after completing installation of a new PAL System. In addition, periodic system backups ensure that a PAL updated configuration file (PAL Firmware backup) is available at any time.

**Note** Do not move any part of the PAL System, such as the *y-z*-axis assembly and, if possible, do not use other computer functionality during the backup and update process. This will cause delays and might freeze the window.


### ❖ To create a backup file

1. Shut off power to the PAL System.
2. Connect the cable corresponding to the communication mode.
  - Serial cable (RS232) between PAL SER1 and PC Serial port (COM)

PN: 00950-01-00332 (standard cable provided with PAL System) or  
PN: 00950-01-00333 (optional, cable length 6 m)

3. Switch on the PAL System power.
4. Double-click the **PAL Loader** icon. The PAL Loader startup window appears.

**Figure 132.** PAL Loader icon and startup window



5. Click **Backup**. The Backup Target Memory dialog box opens (Figure 133).

The path (storage location) and the file name to be assigned to the new backup file appear.


You may customize the path, file name, or both.

Default file name: BKdate.sss (date: YYMMDD)

**Note** You can also use the Info button to establish and check communication with the PAL System using the PAL Loader software.

If you cannot establish communication with the PAL System, see “[Troubleshooting](#)” on page 137.


**Figure 133.** Starting the backup process with serial communication type



**Note** The displayed baud rate in this example of 38400 is the baud rate last used. Do not confuse this with the COM port setting, which is a baud rate of 9600. The application optimizes the speed, depending on work load and processor capabilities. The dynamic increase in the baud rate can reach as high as 115 200. The last used baud rate writes back to the PAL Loader INI file. Opening this window from the PAL Loader application displays this last used rate.

6. Activate the process by clicking **Start Backup** (Figure 134). The process is initialized and takes approximately 3–5 minutes.

**Figure 134.** Backup process for serial communication completed



A backup file is created, the RAM and flash memory are backed up, and the newly created file is closed. After the process is complete, the message: Backup of target memory successful is displayed.

7. If you receive the message: Backup of target memory not successful, repeat the last step and check the communication by using the Info button.

## Updating the PAL Firmware

**Note** Do not move any part of the Accela Open Autosampler, such as the *x* axis, and if possible do not use other computer functions during the backup and update process. This will delay the process and might freeze the application.


Use the following procedure to upgrade the PAL Firmware to another level. Keep in mind that the existing firmware data, such as parameter settings or methods, is overwritten or lost. This is especially important for users who work directly from their local terminal and create methods and jobs within the PAL System. In such cases, ensure that the methods are saved before starting an update procedure.

**Note** Best practice dictates creating a backup file as described above before performing an update of the PAL Firmware. This backup file is for backup purposes only. If an important point is overlooked, recovery is possible by reloading the backup file onto the Accela Open Autosampler.

❖ **To create an update file**

1. Shut off power to the Accela Open Autosampler.
2. Connect the cable corresponding to the communication mode:
  - Serial Cable (RS232) between PAL SER1 and PC Serial port (COM)  
PN: 00950-01-00332 (standard cable provided with PAL System) or  
PN: 00950-01-00333 (optional, cable length 6 m)
3. Double-click the **PAL Loader** icon. The PAL Loader startup window appears. The previously used communication mode is displayed in the status box.


**Figure 135.** PAL Loader icon and startup window



4. Click **Update**. The Update Flash Memory dialog box opens (Figure 136).
5. Browse to the appropriate file (extension \*.sss) to upgrade the PAL Firmware.

**Note** To establish and check communication from the Accela Open Autosampler using the PAL Loader software, you can also use the Info button. If communication with the Accela Open Autosampler cannot be established, refer to “[Troubleshooting](#)” on [page 137](#).


**Figure 136.** Starting the update process with a serial communication type



**Note** The displayed baud rate in this example of 38400 is the last used baud rate. Do not confuse this with the COM port setting, which is a baud rate of 9600. The application optimizes the speed, depending on work load and capabilities of the processor. The dynamic increase of the baud rate can reach as high as 115 200. The last used baud rate writes back to the PAL Loader INI file. Opening the PAL Loader window displays this last used rate.


- In PAL Loader software version 2.1.x, load or activate a file (with extension \*.sss) by dragging it to the window.

**Figure 137.** Drop a file into the Update window



- Activate the process by clicking **Start Update**. The process is initialized and takes approximately 3–5 minutes.

**Figure 138.** Update process for serial communication completed



The RAM and flash memories are erased and replaced by the new data. When the process is complete, this message appears: Update finished (from the task bar).

If there is a problem, a message similar to the following appears: Programming target memory failed at 0x000A2D00.

The Update log entry memory failed #####.

You can try repeating the last step, using the following options:

- Retry with old file.
- Load new file.

You might check the communication by using the Info button.

## Troubleshooting

This section contains information about troubleshooting the PLW Loader software.

### Serial Communication with PAL Loader Software

**Note** You can use PAL Loader software version 2.1.x for the PAL System. It is backwards compatible with PAL Systems.

If you cannot establish serial communication with the PAL Loader software version 2.1.x, check the following points:

- Is the COM port on the PC available and correctly addressed?  
Are default settings verified?

- Is the PAL Loader software COM port setting correct?

If no RS232 (serial) port is available on the computer, use a USB/Serial converter. Use the type recommended by CTC Analytics: PNo.: USB-Ser2.

The PAL RS232 cable has a crossed wiring connection.

PN: 00950-01-00332 (3 m length, standard cable) or

PN: 00950-01-00333 (6 m length, optional cable)

## How to Force Loader Mode Manually

If basic conditions are met but you still cannot establish communication from the PC to the Accela Open Autosampler, you must force the PAL System into so-called Loader mode.

This action might be necessary if the PAL Firmware has been partially corrupted.

### ❖ To force the Loader Mode manually

1. Turn off the power from the PAL System.
2. Turn on the power again.
3. Turn off the power from the PAL System within a time window of approximately 3 to 5 seconds again (turn it off before the startup logo is displayed on the screen).
4. Turn on the power again.

Successful activation of the Loader Mode is indicated by the blinking red LED at the back of the PAL *x* axis.

There are two blinking patterns for the LAN and COM (serial) modes for the Control-xt board only. The LAN mode exhibits a fast, double-blinking signal, whereas the COM (serial) mode shows a pattern with one blinking signal at a constant time interval. See a visual representation of the patterns in [Figure 139](#).

**Figure 139.** LED flashing pattern for LAN and COM modes



Double blinking - LAN Mode



Single blinking - COM (Serial) Mode

Location of LED:

- For PAL Systems, APR CPU or APR Control boards:  
LED is beside the DC connector.
- For the PAL-xt System, APR Control-xt board:  
LED is between the buzzer and wash station.

## Reset PAL to Serial Communication

If the PAL-xt communication protocol is set to the LAN type, it is possible that the link between the PAL-xt software and the PAL-xt System can no longer be established. One cause for such a failure is a corrupt PAL Firmware.


Under these circumstances, you must be able to execute an “emergency” command. This function is set in the PAL Loader software Setup dialog box using the Reset PAL to Serial Comm button.

### How to Reset the PAL to Serial Communication

#### ❖ To reset the PAL to serial communication


1. Start the PAL Loader application (version 2.1.x or later) by double-clicking the corresponding icon.
2. Click **Setup** and change the Communication Type from the TCP/IP to the **Serial Communication** option.

**Figure 140.** Activating Setup for resetting the PAL-xt




If the Communication Type is not set to Serial, an error message appears (see [Figure 141](#)).

**Figure 141.** Preparing to reset the PAL-xt




3. After selecting the Serial Communication Type option, click **Reset PAL to Serial Comm.**

**Figure 142.** Activating Reset PAL to Serial Communication




A confirmation box opens (see [Figure 143](#)).

**Figure 143.** Confirmation for the reset process



4. Click **Yes** to continue the reset process. A second window appears with instructions to manually turn off and on the power of the PAL-xt System (see [Figure 144](#)).

**Figure 144.** Instructions to force the PAL-xt System into Loader Mode



5. Click **Cancel**.

After successful activation of the Loader Mode, the communication type changes automatically to Serial Communication. A beep tone signals the completion of the reset procedure.

The PAL-xt System is now prepared to perform a PAL Firmware update.

## Erratic Behavior of Software or Flash Memory

In some rare cases the red LED might continue to blink after a PAL Firmware update. You cannot start the PAL System from the PAL Loader Start PAL button or by powering it off/on. If such a case occurs, take the following steps:

1. Power down and wait at least 30 seconds before the unit is powered up again. If the PAL System is not restored, go to the next step.
2. Reload a complete PAL Firmware backup file. A complete backup file means core software including all PAL Firmware Objects data, content of RAM, and flash memory.  
 If this action is still unsuccessful, go to the next step.
3. Power down the unit again and remove the board (APR CPU, APR Control, or APR Control -xt). Before you handle an individual board, be careful of static charge.
4. Connect the DC cable, the spiral cable for the terminal, and either the Serial or Ethernet cable to the board on-the-fly.
5. Start the software UPDATE process again.
6. If none of these actions is successful, change the board.

Any severe error requiring changing the board typically means that the Loader section of the flash memory can no longer be addressed, which results in communication failure.

**Note** A PCB, APR CPU, APR Control, or APR Control-xt, which has not been connected to current for a period of six months or longer, can result in a low battery level. Because a low battery will no longer support the RAM memory, data loss is likely.

7. Charge the battery overnight (36 V), and reload a complete PAL Firmware backup file (core software and PAL Firmware Objects).

## Failure to Complete BACKUP or UPDATE Process

Avoid touching the PAL System during the read or write processes (BACKUP or UPDATE). Do not move, for example, the  $y$ -,  $z$ -axis assembly during a process. This will delay its completion and could result in an error message and stopping the process completely.

Furthermore, the window can freeze (shown in a frozen progress bar). This might also happen if the computer processor is very busy with other tasks at the same time. Try to avoid using any other computer function during the process.

## Limitations

Known limitations to consider for troubleshooting purposes relate to the Windows operating system. The PAL Loader software version 2.1.x is compatible with the following systems only:

- XP Professional (Service Pack 2)
- Vista Enterprise (Service Pack 1)
- Windows 7 beta build 7000, preliminary tests fulfilled

# Installing and Using the PAL Object Manager Software

Read this chapter to install, set up, and use the PAL Object Manager software. This chapter is intended for frequent Accela Open Autosampler users or new users who are experienced at configuring and using automated systems to run existing analytical methods. Before using the PAL Object Manager, make sure you have properly installed and set up the Accela Open Autosampler using the instructions in “[Installing the Accela Open Autosampler](#)” on [page 11](#).

## Contents

- [Installing PAL Object Manager](#)
- [Getting Started with PAL Object Manager](#)

**IMPORTANT** Before using the PAL Object Manager software to make changes to your system, back up the current system definition using the PAL Loader software. If problems occur while using the PAL Object Manager software, repair the system using PAL Loader to restore the back up configuration file. See “[PAL Loader](#)” on [page 211](#).

Because this software can change your system to the point that the autosampler and Thermo PAL does not function properly, make changes to objects only if you are an advanced user and understand how the changes you make can impair system functioning.

Thermo Fisher has defined the hardware and software configuration for your autosampler. Changes to this configuration can impact system functioning.

When you add a new hardware module to the Accela Open Autosampler, use the PAL Object Manager software to load new PAL firmware objects onto the system to support those modules. The Object Manager mode also helps create and maintain object lists from an existing Accela Open Autosampler.

After adding an object to the Accela Open Autosampler, choose **Restart Pal** from the File menu to start the system so other software applications can use the object.

The latest PAL Object Manager software is backwards compatible. You can use the software with all PAL firmware levels.

## Installing PAL Object Manager

Installing PAL Object Manager software requires three steps.

- [Verifying System Requirements](#)
- [Installing the Object Manager Software to the Local Hard Drive](#)
- [Installing the PAL Object Lists](#)

## Verifying System Requirements

Before installing the PAL Object Manager software, your system must meet these requirements.

**Table 53.** System requirements for PAL Object Manager

System	Requirements
Software	<p>PAL Object Manager software is compatible with these Windows operating systems:</p> <ul style="list-style-type: none"><li>• Microsoft™ Windows™ 2000</li><li>• Microsoft™ XP Professional (Service Pack 2)</li><li>• Microsoft™ Vista™ Enterprise (Service Pack 1)</li><li>• Windows™ 7 beta build 7000, preliminary tests fulfilled.</li></ul>
Hardware	<p>For serial control communication from the computer to Accela Open Autosampler, use one of these crossed-wiring serial cables provided with the Accela Open Autosampler:</p> <ul style="list-style-type: none"><li>• P/N 00950-01-00332 (cable length, 3 meters)</li><li>• P/N 00950-01-00333 (cable length, 6 meters)</li></ul> <p>If the desktop or laptop computer has no serial port (COM port) installed, use a conversion adapter USB/Serial.</p>

## Installing the Object Manager Software to the Local Hard Drive

The PAL firmware objects are grouped in various folders that must be linked to the Object Manager software. To avoid any conflicts with the link, load the software to your local hard drive before copying the object folders.

You must have administrative rights to install the software.

### ❖ To install the Object Manager software to the local hard drive

1. Put the Object Manager CD in your computer.
2. To start the installation, double-click the PAL Object Manager setup.exe file.

The installation wizard begins installing the software.

3. If there is no change to the proposed installation path, install the software to the default location:

C:\Program Files\PAL\Object Manager

## Installing the PAL Object Lists

After installing the Object Manager software, install the PAL Object Lists folder. This folder contains all PAL firmware object lists in alphabetical order by class, for example, syringes, trays, and wash stations.

Install the PAL object lists folder in the same directory as the PAL Object Manager software.

### ❖ To install the PAL Object Lists folder

1. Find the Pal Object Lists folder on the CD.
2. Copy the folder and paste it into the same folder on your hard drive where the PAL Object Manager resides. The default location is C:\Program Files\PAL\Object Manager.

## Getting Started with PAL Object Manager

This section describes how to get started with PAL Object Manager software.

- [Setting Up the Communication Mode](#)
- [Troubleshooting the Serial Communication Mode](#)
- [Using PAL Object Manager to Change Your System Configuration](#)

### Setting Up the Communication Mode

Use the File menu in the PAL Object Manager window to set the communication mode.


#### ❖ To set up the communication mode

1. Choose **File > Options > Communication** or **Object List folder** to open the Select Communication Type dialog box.



2. Select the **Serial** option.

**Figure 145.** Select Serial communication



3. Select the Serial Port drop down box and choose the COM port to use for communication. Available COM ports are listed in the drop down list.

4. Click **OK** to set the serial communication.

If no error message appears, the communication with the Accela Open Autosampler has been established. The Status Bar displays this message:

Connected on COM $N$

where  $N$  is the number of the COM port.

## Troubleshooting the Serial Communication Mode

PAL Object Manager software version 2.1.0. can address only COM port numbers 1 to 4. The ports must be consecutive. If you connect to one port and do not establish serial communications, connect to another port. Accela Open Autosampler

This limitation has been eliminated with PAL Object Manager software version 2.2.x.

If you cannot establish serial communication with the PAL Object Manager software, check the following questions:

- Has the original RS232 cable been used, as provided with Accela Open Autosampler? (The PAL RS232 cable has a crossed wiring connection.)  
P/N 00950-01-00332 (3 m length) or P/N 00950-01-00333 (6 m length).
- Is the COM port on the PC available and correctly addressed?
- Are default settings verified?
- Is the COM port setting in the PAL Object Manager software correct?

If not, the following message is displayed:

**Figure 146.** Wrong COM Port selected



These types of problems are seen mostly when a USB/Serial port is used to overcome the lack of a serial interface, as in today's laptop computers.

**Note** These two limitations surrounding the COM port setting are valid for the previous Object Manager software, Version 2.1.0. With the release of the new Version 2.2.x these problems are eliminated. The software scans for the available COM ports, the error message as shown in [Figure 146](#) is no longer displayed.

If no RS232 (serial) port is available on the computer, use a USB/Serial converter.

## Using PAL Object Manager to Change Your System Configuration


This section describes how to change your system configuration using the PAL Object Manager.

- [Starting the PAL Object Manager Application](#)
- [Using the Object Manager Application](#)

### Starting the PAL Object Manager Application

❖ **To start the PAL Object Manager application**

1. From the desktop, click the **PAL Object Manager** icon (  ).



The application opens and displays the various user buttons. The main part of the application shows the Object List folder pane with the current Object Lists folder.

All objects must correspond with the proper version of the firmware as identified by Thermo Scientific. For example, for objects using 4.x.x firmware, valid revisions are A, B, or C. For objects using a previous version of the software, use revision K.

The status bar displays the previously used communication mode.

2. To see the version information, choose **Help > About**.

The software displays the Object Manager software version.



## Using the Object Manager Application

The main purpose of the PAL Object Manager software is to load PAL firmware object lists on a system that has added a hardware module. To add an object list, follow this procedure, which describes adding a syringe object to an existing Accela Open Autosampler.

You can only add certain objects to your system. Be sure you know the impact of an object before adding it to the system.

Ensure that the Accela Open Autosampler is set up properly, the PAL Object Manager software is installed, and the communication is established as shown in “[Setting Up the Communication Mode](#)” on [page 236](#).


### ❖ To add an object list to an existing Accela Open Autosampler

1. In the Object List folder pane, click the **Syringes** folder.
2. Double-click the subfolder containing syringe firmware to open up the list of various available LC syringes.
3. In the Object List, select a specific syringe to highlight it.
4. Hold the cursor on the object list item to reveal information about the object.

This information provides the title and an explanation of the selected object.

The Loaded Objects area lists the objects that are loaded with one action. In this example it is a single object, but with other examples, such as a stack cooler, the situation is more complex (see [Figure 147](#)). Four tray types, a tray holder (CStack1) and six trays (01-06) are sent to the Accela Open Autosampler in one package.

**Figure 147.** Object list stack cooler 1 example



Review the information to make sure that the correct object list has been selected and to understand what is included in this list. For example, you need to know whether all necessary tray types for the application are included or if you must specifically select another type and send it to the Accela Open Autosampler as a second task.

5. Click **Send to Accela Open Autosampler** to read the Accela Open Autosampler configuration and send the selected objects to the Accela Open Autosampler.

The configuration file is temporarily stored in the computer memory.

After the file has been sent successfully to the Accela Open Autosampler, the message “xx objects received” is displayed in the status bar, providing feedback from the Accela Open Autosampler to the Object Manager application.

In the example using the LC syringe, 25  $\mu$ L, the Object Manager software might send two objects in a single file. In this case, the first object contains the geometric definition of the syringe itself and the second object specifies which plunger motor driver is assigned to this particular syringe.

The same concept is used to send the desired objects to the Accela Open Autosampler for all other object lists.

The Object Manager always lists the object being sent in the last line of the PAL firmware class, visible from the local terminal. The Object Manager software can quickly check whether the PAL firmware has received the new object.

In some cases—seen in particular in the PAL but not in the PAL-xt System—you might receive an error message: Memory full. To resolve this problem, you must delete as many objects as possible from the Accela Open Autosampler that you are not using. You can link a syringe to a method and a job. First delete the job, then the method, and finally the syringe object. See [“To delete objects”](#) on [page 240](#) for information about deleting objects.

Confirm your understanding of the Object List parameters and descriptions to make sure that the correct, desired objects are sent to the PAL firmware. In certain cases where complexity is greater—for example, multi-position valve drives—the guideline provides the correct order of steps in the process to provide reliable functioning of the Accela Open Autosampler.

### ❖ To delete objects

1. Use the Accela Open Autosampler handheld device to delete objects.

In the handheld device, objects are displayed as a tree. Identify the object and delete it according to instructions in [“Operating the Accela Open Autosampler”](#) on [page 65](#).

To delete multi-object items, delete the lowest items first and then remove higher objects until you delete the top-level object.

# Index

## Symbols

235

## A

Accela Open Autosampler  
 adapter cable for detector 42  
 assembling 14  
 components 1  
 electrical connections 35  
 error messages 137  
 external connectors 200  
 firmware overview 191  
 installing 11  
 interconnect cable 39  
 maintenance 165  
 naming convention 171  
 object positions 49  
 operating 65  
 operating and environmental requirements 9  
 physical specifications 8  
 replacement parts 153  
 sound pressure level 9  
 specifications 6  
 system limitations 206  
 unpacking components 21  
 using control terminal 65

## B

backing up PAL firmware, PAL Loader 221

## C

cables  
 Accela Open Autosampler system interconnect cable 39  
 Accela Pump adapter cable 46  
 detector adapter cable 42  
 communication mode  
 setting up for PAL Object Manager software 236  
 compliance  
 FCC iii

regulatory iii  
 WEEE v  
 control terminal  
 function keys 67  
 illustration 66  
 menu screens 66  
 using 65  
 Cycle 169  
 cycle composer macros 85  
 cycle composer macros or ICC cycles, installing 85  
 Cycle Editor 85

## D

DLW  
 Actuator/Solenoid 28  
 characterizing features 3  
 cycle 96  
 cycle for fast injection 118  
 cycle for standard injection 96  
 fast injection cycle 91  
 Flow Diverter 12  
 functionality 94  
 Holding Loop 12–13  
 macro definitions 85  
 manifold 28  
 needle guide length tool 12–13  
 operating 93  
 overview 3  
 Plunger Holder 12–13  
 Pump Module 12–13  
 replacement 153  
 spare parts ordering information 155  
 standard injection cycle 88  
 Syringe 12, 29  
 Syringe Holder assembly 12–13  
 Syringe Needle 12–13  
 Tubing Kit 12–13  
 DLW Actuator/Solenoid 94  
 DLW pump module, replacing 154  
 DLW Pumps 94

## Index: E

- DLW replacing parts
  - syringe 154
  - syringe holder assembly 154
  - wash station 154
- DLW Syringe Holder Assembly, installing 28
- DLW Wash Station
  - Injection Valve plumbing and connection 34
  - installing 26
- DLW-2
  - spare parts ordering information 159
- DLW-2, components 13
- DLW-2, definition 4
- Dynamic Load and Wash (DLW) 3

## E

- electromagnetic compatibility iv
- EMC compliance iii
- Extended User Mode, accessing 172
- external connectors, Accela Open Autosampler 200

## F

- Fast Wash Station for two different solvents 2
- FCC compliance iii
- firmware
  - error codes 194
  - overview 191
- flow path, injection valve 60

## I

- ICC cycles 85
- info functions 78
  - free objects/free items 80
  - hardware 79
  - maintenance 79
  - software 79
- Injection Unit 2
  - installing 18
  - ribbon cable 20
- injection unit 11
- injection valve
  - flow path 60
  - Valco W-Type 6-Port 62
- installing the PAL Object Manager software 235
- introduction, Object Manager Application 239

## J

- Job 169
- Job queue 169
- job queue 69

- building and starting 70
- cancelling 71

## K

- keypad terminal 2, 11
- keypad terminal, installing 22

## L

- LC injection valve, installing 23
- logfile 78

## M

- Method 170
- Method parameters 170
- methods 67
  - creating 67
  - deleting 69
  - editing and viewing 68
- Module 170
- MSQ Plus MS detector
  - Accela Open Autosampler system interconnect cable connection 40, 43

## O

- Object class 170
- Object Item 170
- Object list 170
- Object Manager 170
- object positions, descriptions 51
- Objects 170
- Open Autosampler components 1
- ordering information, DLW spare parts 155
- ordering information, DLW-2 spare parts 159

## P

- PAL Firmware, updating 223
- PAL Loader 211
  - backing up PAL Firmware 221
  - dedicated shortcut for serial communication 215
  - installing 212
  - multiple shortcuts assignment 214
  - new features 212
  - operating 217
  - reset PAL-xt to serial communication 221
  - serial communication 219
  - setting up COM ports 218
  - starting 217
- PAL Object Lists folder
  - installing for PAL Object Manager software 235

- PAL Object Manager Software [239](#)
- PAL Object Manager software
  - backing up your system configuration [233](#)
- port settings
  - choose COM port for PAL Object Manager software [236](#)
  - troubleshooting for PAL Object Manager software [237](#)
- power supply, installing [23](#)
- pump holder, mounting [24](#)
- pumps, self-priming [3](#)

## R

- reference points
  - injection valve [57](#)
  - Wash Station [55](#)
  - waste [56](#)
- regulatory compliance [iii](#)
- resetting PAL-xt to serial communication, PAL Loader [221](#)

## S

- safety guard [2, 11](#)
- safety standards [iii](#)
- self-priming micro pumps [3](#)
- serial communication, PAL Loader [219](#)
- setting up COM parts, PAL Loader [218](#)
- setting up LAN communication, PAL Loader [221](#)
- setup functions
  - objects [82](#)
  - selecting [80](#)
  - sounds [81](#)
  - time [81](#)
- solvent lines, priming [93](#)
- Stack [171](#)
- Stack Cooler
  - condensation build-up [134](#)
  - temperature alarm [133](#)
  - temperature control [132](#)
  - temperature setting [131](#)
  - temperature stability [133](#)
- stand-alone supports [11](#)
- standard chromatographic tests [148](#)
- standard liquid syringe holders [28](#)
- standard stand-alone supports [2](#)
- starting, PAL Object Manager Application [238](#)
- syringe kit [2, 11](#)
- system components, Accela Open Autosampler [2](#)
- system requirements
  - PAL Object Manager software [234](#)

## T

- Thermo PAL driver for Xcalibur [85](#)
- Torx driver [20](#)
- Tray [171](#)
- tray [2](#)
  - holder [52](#)
  - position [52](#)
  - rows and columns [53](#)
- Tray holder [171](#)
- Tray Type
  - pattern explanation [185](#)
- Tray type [171](#)
- troubleshooting
  - Accela Open Autosampler [137](#)
  - PAL Loader [226](#)
  - special considerations [142](#)

## U

- updating PAL firmware, PAL Loader [223](#)
- utility functions [71](#)
  - dilutors [76](#)
  - injector [74](#)
  - syringe [72](#)
  - tools [77](#)
  - tray [73](#)
  - vial [76](#)
  - wash station [75](#)

## V

- Valve Needle Guide Assembly, installing [34](#)
- valve penetration value, defining [58](#)

## W

- Wash Station assembly [11](#)
- Wash Station reference point [55](#)
- WEEE compliance [v](#)

## X

- x-, y-axes assembly [2](#)

## Z

- z-axis [2](#)

