

Thermo Scientific
iPort Software Version 01.04.02

RELEASE NOTES

Version 01.04.02 changes relative to version 01.04.01:

1. Change help format from old "HLP" type to newer "CHM" for use on newer versions of Windows.
2. Added ability to handle port numbers for TCP/IP communications.
3. Addressed issue in DDE functionality related to the response of the instrument to the "program no" command.
4. Fixed issue where entire application hangs on initialization due to obsolete font file handling.

Version 01.04.01 changes relative to version 01.03.02:

1. Add capability to download filter records from the 2000i/2000iD/2025i/2025iD family.
2. Safety features added to prevent loading of cramfs images onto iSeries units and loading of bin images onto iSeries+ units.

Version 01.03.02 changes relative to version 01.03.00:

1. Fixes to handling of TCPIP responses from instruments for both ASCII and binary data. Improved error handling and messaging in cases where TCPIP communication is interrupted.
2. Fixed Y2K and divide-by-zero issues in record downloading and graphing of incoming data.
3. Handling added for iSeries+ .cramfs program files.