

Thermo Scientific

pDR Port Software Version 02.00.03

OVERVIEW

The pDR Port communication software is for use with the pDR1500 and the ADR1500.

INSTALLATION INSTRUCTIONS

Insert the CD-ROM or storage device containing the pDR Port installation to the computer and locate the file 'pDRPort020003setup.exe' and run it (double-click).

- 1) At the 'Welcome' message box, choose 'Next'.
- 2) At the 'Destination Folder' message box, either browse to the desired folder or accept the folder offered (recommended). Choose 'Next'
- 3) At the 'Ready to Install' message box, choose 'Install'.
- 4) Installation of the 'Silicon Laboratories CP210x VCP Driver' is offered. This is required for USB connection.
 - a. Select "Install a new instance of this application and click 'Next'.
 - b. At the "Silicon Labs: Welcome to the..." box, click 'Next'.
 - c. At the "License Agreement" [EULA], select 'I agree...' and click 'Next'
 - d. Browse or accept directory offered. If unsure, accept. Click 'Next'.
 - e. At the 'Ready to install' box, click 'Install'.
 - f. ****IMPORTANT**** At the 'Install Complete' box, be sure the "Launch the CP210x VCP Driver Installer" item is checked and click 'Finish'

*** NOTE: If Step 4-f was not completed, locate "CP210xVCPInstaller.exe" on the computer's hard drive and run it.

- 5) At the 'Program Group' message box, assign a folder or accept the folder offered (recommended) and click 'OK'.
- 6) Double-click on the pDR Port Icon in the folder showing or locate the 'pDR Port' in the 'Program menu' in Windows ("start", "All programs").
- 7) For instructions on how to use this software, from the top menu of "pDR Port", select "Help", "Contents".

RELEASE NOTES

Version 02.00.03 changes relative to version 02.00.02:

1. Add option in Configure instrument > Configure Setup Parameters > Units to now include mg/m³ (milligrams per cubic meter) units.

Version 02.00.02 changes relative to version 02.00.01:

1. Fixed issue when downloading tags over 70.
2. Revised help file to improve Windows 7 and 8.1 compatibility.
3. Removed link to the manual.