The Thermo Fisher Scientific EPD-N2 combines excellent photon dosimetry with full-spectrum neutron response, making this dosimeter ideal for those working in mixed neutron/gamma fields.

EPD[™]-N2

Electronic Personal Gamma-Neutron Dosimeter

Applications include:

- Reactors
- Spent fuel and glass waste transport
- Reprocessing and plutonium finishing
- MOX plants
- Neutron source manufacture
- Many types of nuclear and university research
- Accelerator facilities
- Medical facilities



- Advanced radiological performance, 20keV-10MeV (photon), thermal (0.025eV) - 15MeV (neutron)
- Excellent performance in mixed gamma/neutron fields
- Multi-detector technology
- Excellent performance for low-dose measurements
- Direct display of Hp(10) for neutrons and for photons
- Outstanding immunity to electromagnetic interference
- AA battery, lithium or alkaline, interchangeable
- Compatible with current or upgradeable Thermo Scientific EPD readers, software and accessories



Radiological

- Sensitive to X- and γ-radiation (E > 20keV) and neutrons 0,025eV < E < 15MeV
- Direct readout of Hp(10) for neutron & photon dose
- Multiple diode detectors with converters and energy compensation shields
- Display units: Sv & rem (with prefixes µ, m), set

via internal software

- Generally in accordance with ANSI standards 13.11, 13.27 & 42.20 (photons performance) and most aspects of IEC 61525 (neutrons & photons)


 $0\mu Sv$ to > 16Sv, auto-ranging Dose display & storage: - Resolution for display: $1\mu Sv$ (< 10mSv/1rem) (γ , and neutron under best conditions)

- Resolution for storage: $1/64\mu Sv$ (~1.5 μ rem) (γ), $1\mu Sv$ for neutron

dose under best conditions

- Dose rate display: $0\mu Sv/h$ to > 4Sv/h (400rem/h).

auto-ranging, variable resolution



Electrical & Mechanical

- Power supply: 1 x AA battery, 1.5V alkaline or 3.6V

lithium, interchangeable without any

adjustment

- Operating life (see assumptions below)

Continuous use: 1.5V alkaline: typically 42 days

3.6V lithium: 4.5 - 5 months

8h/24 with use of 'OFF' standby state:

1.5V alkaline: ~ 2.5 months 3.6V lithium: ~ 9 months

Assumptions: average dose rate < 5uSv/h

(<0.5mrem/h), IR communications < 5s, 2x/day, audible alarm sounding <2h total

during battery life

- Communications: IR interface, < 1m range (39")

- Display and enabled functions controlled by button on front face of

EPD (button recessed and sealed)

86 x 63 x 18.5 mm, without clip, - Size:

(approx 3.4 x 2.5 x .75")

- Weight:: 108 g (~4oz) incl. battery & clip

- Case material: high impact polycarbonate blend

- Clip: high impact plastic, easily renewed, strong clamp, with eyelets for lanyard

(optional lanyard-only version)

± 20% 25keV to 1.5MeV Energy response (γ):

> ± 30% 20keV to 6MeV ± 50% 6MeV to 10MeV

- Energy response (n): see energy response curve above

> With a single calibration, the neutron dose estimated by the EPD-N2 will be within approximately ± 30% of the true

value for many workplace fields

 $Hp(10) (\gamma) \pm 20\%$ up to $\pm 75^{\circ}$ Cs-137 - Angular response: $Hp(10) (n) \pm 30\% \text{ up to } \pm 60^{\circ} \text{ Am-Be}$

- Internal detector self -test under CPU control

- Accuracy: Hp(10) (γ) 10% Cs-137

Hp(10) (n) 20% Am-Be

Alarms

- Audible & visual alarms: Photon dose rate (2), photon dose,

combined photon + neutron dose, neutron dose rate, neutron dose, over-range, failure, count - down timer, low battery, 'return for read'. Alarm tone, pattern, sound level,

mutability and red LED configurable via

external software

- 'Beep' for gamma dose with configurable sensitivity

- Alarm sounder: sealed, typically 98-100 dB(A) @ 20cm

on 4kHz 'loud'setting

Memory

- 10 year data retention without battery
- Short term and Total dose registers for Hp(10) γ & n
- Storage of peak photon & neutron dose rates, with date & time (1s resolution for all stored times)
- 23 most recent alarms or events stored with date & time
- Dose profile storage: \sim 500 dose data points for γ & neutron dose with date & time

Environmental

- Operating temperature:

-10 °C to 40 °C (15 to 105 °F)

- Storage temperature:

-25 °C to 70 °C (-13 to 158 °F)

- Humidity:

20% - 90% RH, non-condensing

- Protection rating:

IP55 (protection against dust ingress &

low pressure jets of water from all

directions)

- Vibration: IEC 1283 (2 g, 15 min., 10-33 Hz)

- Shock: 1.5 m drop onto concrete on each

surface

- EMI/EMC:

Exceeds MIL STD 461D RS103;

IEC 1283 & IEC 61525

©2007 Thermo Fisher Scientific Inc. All rights reserved. Kapton is a registered trademark of of E.I. du Pont de Nemours and Company. All other trademarks are the property of Thermo Fisher Scientific Inc. and its subsidiaries. Results may vary under different operating conditions. Specifications, terms and pricing are subject to change. Not all products are available in all countries. Please consult your local sales representatives for details. Literature Code LITEPD N2 0407

Frauenauracher Strasse 96 +49 (0) 9131 909-0 +49 (0) 9131 909-205 fax D 91056 Erlangen, Germany

United Kingdom

Bath Road, Beenham, Reading RG7 5PR United Kingdom +44 (0) 118 971 2121 +44 (0) 118 971 2835 fax

+1 (508) 520-2815 United States +1 (800) 274-4212 toll-free 27 Forge Parkway Franklin, MA 02038 USA +1 (508) 428-3535 fax

www.thermo.com/rmp

