

Thermo Scientific Model 48i-TLE

Trace level enhanced carbon monoxide analyzer

The Thermo Scientific™ Model 48i-TLE Carbon Monoxide (CO) Analyzer utilizes gas filter correlation technology to measure the amount of carbon monoxide in the air.

Features

- U.S. EPA Designated Method (RFCA-0981-054)
- Ethernet connectivity for efficient remote access
- Enhanced user interface with one button programming and large display screen
- Flash memory for increased data storage and user downloadable software
- Enhanced electronics design optimizes product commonality

Introduction

The Thermo Scientific Model 48i-TLE Analyzer is a single chamber, single photomultiplier tube design that measures only CO.

Dual range and auto range are standard features in this instrument. Because the instrument is operated continuously in the CO mode, the response time is less than 10 seconds.



Temperature and pressure correction are standard features. User settable alarm levels for concentration a wide variety of internal diagnostics are available from an easy to follow menu.

This state-of-the-art gas analyzer offers features such as an Ethernet port as well as flash memory for increased data storage and field upgradeability.

Ethernet connectivity provides efficient remote access, allowing the user to download measurement information directly from the instrument without having to be on-site. Easily programmable short cut keys allow you to jump directly to frequently accessed functions, menus or screens. The larger interface screen can display measurement information and status, while viewing menu and operational screens.



ThermoFisher
SCIENTIFIC

Thermo Scientific Model 48i-TLE
Trace Level Enhanced
Carbon Monoxide Analyzer

Thermo Scientific Model 48i-TLE Trace Level Enhanced Carbon Monoxide Analyzer

Specifications	
Preset ranges	0-1, 5, 10, 20, 50, 100, 200, 500, 1000 ppm 0-1, 2, 5, 10, 20, 50, 100, 200, 500, 1000 mg/m ³
0-1 to 1000 ppm	0-1 to 10000 ppm, 0-1 to 10000 mg/m ³
Zero noise	0.02 ppm RMS (60 second averaging time)
Lower detectable limit	0.04 ppm
Zero drift (24 hour)	< 0.1 ppm
Span drift (24 hour)	+/-1% full scale
Response time	60 seconds (30 second average time)
Linearity	+/-1% full scale < 1000 ppm
Sample flow rate	0.5 liters/min
Power requirements	100 VAC, 115 VAC, 220-240 VAC +/-10% @ 300W
Size and weight	16.75" (W) x 8.62" (H) x 23" (D), 55 lbs. 425 mm (W) x 219 mm (H) x 584 mm (D), 25 kg
Outputs	Selectable voltage, RS232/RS485, TCP/IP, 10 status relays and power fail indication (standard) 0-20 or 4-20 mA isolated current output (optional)
Inputs	16 digital inputs (standard), 8 0-10Vdc analog inputs (optional)

To maintain optimal product performance, you need immediate access to experts worldwide, as well as priority status when your air quality equipment needs repair or replacement. We offer comprehensive, flexible support solutions for all phases of the product life cycle. Through predictable, fixed-cost pricing, our services help protect the return on investment and total cost of ownership of your Thermo Scientific products.

Ordering information

Model 48i-TLE Trace Level Enhanced Carbon Monoxide Analyzer

Choose from the following configurations options to customize your own Model 48i-TLE Analyzer

1. Voltage options

A = 120 VAC 50/60 Hz

B = 220 VAC 50/60 Hz

J = 100 VAC 50/60 Hz

2. Internal zero / span and/or Oxygen Sensor

C = Internal zero / span valves w/zero air scrubber

3. Filter wheel purge

P = Filter wheel purge setup

4. Optional I/O

A = No optional I/O (standard)

C = 0-20, 4-20mA current output – 6 channels,
0-10v analog input -8 channel

5. Mounting hardware

A = Bench mounting and ears/handles, EIA

Other options

Tefl on particulate filter

Rack mounts

Rear extender

Your Order Code: Model 48i-TLE

<input type="text"/>	<input type="text"/>	<input type="text"/>	<input type="text"/>	<input type="text"/>
----------------------	----------------------	----------------------	----------------------	----------------------

USA

27 Forge Parkway
Franklin, MA 02038
Ph: (866) 282-0430
Fax: (508) 520-2800
orders.aqi@thermofisher.com

India

Industrial Unit No.101+130,
Plot No.C-56/1, TTC Industrial
area, MIDC-Turbhe,
New Mumbai 400 703, India
Ph: +91 82 9199 0337
INinfo@thermofisher.com

China

8/F Bldg C of Global Trade Ctr,
No.36, North 3rd Ring Road,
Dong Cheng District
Beijing, China 100013
Ph: +86 10 84193588
info.eid.china@thermofisher.com

Europe

Ion Path, Road Three,
Winsford, Cheshire CW73GA UK
Ph: +44 1606 548700
Fax: +44 1606 548711
sales.epm.uk@thermofisher.com

Find out more at thermofisher.com/cleanair

ThermoFisher
SCIENTIFIC